



RIGOL

MHO/DHO5000 Series

Digital Oscilloscope

User Guide

Nov. 2025

Guaranty and Declaration

Copyright

© 2025 RIGOL TECHNOLOGIES CO., LTD. All Rights Reserved.

Trademark Information

RIGOL® is the trademark of RIGOL TECHNOLOGIES CO., LTD.

Notices

- RIGOL products are covered by P.R.C. and foreign patents, issued and pending.
- RIGOL reserves the right to modify or change parts of or all the specifications and pricing policies at the company's sole decision.
- Information in this publication replaces all previously released materials.
- Information in this publication is subject to change without notice.
- RIGOL shall not be liable for either incidental or consequential losses in connection with the furnishing, use, or performance of this manual, as well as any information contained.
- Any part of this document is forbidden to be copied, photocopied, or rearranged without prior written approval of RIGOL.

Product Certification

RIGOL guarantees that this product conforms to the national and industrial standards in China as well as the ISO9001:2015 standard and the ISO14001:2015 standard. Other international standard conformance certifications are in progress.

Contact Us

If you have any problem or requirement when using our products or this manual, please contact RIGOL.

E-mail: service@rigol.com

Website: <http://www.rigol.com>

Section	Description	Page
	List of Figures.....	IX
	List of Tables.....	XVI
1	Safety Requirement	1
1.1	General Safety Summary	1
1.2	Safety Notices and Symbols	3
1.3	Measurement Category	3
1.4	Ventilation Requirement	4
1.5	Working Environment	4
1.6	Care and Cleaning	6
1.7	Environmental Considerations	6
2	Product Features	8
3	Document Overview	10
4	Quick Start	13
4.1	General Inspection	13
4.2	Product Appearance	13
4.3	Appearance and Dimensions	15
4.4	To Prepare for Use	15
4.4.1	To Adjust the Supporting Legs	15
4.4.2	To Connect to AC Power	16
4.4.3	Turn-on Checkout	17
4.4.4	To Replace the Fuse	17
4.4.5	To Set the System Language	18
4.4.6	To Connect the Probe	18
4.4.7	Function Inspection	21
4.4.8	Probe Compensation	23
4.5	Product Overview	23
4.5.1	Front Panel Overview	23
4.5.2	Front Panel Function Overview	25
4.5.3	Rear Panel Overview	31
4.5.4	User Interface Overview	33
4.6	Touch Screen Gestures	36
4.6.1	Tap	36
4.6.2	Pinch&Stretch	36

4.6.3 Drag	37
4.6.4 Rectangle Drawing	38
4.7 Parameter Setting Method	40
4.8 To Use the Security Lock	44
4.9 To Use the Built-in Help System	44
4.10 To View the Option Information and the Option Installation	44
5 Vertical System	46
5.1 To Enable or Disable the Analog Channel	46
5.2 To Adjust the Vertical Scale	48
5.3 To Adjust the Vertical Offset	49
5.4 Channel Coupling	50
5.5 Bandwidth Limit	50
5.6 Input Impedance	51
5.7 Waveform Invert	52
5.8 Probe	53
5.9 Amplitude Unit	57
5.10 Bias	58
5.11 Channel Delay	58
5.12 Channel Label	59
6 Horizontal System	60
6.1 To Adjust the Horizontal Time Base	60
6.2 To Adjust the Horizontal Position	61
6.3 Zoom Mode (Delayed Sweep)	62
7 Acquisition System	64
7.1 Acquisition Mode	64
7.2 Sampling Mode	65
7.3 Sample Rate	66
7.4 Memory Depth	67
7.5 Horizontal Expansion	68
7.6 Roll Mode	69
7.7 XY Mode	70
8 To Trigger the Oscilloscope	72
8.1 Trigger Source	73
8.2 Trigger Level	73
8.3 Trigger Mode	74
8.4 Trigger Coupling	76
8.5 Trigger Holdoff	76

8.6	Noise Rejection	77
8.7	Trigger Type	77
8.7.1	Edge Trigger	77
8.7.2	Pulse Trigger	78
8.7.3	Slope Trigger	81
8.7.4	Video Trigger	84
8.7.5	Pattern Trigger	86
8.7.6	Duration Trigger	88
8.7.7	Timeout Trigger	91
8.7.8	Runt Trigger	93
8.7.9	Window Trigger	95
8.7.10	Delay Trigger	97
8.7.11	Setup/Hold Trigger	100
8.7.12	Nth Edge Trigger	102
8.7.13	RS232 Trigger	104
8.7.14	I2C Trigger	106
8.7.15	SPI Trigger	110
8.7.16	CAN Trigger	113
8.7.17	FlexRay Trigger (Option)	116
8.7.18	LIN Trigger (Option)	118
8.7.19	I2S Trigger (Option)	120
8.7.20	MIL-STD-1553 Trigger (Option)	123
8.8	Zone Trigger	127
8.9	Trigger Output Connector	129
9	Math Operation	130
9.1	Arithmetic Operation	132
9.2	Function Operation	133
9.3	FFT Operation	135
9.4	Logic Operation	139
9.5	Digital Filter	142
9.6	Parameter Settings of the Math Operation Result	144
10	Measurements	147
10.1	Measurement Parameter	147
10.1.1	Time Parameters	147
10.1.2	Count Values	148
10.1.3	Delay and Phase Parameters	150
10.1.4	Voltage Parameters	151

10.1.5 Other Parameters	153
10.2 To Select the Measurement Item	153
10.3 Measurement Settings	154
10.4 Statistics of Measurement Results	157
10.5 To Remove the Measurement Results	158
10.6 Auto Measurement	159
10.7 Cursor Measurements	160
10.7.1 Manual Mode	162
10.7.2 Track Mode	164
10.7.3 XY Mode	167
11 Digital Voltmeter (DVM) and Frequency Counter	169
11.1 Digital Voltmeter (DVM)	169
11.1.1 Measurement Settings	169
11.1.2 To Remove the Measurement	171
11.2 Frequency Counter	171
11.2.1 Measurement Settings	172
11.2.2 To Reset Statistics	173
12 Digital Channels (Available Only for MHO Series)	174
12.1 Basic Settings	174
12.1.1 To Enable or Disable the Digital Channel	175
12.1.2 To Set the Label	175
12.1.3 To Select the Digital Channel	176
12.1.4 To Set the Threshold	176
12.2 Other Settings	176
12.2.1 To Set the Waveform Size	177
12.2.2 To Set the Channel Sequence	177
12.2.3 Priority of the Waveform Display	177
12.2.4 To Set the Probe Delay	178
13 Histogram Analysis	179
13.1 To Enable or Disable the Histogram	179
13.2 To Select the Histogram Type	180
13.3 To Select the Histogram Source	180
13.4 To Set the Histogram Height	181
13.5 To Set the Histogram Range	181
13.6 Histogram Analysis Results	181
13.7 To Remove the Measurement	182
13.8 To Clear Statistics	182

14 Function/Arbitrary Waveform Generator (Available Only for MHO5054/5104)	183
14.1 To Output Basic Waveforms	184
14.1.1 Sine	184
14.1.2 Square	186
14.1.3 Ramp	186
14.1.4 Pulse	187
14.1.5 Noise	187
14.1.6 DC	188
14.1.7 Exp.Rise	188
14.1.8 Exp.Fall	188
14.1.9 ECG1	189
14.1.10 Gauss	189
14.1.11 Lorentz	190
14.1.12 Haversine	191
14.1.13 Sinc	191
14.2 Modulation	192
14.2.1 AM	193
14.2.2 FM	194
14.2.3 PM	196
15 Bode Plot (Available Only for MHO5054/5104)	198
15.1 Basic Setting	199
15.1.1 To Enable or Disable the Bode Plot Function	199
15.1.2 To Run or Stop the Drawing of the Bode Plot	199
15.1.3 To Set the Input/Output Source	199
15.1.4 To Set the Sweep Signal	200
15.1.5 To Set the Display Type	200
15.1.6 To View the Connection Diagram	202
15.2 Ampl/Freq Setting	203
15.3 To Save and Load the Bode Plot File	203
16 Power Analysis (Option)	205
17 Reference Waveform	208
17.1 To Enable the Ref Function	208
17.2 To Set the Reference Waveform	208
17.3 To Set the Ref Waveform Display	209
17.4 To Export and Import the Reference Waveform	210
18 Pass/Fail Test	212

18.1	To Enable or Disable the Pass/Fail Test Function	212
18.2	To Select the Source	213
18.3	To Set the Test Mask	213
18.4	To Set the Output Form of the Test Results	214
18.5	To Start or Stop the Pass/Fail Test Operation	215
18.6	To Display the Statistics Information of the Test Results	215
19	Protocol Decoding	217
19.1	Parallel Decoding	217
19.1.1	Clock Setting (CLK)	218
19.1.2	Bus Setting	219
19.1.3	Display-related Setting	221
19.1.4	Event Table	222
19.2	RS232 Decoding	223
19.2.1	Source Setting	224
19.2.2	To Set Data Package	225
19.2.3	Display-related Setting	226
19.2.4	Event Table	226
19.3	I2C Decoding	227
19.3.1	Source Setting	228
19.3.2	Display-related Setting	230
19.3.3	Event Table	230
19.4	SPI Decoding	231
19.4.1	Source Setting	232
19.4.2	To Set the Mode and Data	233
19.4.3	Display-related Setting	234
19.4.4	Event Table	234
19.5	CAN Decoding	235
19.5.1	Signal Configuration	236
19.5.2	Display-related Setting	238
19.5.3	Event Table	238
19.6	LIN Decoding (Option)	239
19.6.1	Signal Configuration	240
19.6.2	Display-related Setting	241
19.6.3	Event Table	241
19.7	I2S Decoding (Option)	242
19.7.1	Source Setting	243
19.7.2	Bus Setting	244

19.7.3	Display-related Setting	245
19.7.4	Event Table	245
19.8	FlexRay Decoding (Option)	246
19.8.1	Signal Configuration	247
19.8.2	Display-related Setting	248
19.8.3	Event Table	248
19.9	1553B Decoding (Option)	249
19.9.1	To Set the Data Channel Source and the Threshold	250
19.9.2	Event Table	250
20	Multi-pane Windowing	253
21	Waveform Recording and Playing	255
21.1	Common Settings	255
21.2	Record Options	256
21.3	Play Options	257
22	Search and Navigation Function	260
22.1	Search Function	260
22.2	Navigation Function	262
23	Display Control	266
23.1	Display Type	266
23.2	Persistence Time	266
23.3	Waveform Intensity	267
23.4	To Set the Screen Grid	267
23.5	Display Setting	267
23.6	Show Scale	268
23.7	Color Grade	268
23.8	Waveform Freeze	268
24	To Store and Load	269
24.1	To Enter the Storage Menu	269
24.2	To Save a File	269
24.2.1	To Save the Image	271
24.2.2	To Save the Wave	271
24.2.3	To Save the Setup	273
24.2.4	Binary Data Format (.bin)	273
24.3	To Upload the File via the FTP Server	277
24.4	To Load the Setup File	277
24.5	Upgrade	278
24.6	Disk Management	279

25	System Utility Function Setting	282
25.1	I/O Setting	282
25.2	Basic Settings	284
25.3	About this Oscilloscope	287
25.4	Other Settings	287
25.5	Auto Config	288
25.6	SelfCal	288
25.7	Option List	289
25.8	Quick Operation	289
25.9	Self-check	291
26	Remote Control	294
26.1	Remote Control via USB	295
26.2	Remote Control via LAN	295
26.3	Remote Control via GPIB	296
27	Troubleshooting	298
28	Appendix	300
28.1	Appendix A: Options and Accessories	300
28.2	Appendix B: Warranty	301
28.3	Appendix C: Factory Settings	302

List of Figures

Figure 4.1 DHO5108 Front Panel	13
Figure 4.2 MHO5104 Front Panel	14
Figure 4.3 Rear Panel	14
Figure 4.4 Front View	15
Figure 4.5 Side View	15
Figure 4.6 Adjust the Supporting Legs	16
Figure 4.7 Connect to AC Power	16
Figure 4.8 Replace the Fuse	18
Figure 4.9 Connect the Passive Probe	19
Figure 4.10 Connect the Probe Head to the PA of the Active Probe	19
Figure 4.11 Connect the Active Probe	20
Figure 4.12 Connect the Logic Probe	21
Figure 4.13 Use the Compensation Signal	22
Figure 4.14 Square Waveform Signal	22
Figure 4.15 Probe Compensation	23
Figure 4.16 MHO5104 Front Panel	24
Figure 4.17 DHO5108 Front Panel	24
Figure 4.18 Rear Panel	31
Figure 4.19 DHO5108 User Interface	33
Figure 4.20 MHO5104 User Interface	33
Figure 4.21 Tap Gesture	36
Figure 4.22 Pinch&Stretch Gesture	37
Figure 4.23 Drag Gesture	38
Figure 4.24 Rectangle Drawing Gesture (a)	38
Figure 4.25 Rectangle Drawing Gesture (b)	39
Figure 4.26 English Input Interface	40
Figure 4.27 Chinese Input Interface	42

Figure 4.28 Numeric Keypad	43
Figure 4.29 Use the Security Lock	44
Figure 5.1 Vertical Menu	46
Figure 5.2 Input Impedance Switchover	52
Figure 5.3 Waveform Invert	53
Figure 5.4 Probe Setting Menu	53
Figure 5.5 Active Probe Setting Menu	54
Figure 5.6 Zero Offset	59
Figure 6.1 Horizontal System Menu	60
Figure 6.2 Zoom Mode	63
Figure 7.1 Horizontal Menu	64
Figure 7.2 Memory Depth	67
Figure 7.3 XY Menu	70
Figure 7.4 Measurement Schematic Diagram of Phase Deviation	71
Figure 8.1 Trigger System Menu	72
Figure 8.2 Schematic Diagram of the Acquisition Memory	75
Figure 8.3 Trigger Holdoff	77
Figure 8.4 Positive/Negative Pulse Width	79
Figure 8.5 Pulse Trigger Setting Menu	79
Figure 8.6 Positive Slope Time/Negative Slope Time	81
Figure 8.7 Slope Trigger Setting Menu	82
Figure 8.8 Video Trigger Setting Menu	84
Figure 8.9 Pattern Trigger	86
Figure 8.10 Pattern Trigger Setting Menu of MHO Series 4-CH Model	87
Figure 8.11 Pattern Trigger Setting Menu of DHO Series 8-CH Model	87
Figure 8.12 Duration Trigger	89
Figure 8.13 Duration Trigger Setting Menu of MHO Series 4-CH Model	89
Figure 8.14 Duration Trigger Setting Menu of DHO Series 8-CH Model	90
Figure 8.15 Timeout Trigger	92

Figure 8.16 Timeout Trigger Menu	92
Figure 8.17 Runt Trigger	93
Figure 8.18 Runt Trigger Setting Menu	94
Figure 8.19 Window Trigger Setting Menu	96
Figure 8.20 Delay Trigger	98
Figure 8.21 Delay Trigger Setting Menu	98
Figure 8.22 Setup/Hold Trigger	100
Figure 8.23 Setup/Hold Trigger Setting Menu	101
Figure 8.24 Nth Edge Trigger	103
Figure 8.25 Nth Edge Trigger Setting Menu	103
Figure 8.26 Schematic Diagram of RS232 Protocol	104
Figure 8.27 RS232 Trigger Setting Menu	105
Figure 8.28 Sequential Chart of I2C Bus	107
Figure 8.29 I2C Trigger Setting Menu	107
Figure 8.30 Bin Format Setting	109
Figure 8.31 Hex Format Setting	109
Figure 8.32 Sequential Chart of SPI Bus	110
Figure 8.33 SPI Trigger Setting Menu	111
Figure 8.34 Data Frame Format of the CAN Bus	113
Figure 8.35 CAN Trigger Setting Menu	113
Figure 8.36 Sample Position (CAN Trigger)	114
Figure 8.37 Frame Format of FlexRay Bus	116
Figure 8.38 FlexRay Trigger Setting Menu	116
Figure 8.39 Data Frame Format of the LIN Bus	118
Figure 8.40 LIN Trigger Setting Menu	118
Figure 8.41 Sample Position (LIN Trigger)	119
Figure 8.42 Sequential Chart of I2S Bus	121
Figure 8.43 I2S Trigger Setting Menu	121

Figure 8.44 Formats of the Command Word, Data Word, and Status Word of the 1553B Bus	124
Figure 8.45 MIL-STD-1553 Trigger Setting Menu	125
Figure 9.1 Math Operation Menu	131
Figure 9.2 Math Operation Result Display Window	131
Figure 9.3 Arithmetic Operation Result Display Window	132
Figure 9.4 Function Operation Menu	133
Figure 9.5 Function Operation Result Display Window	134
Figure 9.6 FFT Operation Menu	135
Figure 9.7 FFT Operation Result Display Window	136
Figure 9.8 Peak Search	138
Figure 9.9 Logic Operation Menu	140
Figure 9.10 Logic Operation Result Display Window	141
Figure 9.11 Digital Filter Menu	142
Figure 9.12 Digital Filter Operation Result Display Window	143
Figure 10.1 Time Parameters	147
Figure 10.2 Delay and Phase Parameters	150
Figure 10.3 Voltage Parameters	151
Figure 10.4 Measurement Settings Menu	154
Figure 10.5 Display Statistics at the Right Section of the Screen	158
Figure 10.6 Cursors	160
Figure 10.7 Manual Mode Setting Menu	162
Figure 10.8 Manual Cursor Measurement Example	164
Figure 10.9 Track Mode Setting Menu	165
Figure 10.10 Track Measurement (before Horizontal Expansion)	166
Figure 10.11 Track Measurement (after Horizontal Expansion)	167
Figure 10.12 XY Mode Setting Menu	167
Figure 11.1 DVM Setting Menu	170
Figure 11.2 Frequency Counter Setting Menu	172

Figure 12.1 Basic Settings Tab of Logic Analyzer Interface	174
Figure 12.2 "Other Settings" Tab of Logic Analyzer Interface	177
Figure 13.1 Histogram Setting Menu	179
Figure 13.2 Histogram Analysis Interface	180
Figure 14.1 AFG Menu	184
Figure 14.2 Exp.Rise	188
Figure 14.3 Exp.Fall	189
Figure 14.4 ECG1	189
Figure 14.5 Gauss	190
Figure 14.6 Lorentz	190
Figure 14.7 Haversine	191
Figure 14.8 Sinc	191
Figure 14.9 Modulation Setting Interface	192
Figure 14.10 AM	193
Figure 14.11 FM	195
Figure 14.12 PM	196
Figure 15.1 Bode Plot Setting Menu	198
Figure 15.2 Minimized Bode Plot Window	198
Figure 15.3 Bode Plot Displayed in Waveform Display Form	201
Figure 15.4 Bode Plot Chart Display	202
Figure 16.1 Power Analysis Menu	205
Figure 16.2 Power Analysis Test Items	206
Figure 16.3 Power Analysis Test Connection Diagram	206
Figure 16.4 Power Analysis Test Results	207
Figure 17.1 Reference Waveform Menu	208
Figure 18.1 Pass/Fail Test Menu	212
Figure 18.2 Pass/Fail Test Interface	215
Figure 19.1 Schematic Diagram of Parallel Decoding	217
Figure 19.2 Parallel Decoding Menu	218

Figure 19.3 Parallel Decoding Event Table	222
Figure 19.4 Schematic Diagram of RS232 Serial Bus	223
Figure 19.5 RS232 Decoding Menu	224
Figure 19.6 RS232 Decoding Event Table	227
Figure 19.7 I2C Serial Bus	228
Figure 19.8 I2C Decoding Menu	228
Figure 19.9 I2C Decoding Event Table	230
Figure 19.10 SPI Serial Bus	231
Figure 19.11 SPI Decoding Menu	232
Figure 19.12 SPI Decoding Event Table	235
Figure 19.13 CAN Decoding Menu	236
Figure 19.14 Sample Position (CAN Decoding)	237
Figure 19.15 CAN Decoding Event Table	238
Figure 19.16 LIN Decoding Menu	240
Figure 19.17 LIN Decoding Event Table	241
Figure 19.18 I2S Decoding Menu	243
Figure 19.19 I2S Decoding Event Table	245
Figure 19.20 FlexRay Decoding Menu	246
Figure 19.21 Sample Position (FlexRay Decoding)	247
Figure 19.22 FlexRay Decoding Event Table	248
Figure 19.23 1553B Decoding Menu	250
Figure 19.24 1553B Decoding Event Table	251
Figure 20.1 Add Window Menu	253
Figure 21.1 Waveform Recording Interface	255
Figure 21.2 Minimized Window of Play Operation Interface	258
Figure 22.1 Search Menu	260
Figure 22.2 Marker Table	262
Figure 22.3 Navigation Menu	263
Figure 22.4 Minimized Navigation Window (Time Navigation)	263

Figure 22.5 Search Event Navigation Interface	264
Figure 23.1 Display Setting Menu	266
Figure 24.1 Storage Menu	270
Figure 24.2 Waveform Saving Setting Menu	272
Figure 24.3 Setup Saving Setting Menu	273
Figure 24.4 Setup File Loading Interface	278
Figure 24.5 Upgrade Menu	279
Figure 24.6 Disk Management Interface	280
Figure 25.1 Self-calibration Menu	289
Figure 25.2 Key Test Interface	291
Figure 25.3 Touch Screen Test Interface	292
Figure 26.1 Search for the Available Device	297
Figure 26.2 Confirm the Available Device	297

List of Tables

Table 5.1 Probe Ratio of the Voltage Probe	55
Table 5.2 Probe Ratio of the Current Probe	56
Table 5.3 Range of the External Attenuation	57
Table 8.1 Video Standard	85
Table 9.1 Window Function	137
Table 9.2 Logic Operation	140
Table 19.1 Bus Setting of DHO Series 8-CH Model	219
Table 19.2 Bus Setting of MHO Series 4-CH Model	220
Table 24.1 BIN File Format	273
Table 24.2 File Header	274
Table 24.3 Waveform Header	274
Table 24.4 Waveform Data Header	276
Table 28.2 Factory Settings	302

1 Safety Requirement

1.1 General Safety Summary

Please review the following safety precautions carefully before putting the instrument into operation so as to avoid any personal injury or damage to the instrument and any product connected to it. To prevent potential hazards, please follow the instructions specified in this manual to use the instrument properly.

- **Use Proper Power Cord.**

Only the exclusive power cord designed for the instrument and authorized for use within the local country could be used.

- **Ground the Instrument.**

The instrument is grounded through the Protective Earth lead of the power cord. To avoid electric shock, it is essential to connect the earth terminal of the power cord to the Protective Earth terminal before connecting any inputs or outputs.

- **Connect the Probe Correctly.**

If a probe is used, the probe ground lead must be connected to earth ground. Do not connect the ground lead to high voltage. Improper way of connection could result in dangerous voltages being present on the connectors, controls or other surfaces of the oscilloscope and probes, which will cause potential hazards for operators.

- **Observe All Terminal Ratings.**

To avoid fire or shock hazard, observe all ratings and markers on the instrument and check your manual for more information about ratings before connecting the instrument.

- **Use Proper Overvoltage Protection.**

Ensure that no overvoltage (such as that caused by a bolt of lightning) can reach the product. Otherwise, the operator might be exposed to the danger of an electric shock.

- **Do Not Operate Without Covers.**

Do not operate the instrument with covers or panels removed.

- **Do Not Insert Objects Into the Air Outlet.**

Do not insert anything into the holes of the fan to avoid damaging the instrument.

- **Use Proper Fuse.**

Please use the specified fuses.

- **Avoid Circuit or Wire Exposure.**

Do not touch exposed junctions and components when the unit is powered on.

- **Do Not Operate With Suspected Failures.**

If you suspect damage occurs to the instrument, have it inspected by RIGOL authorized personnel before further operations. Any maintenance, adjustment or replacement especially to circuits or accessories must be performed by RIGOL authorized personnel.

- **Provide Adequate Ventilation.**

Inadequate ventilation may cause an increase of temperature in the instrument, which would cause damage to the instrument. So please keep the instrument well ventilated and inspect the air outlet and the fan regularly.

- **Do Not Operate in Wet Conditions.**

To avoid short circuit inside the instrument or electric shock, never operate the instrument in a humid environment.

- **Do Not Operate in an Explosive Atmosphere.**

To avoid personal injuries or damage to the instrument, never operate the instrument in an explosive atmosphere.

- **Keep Instrument Surfaces Clean and Dry.**

To avoid dust or moisture from affecting the performance of the instrument, keep the surfaces of the instrument clean and dry.

- **Prevent Electrostatic Impact.**

Operate the instrument in an electrostatic discharge protective environment to avoid damage induced by static discharges. Always ground both the internal and external conductors of cables to release static before making connections.

- **Use the Battery Properly.**

Do not expose the battery (if available) to high temperature or fire. Keep it out of the reach of children. Improper change of a battery (lithium battery) may cause an explosion. Use the RIGOL specified battery only.

- **Handle with Caution.**

Please handle with care during transportation to avoid damage to keys, knobs, interfaces, and other parts on the panels.



WARNING

Equipment meeting Class A requirements may not offer adequate protection to broadcast services within residential environment.

1.2 Safety Notices and Symbols

Safety Notices in this Manual:



WARNING

Indicates a potentially hazardous situation or practice which, if not avoided, will result in serious injury or death.



CAUTION

Indicates a potentially hazardous situation or practice which, if not avoided, could result in damage to the product or loss of important data.

Safety Notices on the Product:

- **DANGER**

It calls attention to an operation, if not correctly performed, could result in injury or hazard immediately.

- **WARNING**

It calls attention to an operation, if not correctly performed, could result in potential injury or hazard.

- **CAUTION**

It calls attention to an operation, if not correctly performed, could result in damage to the product or other devices connected to the product.

Safety Symbols on the Product:



**Hazardous
Voltage**



Safety Warning



**Protective Earth
Terminal**



Chassis Ground



Test Ground

1.3 Measurement Category

Measurement Category

This instrument can make measurements in Measurement Category I.



WARNING

This instrument can only be used for measurements within its specified measurement categories.

Measurement Category Definitions

- **Measurement category I** is for measurements performed on circuits not directly connected to MAINS. Examples are measurements on circuits not derived from MAINS, and specially protected (internal) MAINS derived circuits. In the latter case, transient stresses are variable. Thus, you must know the transient withstand capability of the equipment.
- **Measurement category II** is for measurements performed on circuits directly connected to low voltage installation. Examples are measurements on household appliances, portable tools and similar equipment.
- **Measurement category III** is for measurements performed in the building installation. Examples are measurements on distribution boards, circuit-breakers, wiring (including cables, bus-bars, junction boxes, switches and socket-outlets) in the fixed installation, and equipment for industrial use and some other equipment. For example, stationary motors with permanent connection to a fixed installation.
- **Measurement category IV** is for measurements performed at the source of a low-voltage installation. Examples are electricity meters and measurements on primary overcurrent protection devices and ripple control units.

1.4 Ventilation Requirement

This instrument uses a fan to force cooling. Please make sure that the air inlet and outlet areas are free from obstructions and have free air. When using the instrument in a bench-top or rack setting, provide at least 10 cm clearance beside, above and behind the instrument for adequate ventilation.



CAUTION

Inadequate ventilation may cause an increase of temperature in the instrument, which would cause damage to the instrument. So please keep the instrument well ventilated and inspect the air outlet and the fan regularly.

1.5 Working Environment

Temperature

Operating: -10°C to +50°C

Non-operating: -30°C to +60°C

Humidity

- **Operating:**
 - Below +30°C: ≤90%RH (without condensation)
 - +30°C to +40°C: ≤75% RH (without condensation)

+40°C to +50°C: ≤45%RH (without condensation)

- **Non-operating:**

Below +60°C: ≤90% RH (without condensation)



WARNING

To avoid short circuit inside the instrument or electric shock, never operate the instrument in a humid environment.

Altitude

- **Operating:** below 3 km
- **Non-operating:** below 15 km

Protection level against electric shock

ESD ±8kV

Installation (Overvoltage) Category

This product is powered by mains conforming to installation (overvoltage) category II.



WARNING

Ensure that no overvoltage (such as that caused by a bolt of lightning) can reach the product. Otherwise, the operator might be exposed to the danger of an electric shock.

Installation (Overvoltage) Category Definitions

Installation (overvoltage) category I refers to signal level which is applicable to equipment measurement terminals connected to the source circuit. Among these terminals, precautions are done to limit the transient voltage to a low level.

Installation (overvoltage) category II refers to the local power distribution level which is applicable to equipment connected to the AC line (AC power).

Pollution Degree

Pollution Degree 2

Pollution Degree Definition

- **Pollution Degree 1:** No pollution or only dry, nonconductive pollution occurs. The pollution has no effect. For example, a clean room or air-conditioned office environment.
- **Pollution Degree 2:** Normally only nonconductive pollution occurs. Temporary conductivity caused by condensation is to be expected. For example, indoor environment.

- **Pollution Degree 3:** Conductive pollution or dry nonconductive pollution that becomes conductive due to condensation occurs. For example, sheltered outdoor environment.
- **Pollution Degree 4:** The pollution generates persistent conductivity caused by conductive dust, rain, or snow. For example, outdoor areas.

Safety Class

Class 1 – Grounded Product

1.6 Care and Cleaning

Care

Do not store or leave the instrument where it may be exposed to direct sunlight for long periods of time.

Cleaning

Clean the instrument regularly according to its operating conditions.

1. Disconnect the instrument from all power sources.
2. Clean the external surfaces of the instrument with a soft cloth dampened with mild detergent or water. Avoid having any water or other objects into the chassis via the heat dissipation hole. When cleaning the LCD, take care to avoid scarifying it.

CAUTION

To avoid damage to the instrument, do not expose it to caustic liquids.

WARNING

To avoid short-circuit resulting from moisture or personal injuries, ensure that the instrument is completely dry before connecting it to the power supply.

1.7 Environmental Considerations

The following symbol indicates that this product complies with the WEEE Directive 2012/19/EU.



The equipment may contain substances that could be harmful to the environment or human health. To avoid the release of such substances into the environment and avoid harm to human health, we recommend you to recycle this product

appropriately to ensure that most materials are reused or recycled properly. Please contact your local authorities for disposal or recycling information.

You can click on the following link <https://www.rigol.com/intl/services/environmental-protection-statement.html> to download the latest version of the RoHS&WEEE certification file.

2 Product Features

Product Features

- Based on RIGOL's brand new self-developed Centaurus technical platform
- 12-bit resolution for all the series^[1]
- Max. 1 GHz bandwidth, 8 analog channels, and 1 external trigger channel
- Standard configuration of 16 digital channels (required to purchase the logic analyzer probe) for the MHO models
- Real-time sample rate: up to 4 GSa/s
- Max. memory depth 500 Mpts
- Vertical sensitivity up to 100 $\mu\text{V}/\text{div}$
- Maximum waveform capture rate of 1,000,000 wfms/s in fast recording mode
- Arbitrary Waveform/Function Generator (AFG)^[2], power analysis, histogram, and digital signal analysis^[3], Bode plot^[4], and protocol decodings
- Search and navigation functions enable users to quickly search for the signals with exceptions and locate them accurately
- 256-level intensity grading display, with digital real-time fluorescence technology
- 10.1" 1280*800 high-definition touch screen
- Brand new Flex knob brings friendly user experience
- Standard configuration of USB Device, USB Host, LAN, HDMI interfaces for all the series
- Battery pack-powered, convenient to charge anytime and anywhere, providing great feasibility for measurement
- Online upgrade
- Standard configuration of the photoelectric encoder operating knob for all the series to improve the service life of the instrument

The MHO/DHO5000 series (4/6/8-CH) is a high-resolution digital oscilloscope designed for the vast mainstream digital oscilloscope market to meet the design, debugging, and test demands. It is developed based on RIGOL's brand new self-developed Centaurus technical platform. Its 1,000,000 wfms/s waveform capture rate (in fast recording mode), 500 Mpts memory depth, 12-bit resolution, excellent noise floor and vertical measurement accuracy can meet the test demands for higher accuracy. The MHO/DHO5000 series digital oscilloscope has multiple models, supporting AFG, digital signal analysis, Bode plot, and other functions. It is powered by battery pack, convenient to operate and control, applicable for various complex test scenarios.

Note:

[1]: Up to 16-bit in high resolution mode.

-
- [2]: The AFG function is the optional configuration for MHO5054 and MHO5104.
- [3]: Digital signal analysis is only available for the MHO series.
- [4]: The Bode plot function is only available for MHO5054 and MHO5104 models.

3 Document Overview

This manual gives you a quick overview of the front and rear panel, user interface as well as basic operation methods of MHO/DHO5000 series.



TIP

For the latest version of this manual, download it from the official website of RIGOL (<http://www.rigol.com>).

Publication Number

UGA43103-1110

Software Version

00.01.00

Software upgrade might change or add product features. Please acquire the latest version of the manual from RIGOL website or contact RIGOL to upgrade the software.

Format Conventions in this Manual

1. Key

The front panel key is denoted by the menu key icon. For example, indicates the "DEFAULT" key.



2. Menu

The menu item is denoted by the format of "Menu Name (Bold) + Character Shading" in the manual. For example, **Setup** indicates the "Setup" sub-menu under the "Utility" function menu. You can click or tap **Setup** to access the "Setup" menu.

3. Operation Procedures

The next step of the operation is denoted by ">" in the manual. For example,



> **Storage** indicates first clicking or tapping  and then clicking or tapping **Storage**.

4. The front/rear panel connector is denoted by "Brackets + Connector Name (Bold)", for example, **[AUX OUT]**.

5. Knob

Label	Knob	Label	Knob
Horizontal POSITION 	Horizontal Position Knob	 1	Multifunction Knob 1

Label	Knob	Label	Knob
Horizontal  <u>SCALE</u>	Horizontal Scale Knob	 <u>2</u>	Multifunction Knob 2
Vertical  <u>POSITION</u>	Vertical Position Knob	 <u>LEVEL</u>	Trigger Level Knob
Vertical  <u>SCALE</u>	Vertical Scale Knob	-	-

Content Conventions in this Manual

MHO/DHO5000 series digital oscilloscope includes the following models, which support different combinations of features.

Model	Max. Analog Bandwidth	Analog Channels	Function/ Arbitrary Waveform Generator Channels	Digital Channels	Bode Plot
DHO5054	500 MHz	4	-	-	-
DHO5104	1 GHz	4	-	-	-
MHO5054	500 MHz	4	2 ^[1]	16	Supported ^[1]
MHO5104	1 GHz	4	2 ^[1]	16	Supported ^[1]
MHO5056	500 MHz	6	-	16	-
MHO5106	1 GHz	6	-	16	-
DHO5058	500 MHz	8	-	-	-
DHO5108	1 GHz	8	-	-	-

Note: [1] The MHO5000-AWG option is required to be installed for use.

- Analog channels supported by each model:
 - DHO5058/DHO5108: CH1 to CH8
 - DHO5054/DHO5104: CH1 to CH4
 - MHO5056/MHO5106: CH1 to CH6
 - MHO5054/MHO5104: CH1 to CH4
- Only MHO series models support digital channels: D0 to D15

Unless otherwise specified, this manual takes DHO5108 as an example to illustrate the operation methods of MHO/DHO5000 series. The digital analysis, function/arbitrary waveform generator and Bode plot are illustrated by the MHO5104 model.

4 Quick Start

4.1 General Inspection

1. Inspect the packaging

If the packaging has been damaged, do not dispose the damaged packaging or cushioning materials until the shipment has been checked for completeness and has passed both electrical and mechanical tests.

The consigner or carrier shall be liable for the damage to the instrument resulting from shipment. RIGOL would not be responsible for free maintenance/rework or replacement of the instrument.

2. Inspect the instrument

In case of any mechanical damage, missing parts, or failure in passing the electrical and mechanical tests, contact your RIGOL sales representative.

3. Check the accessories

Please check the accessories according to the packing lists. If the accessories are damaged or incomplete, please contact your RIGOL sales representative.

Recommended Calibration Interval

RIGOL suggests that the instrument should be calibrated every 18 months.

4.2 Product Appearance



Figure 4.1 DHO5108 Front Panel



Figure 4.2 MHO5104 Front Panel



Figure 4.3 Rear Panel

4.3 Appearance and Dimensions




Figure 4.4 Front View




Figure 4.5 Side View

4.4 To Prepare for Use

4.4.1 To Adjust the Supporting Legs

Adjust the supporting legs properly to use them as stands to tilt the oscilloscope upwards for stable placement of the oscilloscope to better operate and observe. You

can also fold the supporting legs when the instrument is not in use for easier storage or shipment, as shown in the figure below.




Figure 4.6 Adjust the Supporting Legs

4.4.2 To Connect to AC Power

The AC power requirements of the oscilloscope are 100-240 V, 50/60 Hz, 400VA Max. Please use the power cord provided in the accessories to connect the oscilloscope to the AC power source, as shown in the figure below.




Figure 4.7 Connect to AC Power



WARNING

To avoid electric shock, ensure that the instrument is correctly grounded.

**TIP**

When the oscilloscope equipped with the battery pack is connected to the AC power, the oscilloscope is energized and the AC power can also charge the battery pack. For details about battery pack installation, refer to *BatHolder138 User Guide*.

4.4.3 Turn-on Checkout

After the instrument is connected to the power source, press the power key  at the lower-left corner of the front panel to power on the instrument. During the start-up process, the instrument performs a series of self-tests. After the self-test, the splash screen is displayed.

- **Restart:** Click or tap  > **Restart**. Then a prompt message "Are you sure to reboot?" is displayed. Click or tap **OK** to restart the instrument.
- **Shutdown:**
 - Click or tap  > **Shutdown**. Then a prompt message "Are you sure to shutdown?" is displayed. Click or tap **OK** to shut down the instrument.
 - Press the power key  and a prompt message "Are you sure to shutdown?" is displayed. Click or tap **OK** to shut down the instrument.
 - Press  twice to directly shut down the instrument.
 - Press  for three seconds to directly shut down the instrument.

**TIP**

You can also click or tap  > **Utility** > **Setup**, then select "Switch On" under the "Power Status" menu. After this setting, the instrument powers on once connected to power.

4.4.4 To Replace the Fuse

If you need to replace the fuse, please use the proper fuse (AC 250 V, T5 A; 5.2 mm×20 mm) and follow the steps shown below.

1. Power off the instrument and remove the power cord.
2. Insert a small straight screwdriver into the slot at the power socket and pry out the fuse holder gently.
3. Remove the fuse.
4. Insert the proper fuse into the fuse holder.

5. Re-insert the fuse holder into the power socket.




Figure 4.8 Replace the Fuse



WARNING

To avoid electric shock, please make sure that the instrument is powered off and disconnected from the power before replacing the fuse. Also, please make sure the fuse is consistent with the required fuse rating.

4.4.5 To Set the System Language

This oscilloscope supports multiple languages. You can click or tap  > **Utility** > **Setup** > **Language** to select the system language.

4.4.6 To Connect the Probe

RIGOL provides the passive probe, active probe, and logic probe for MHO/DHO5000 series. For specific probe models, please refer to *MHO/DHO5000 Data Sheet*. For detailed technical information of the probes, please refer to the corresponding Probe User Guide.

Connect the Passive Probe

1. Connect the BNC terminal of the probe to an analog channel input terminal of the oscilloscope on the front panel as shown in the figure below.
2. Connect the ground alligator clip or spring of the probe to the circuit ground terminal, and then connect the probe tip to the circuit point to be tested.




Figure 4.9 Connect the Passive Probe

After you connect the passive probe, check the probe function and probe compensation adjustment before making measurements. For details, please refer to *Function Inspection* and *Probe Compensation*.

Connect the Active Probe

Take PVA7250 (active differential probe) as an example.

1. Connect the probe head to the preamp of the active probe, as shown in the figure below.




Figure 4.10 Connect the Probe Head to the PA of the Active Probe

2. Connect the other end of the preamp to an analog channel input terminal of the oscilloscope on the front panel, as shown in the figure below. Note that you need to push the probe to the due position to lock it firmly.




Figure 4.11 Connect the Active Probe

3. Use the probe's auxiliary device to connect the probe head to the circuit under test. For detailed information of the probes, please refer to *User Guide for PVA7000 Series Active Probe*.

After connecting the active probe, you can perform probe calibration and offset voltage adjustment if necessary. For details, refer to descriptions about the active probe in this User Guide.

Connect the Logic Probe

1. Connect the output terminal of the logic probe to the digital channel input terminal on the front panel of the oscilloscope in the correct direction, as shown in the figure below.
2. Connect the other terminal of the logic probe to the signal terminal under test. MHO/DHO5000 provides the optional PLA3204 active logic probe. For details, refer to *User Guide for PLA3204 Logic Probe*.




Figure 4.12 Connect the Logic Probe



TIP

- For ground connection of high-speed signals, the ground lead shall be connected to the ground test point near the measured signal, and the ground lead shall be kept as short as possible.
- If there are a large number of input signal channels, please connect each signal to a ground signal as far as possible. If there is only one ground test point, connect all ground leads on the probe to the ground test point.
- Set a proper threshold value for the logic probe according to the actual level range of the signal under test. Set the threshold value to the middle of the level range.

4.4.7 Function Inspection

1. Press the front-panel  and a prompt message "Restore default settings?" is displayed. Click or tap **OK** to restore the instrument to its factory default settings.
2. Connect the ground alligator clip of the probe to the "Ground Terminal" as shown in *Figure 4.13*.
3. Use the probe to connect the input terminal of CH1 and the "Compensation Signal Output Terminal" of the probe, as shown in *Figure 4.13*.




Figure 4.13 Use the Compensation Signal

4. Set the probe ratio based on the attenuation of the probe, and then click or tap



5. Observe the waveform on the display. In normal condition, you should see a square waveform as shown in the figure below.




Figure 4.14 Square Waveform Signal

6. Use the same method to test other channels. If the square waveforms actually shown do not match that in the figure above, please perform *Probe Compensation* introduced in the next section. If no waveform is displayed on the screen, perform the above steps again.



WARNING

To avoid electric shock when using the probe, please make sure that the insulated wire of the probe is in good condition. Do not touch the metallic part of the probe when the probe is connected to high voltage source.

4.4.8 Probe Compensation

When used for the first time, the oscilloscope probe must be compensated to match the input characteristics of the oscilloscope channel to which it is connected. The non-compensated or poorly compensated probe may cause measurement errors. The compensation procedure is as follows:

1. Perform step 1, 2, 3, and 4 in *Function Inspection*.
2. Check the displayed waveforms and compare them with waveforms shown in the figure below.




Figure 4.15 Probe Compensation

3. Use the probe compensation adjustment tool provided in the accessories to adjust the low-frequency compensation adjustment hole on the probe until the displayed waveform is consistent with the "Perfectly compensated" waveform shown in the figure above.

4.5 Product Overview

RIGOL MHO/DHO5000 series is a high-resolution digital oscilloscope designed for the vast mainstream digital oscilloscope market to meet the design, debugging, and test demands. It is developed based on RIGOL's brand new self-developed Centaurus technical platform. Its 4 GSa/s sample rate, 1 GHz real-time bandwidth, 1,000,000 wfms/s waveform capture rate (in fast recording mode), 500 Mpts memory depth, 12-bit resolution, excellent noise floor and vertical measurement accuracy can meet the test demands for higher accuracy. MHO/DHO5000 series digital oscilloscope has multiple models, supporting AFG, digital signal analysis, Bode plot, and other functions. It is powered by battery pack, convenient to operate and control, applicable for various complex test scenarios.

4.5.1 Front Panel Overview

This chapter takes the MHO5104 model with digital channels and arbitrary waveform generator (AFG) features, and the eight-channel DHO5108 model as examples to introduce the front panel.




Figure 4.16 MHO5104 Front Panel




Figure 4.17 DHO5108 Front Panel

- | | | | |
|---|-------------------------------|----|---|
| 1 | 10.1" Capacitive Touch Screen | 10 | Vertical Control Area |
| 2 | Multifunction Knobs | 11 | Probe Compensation Signal Output Terminal/Ground Terminal |
| 3 | Measure Key | 12 | Horizontal Control Area |
| 4 | Cursor Key | 13 | Analog Channel Input Terminals |
| 5 | Analyse Key | 14 | Digital Channel Input (Type-C Interface) ^[1] |

6	Touch Lock Key	15	Dual-Channel Function/Arbitrary Waveform Generator Output Terminal ^[2]
7	Common Operation Keys	16	USB HOST Interface
8	Quick Operation Key (Self-defined function)	17	Power Key
9	Trigger Control Area		



NOTE

[1]: Digital channels are only available for MHO5054, MHO5104, MHO5056, and MHO5106 models.


[2]: Function/Arbitrary Waveform Generator (AFG) is the optional configuration only for MHO5054 and MHO5104 models.

4.5.2 Front Panel Function Overview

1. 10.1" capacitive touch screen

Displays the waveform, menu name, parameter setting, system state, prompt messages, etc.

2. Multifunction Knobs



- Non-menu operation:

When not operating on the menu, you can rotate the knob 1 to adjust the waveform brightness. When a cursor, decoding, Math waveform, or reference waveform is added on the screen, you can rotate the multifunction knob (knob 1 and 2) to move the cursor, adjust the decode threshold (knob 1) and decode result display position (knob 2), adjust the vertical scale (knob 1) and vertical offset (knob 2) of the math/reference waveform. You can click or tap **Flex Knob** on the Toolbar at the upper-right of the screen to set the priority.

- Automatic: Cursor > (Math/Ref/Decode) > Intensity (default priority).

- Manual: all non-menu operation items are listed at the lower part of the **Flex Knob** menu. You can select one of them as the current item for the multifunction knob to adjust.

- Menu operation:

When operating on the menu, you can rotate the multifunction knob 1/2 to adjust the value in the menu. When you click or tap the input field and then the **1 / 2** icon is displayed in the input field, it indicates that you can use multifunction knob 1/2 to set the value. The LED indicator of the corresponding knob is illuminated. At this point, you can rotate the knob to adjust the value or press down the knob to restore the parameter to the default value.

When using the virtual numeric keypad or selecting from the drop-down list, you can rotate the knob to navigate through the keypad or drop-down list, then press down the knob to select an item.

3. Measure Key



: press this key to enter the "Measure" interface. You can set the measurement source, select the measurement item, etc.

4. Cursor Key



: press this key to enter the cursor measurement interface. The measurement results are displayed in the result list at the right section of the screen. This instrument provides three cursor modes: Manual, Track, and XY. XY mode is only available when the XY function is enabled.

5. Analyse Key




: press this key to enter the "Analyse" interface. You can click or tap "DVM", "Counter", "UPA", "Record", and "Pass/Fail" to enter the specified function interface.

6. Touch Lock Key



: press this key to disable the touch screen. Once disabled, press this key again to enable the touch screen.

7. Common Operation Keys




- : waveform auto setting key. Press this key to enable the waveform auto setting function. The oscilloscope will automatically adjust the vertical scale, horizontal time base, and trigger mode according to the input signal to realize optimal waveform display.
- : runs or stops the instrument. Press this key to set the operating state of the oscilloscope to "RUN" or "STOP". In the RUN state, the backlight of the key is illuminated in green. In the STOP state, the backlight of the key is illuminated in red.
- : single trigger key. Press this key to set the trigger mode to "Single".
- : default setting key. Press this key, and then a prompt message is displayed. Click or tap **OK** to restore the instrument to its default settings.
- : Clear key. Press this key to clear all the waveforms on the screen. If the oscilloscope is in the "RUN" state, new waveforms will continue being displayed.

8. Quick Operation Key

- : press this key to perform the quick operation for the specified function such as saving image, saving waveforms, saving setup files, performing All Measure function, resetting statistics, recording waveforms, and saving group.

9. Trigger Control Area




- : trigger setting key. Press this key to enter the "Trigger" interface.
- : trigger edge setting key. Press this key to switch the edge type (rising, falling, or either) of the Edge trigger signal. When the trigger type is not edge type, this key is unavailable to use.
- : force trigger key. Press this key to generate a trigger signal forcibly.
-  **LEVEL**: used to modify the trigger level/threshold level. Rotate it clockwise to increase the level, and rotate it counterclockwise to decrease the level. Press

down the knob to quickly set the trigger level/threshold level to 50% of the waveform peak-peak value.

10. Vertical Control Area

This part takes MHO5104 model that supports the digital channel and AFG function as an example to introduce the vertical control area on the front panel.




- **Vertical  POSITION**: channel vertical position knob. Rotate this knob to modify the vertical position of the waveform for the specified channel. The waveforms will move up and down on the screen. Press down the knob to reset the vertical position to zero.
- **Vertical  SCALE**: channel vertical scale knob. Rotate this knob to modify the amplitude of each vertical grid of the selected waveform, making its amplitude increase or decrease. Press down this knob, then you can rotate it to switch between the coarse and fine adjustment of the vertical scale.
- ** Ref**: reference waveform key. Press this key to enter the reference waveform setting interface. The reference waveform is displayed in the waveform view. Compare the actual waveform with the reference waveform to locate the circuit failure problem.
- ** Math**: math operation key. Press this key to enter the math operation interface. You can perform the math operations such as $A+B$, $A-B$, $A \times B$, A/B , and FFT. Besides, you can also set the math operation label.
- ** LAT**: logic analyzer setting key. Press this key to open the logic analyzer control menu. You can enable or disable any channel or channel group, modify the waveform size of the digital channels, modify the threshold, group the 16 digital channels, etc. Besides, you can set the label for each digital channel.

- **GI**, **GII**: Function/Arbitrary Waveform Generator setting key. Press **[GI]** or **[GII]** on the front panel to enable or disable the output of the **[GI]** or **[GII]** connector, and enter the specified AFG interface.
- **1**, **2**, **3**, **4**: analog channel key. Press the specified key to enable or disable the specified channel.
 - If the channel is not displayed, you can press the channel key to open the channel in the waveform view window.
 - If the channel is displayed but not selected, you can press the channel key to select the channel.
 - If the channel is both displayed and selected, you can press the channel key to close its display in the waveform view.

11. Probe Compensation Signal Output Terminal/Ground Terminal

This terminal outputs the probe compensation signal which helps you match a probe's input capacitance to the oscilloscope channel to which it is connected.

12. Horizontal Control Area



- **Horizontal  POSITION**: horizontal position knob. Rotate this knob to modify the horizontal position (that is, trigger position), making the waveforms move left and right. Press down this knob to reset the horizontal position.
- **Horizontal  SCALE**: horizontal scale knob. Rotate this knob to modify the horizontal time base of the waveform, then the displayed waveforms of all channels are expanded or compressed horizontally. Press down this knob, then you can rotate it to switch between the coarse and fine adjustment of the horizontal scale.

- : waveform acquisition setting key. Press this key to enter the acquisition and horizontal menu. You can set the time base mode, the acquisition mode, memory depth, and etc.
- : zoom key, also called the delayed sweep key. Press this key to enable or disable the delayed sweep function.
- : navigation key. Press this key to enter the navigation menu. You can set the navigation mode by time or search event.
- : navigation combination key.

13. Analog Channel Input Terminals

Used to connect the probe to input the analog signal.

14. Digital Channel Input (Type-C Interface)^[1]

Four USB Type-C interfaces. They are used to connect the logic analyzer probe to input the digital signal.

15. Dual-channel Function/Arbitrary Waveform Generator Output Terminal^[2]

Used to connect the Function/Arbitrary Waveform Generator signal. Press **[GI]** or **[GII]** on the front panel to enable or disable the output of the **[GI]** or **[GII]** connector, and enter the specified AFG interface. Note: This function is only available when the instrument has installed the MHO5000-AWG option.

16. USB HOST Interface

Supports FAT32 format Flash type USB storage device and the USB-GPIB module.

- **USB storage device:** imports or exports data (software update, waveform, setup, or captured image).
- **USB-GPIB module:** extends the GPIB interface for RIGOL instruments that integrates the USB HOST interface but not the GPIB interface.

17. Power Key

Powers on or off the instrument.

4.5.3 Rear Panel Overview




Figure 4.18 Rear Panel

1. 10 MHz REF OUT

BNC connector that can output the 10 MHz clock signal generated by the internal crystal oscillator inside the instrument.

2. 10 MHz REF IN

BNC connector to input external reference clock signal.

3. Battery Pack Snap-Fit Slot

Used to insert the battery pack snap-fit part to fasten the battery pack.

4. HDMI

You can connect the instrument to an external display that has the HDMI interface (e.g. monitor or projector) via this interface to better observe the waveform display clearly. At this time, you can also view the waveforms on the screen of the instrument.

5. USB DEVICE

Connect the instrument to the PC via this interface. Then you can use the PC software to send the SCPI commands or use the user-defined programming to control the instrument.

6. LAN

Connect the instrument to network via this interface. The instrument conforms to the standards specified in *LXI Device Specification 2011*. Its test system can be built quickly. Then you can control the instrument through using Web Control to send the SCPI commands. When update is available, you can perform online upgrading for the system software of the instrument via the LAN interface.

7. Security Lock Hole

Use a standard PC/laptop lock cable to secure the oscilloscope to a work bench or other location.

8. Mounting Hole

Used for securing the bracket to the back of the instrument.

9. AC Power Cord Connector

The AC power requirements of the instrument are 100-240 V, 50-60 Hz. Please use the power cord provided in the accessories to connect the instrument to the AC power source.

10. Fuse

If you need to replace the fuse, use only the specified fuse.

11. Battery Pack Interface

Used to connect the battery pack.

12. Battery Pack Mounting Slot

Used to insert the brackets of the battery pack to fasten the battery pack.

13. AUX OUT

- Trigger output:

When the AUX output is set to "TrigOut", the oscilloscope generates a trigger and outputs a signal that can reflect the current capture rate of the oscilloscope via this interface. Connect the signal to a waveform display device and measure the frequency of the signal. The measurement result is the same as the current capture rate.

- Pass/Fail:

When the AUX output is set to "PassFail", in the pass/fail test, the instrument will output a pulse via the **[AUX OUT]** connector when a passed or failed waveform is detected during the pass/fail test.

14. EXT TRIG

BNC connector. The external trigger signal is input to the oscilloscope via this connector.

4.5.4 User Interface Overview

This chapter takes the MHO5104 model with digital channels and arbitrary waveform generator (AFG) features, and the eight-channel DHO5108 model as examples to introduce the user interface.




Figure 4.19 DHO5108 User Interface




Figure 4.20 MHO5104 User Interface

1. Waveform View

Displays the measurement waveform window of analog and digital channels. Click or tap  at the upper-right corner of the window to close the window; click or tap  to enter the configuration menu of the specified function.

2. Operating Status Label

Displays the operating status of the instrument.

3. Horizontal Timebase Label

Displays the current horizontal time base. Click or tap this label to enter the horizontal setting menu.

4. Sample Rate & Memory Depth Label

Displays the current sample rate and memory depth. Click or tap this label to enter the horizontal setting menu.

5. Horizontal Position Label

Displays the current horizontal position. Click or tap this label to enter the horizontal setting menu.

6. Trigger Label

- Displays the trigger information of the system, including the trigger type, trigger level, trigger mode, and etc.
- Click or tap the trigger label, then the trigger setting window is displayed. You can set the parameters for the trigger.

7. Quick Operation Toolbar

Provides **STOP/RUN**, **XY**, **Default**, **Flex Knob**, **Navigate** keys and some function keys in the function navigation menu for easy operation.

8. Result List

Displays the measurement results and statistics of various functions. Click or tap  at the lower-right corner of the screen to fold the "Result" list of the specified function.

9. Notification Area

Displays USB icon, LAN icon, sound icon, and remote control icon as well as date and time. You can click or tap this area to open the "Utility" menu.

- USB storage device icon: When a USB storage device is detected,  will be displayed.
- LAN icon: When the LAN interface is successfully connected,  is displayed.

- Sound icon: In the "Utility" menu, click or tap **Setup** > **Beeper** to enable or disable the sound. When on,  will be displayed; when off,  will be displayed. You can simply click or tap the icon to enable or disable the sound.
- Remote control icon: When you use Web Control to control the instrument remotely,  will be displayed.
- Date and time: Displays the system date and time. You can set them in the **Setup** menu.

10. Math Labels

Displays the on/off state, operation type, and vertical scale of Math1-Math4.

11. Digital Channel Labels^[1]

Displays the on/off state of 16 digital channels. When a digital channel is enabled, click or tap this label to enter the logic analyzer (LA) setting menu.

12. Function/Arbitrary Waveform Generator Channels^[2]

Displays the on/off state, waveform type, amplitude, and frequency for Arbitrary Waveform Generator GI/GII. Click or tap the label to enable/disable the AFG output. When the AFG output is enabled, click or tap this label to open the AFG setting menu.

13. Multi-pane Windowing

If you enable multiple functions, multiple windows can be displayed on the screen at one time.

14. Analog Channel Labels

- Displays the on/off status of analog channels (CH1-CH4/CH6/CH8).
- Displays the channel coupling mode.
- Displays the vertical scale of the channel.
- Displays the vertical offset of the channel.

15. Function Navigation Icon

Click or tap the icon to open the function navigation menu in which you can access the specified function menu by clicking or tapping the corresponding function key.

NOTE

[1]: Digital channels are only available for MHO5054, MHO5104, MHO5056, and MHO5106 models.

[2]: Function/Arbitrary Waveform Generator (AFG) is the optional configuration only for MHO5054 and MHO5104 models.



4.6 Touch Screen Gestures

The instrument provides a capacitive touch screen, which is convenient for you to operate and make configurations. It has strong waveform display capability and excellent user experience. It features great convenience, high flexibility, and great sensitivity. The multi-capacitive touch screen supports gesture-enabled operation. The gestures supported by the touch screen controls include tapping, pinching & stretching, dragging, etc.

4.6.1 Tap

Use one finger to tap the symbol or characters on the screen slightly, as shown in *Figure 4.21*. With the Tap gesture, you can perform the following operations:

- Tap the menu displayed on the screen to operate on the menu.
- Tap the function navigation icon at the lower-left corner of the touch screen to enable the function navigation.
- Tap the displayed numeric keypad to set the parameters.
- Tap the virtual keypad to set the label name and the filename.
- Tap the close button at the upper-right corner of the message box to close the prompt window.
- Tap other windows on the touch screen and operate on the windows.



Figure 4.21 Tap Gesture

4.6.2 Pinch&Stretch

Pinch or stretch two points on the screen with two fingers to zoom in or out the waveform. To zoom in the waveform, first pinch the two fingers and then stretch the fingers; to zoom out the waveform, first stretch the two fingers, and then pinch the

fingers together, as shown in the figure below. With the pinch&stretch gesture, you can perform the following operation:

- Pinching&stretching in the horizontal direction can adjust the horizontal time base of the waveform.
- Pinching&stretching in the vertical direction can adjust the vertical scale of the waveform.



Figure 4.22 Pinch&Stretch Gesture

4.6.3 Drag

Use one finger to select the object, and then drag the object to a destination place, as shown in the figure below. With the drag gesture, you can perform the following operation:

- Drag the waveform to change its position or scale.
- Drag the window controls to change the position of the window (e.g. numeric keypad).
- Drag the cursor to move the cursor.
- Drag the trigger cursor to change the trigger level.
- In multi-window display, drag one of the displayed windows to change its position on the display.




Figure 4.23 Drag Gesture

4.6.4 Rectangle Drawing

Open the function navigation menu, and then click or tap the "DrawRect" icon to switch to the rectangle drawing mode. Drag a finger from upper left to lower right across the screen to draw a rectangle on the screen, as shown in [Figure 4.24](#). Move your finger away from the screen, and then a menu is displayed on the screen. At this time, you can tap to select "Trigger zone A", "Trigger zone B", "Histogram", "Horizontal zoom in", "Vertical zoom in", or "Waveform zoom in". Drag a finger from lower right to upper left across the screen to draw a rectangle on the screen, as shown in [Figure 4.25](#). Move your finger away from the screen, and then a menu is displayed on the screen. At this time, you can tap to select "Trigger zone A", "Trigger zone B", "Histogram", "Horizontal zoom out", "Vertical zoom out", or "Waveform zoom out".




Figure 4.24 Rectangle Drawing Gesture (a)




Figure 4.25 Rectangle Drawing Gesture (b)

- Trigger zone A:
 - Draw the region for Trigger zone A;
 - Open Trigger zone A:
 - Open the "Zone Trigger" menu.
- Trigger zone B:
 - Draw the region for Trigger zone B;
 - Open Trigger zone B:
 - Open the "Zone Trigger" menu.
- Histogram:
 - Draw the region for the histogram;
 - Open the "Histogram" menu.
- Horizontal zoom in: expands the waveform in the horizontal direction. Horizontal zoom out: compresses the waveform in the horizontal direction.
- Vertical zoom in: expands the waveform in the vertical direction. Vertical zoom out: compresses the waveform in the vertical direction.
- Waveform zoom in: expands the waveforms both in the horizontal and vertical direction. Waveform zoom out: compresses the waveforms both in the horizontal and vertical direction.
- **TIP**
Click or tap the "DrawRect" icon to switch between the rectangle drawing and waveform operation.



Click or tap the "DrawRect" icon, if  is highlighted, it indicates that the rectangle drawing mode is enabled. You can draw the rectangle to select the desired function. If

 is displayed, it indicates that the waveform operation mode is enabled. By default, waveform operation mode is enabled.

4.7 Parameter Setting Method

The parameters can be set by using the knob or the touch screen. The common parameter setting methods are as follows:

- **Method 1:** Some parameters can be adjusted by rotating the knob on the front panel.
- **Method 2:** Click or tap the input field of a specified parameter, then a virtual keypad is displayed. Complete the parameter setting with the keypad.

Input Chinese and English Characters

When naming a label, this instrument supports Chinese/English input method. The following part introduces how to input Chinese and English characters with the Chinese/English input method.

- **Input English Characters**




Figure 4.26 English Input Interface

1. Select English input method

First check the input method type. If it shows "En/中" currently, then go to Step 2; if it shows "中/En", click or tap the input method switchover key to switch to "En/中" (English input method).

2. Clear the name input area

If there is no character in the "Name Input Area", please go to the next step. If there are characters in the "Name Input Area", click or tap the Backspace key to delete all the characters from the "Name Input Area" in sequence.

3. Input the upper-case letter

If you want to input an upper-case letter, first use the Caps key to switch between the upper-case and lower-case mode. If the Caps key is selected, input the upper-case letter with the virtual keypad. If not, first click or tap the Caps key to ensure it is selected, then input the upper-case letter. All the input letters will be displayed in the "Name Input Area".

4. Input the lower-case letter

Refer to the operation specified in the previous step. If the Caps key is not selected, directly input the lower-case letter.

5. Input numbers or symbols

If the letter keypad is displayed, you need to click or tap the numeric switchover key to switch to the numeric keypad, and input numbers or symbols with the numeric keypad. All the input letters will be displayed in the "Name Input Area".

6. Modify or delete the unwanted characters that have been input

During the name input process, you can modify or delete the unwanted character if necessary. To delete the input characters, click or tap the Backspace key in the virtual keypad to delete the characters. To modify the characters that have been input, delete the unwanted characters first and then input the new characters.

You can directly move the cursor to the character to be modified or deleted, delete the desired character or input the new characters after deleting the unwanted character.

7. Confirm the input

After completing the input operation, click or tap "OK".

- **Input Chinese Characters**



Figure 4.27 Chinese Input Interface

1. Select Chinese input method

First check the input method type. If it shows "中/En" currently, then go to Step 2; if it shows "En/中", click or tap the input method switchover key to switch to "中/En" (Chinese input method).

2. Clear the name input area

If there is no character in the "Name Input Area", please go to the next step. If there are characters in the "Name Input Area", click or tap the Backspace key to delete all the characters from the "Name Input Area" in sequence.

If there are characters in the "Pinyin Input Area", when you delete characters from the name input area, the characters in the Pinyin input area will be deleted first.

3. Input Chinese characters

Click or tap the characters in the virtual keypad to input Pinyin into the input area, then the characters to be selected will be displayed in the Chinese character selection area. Slide to view more Chinese characters for you to choose. Select the desired Chinese character, and then the selected character will be displayed in the input area.

4. Modify or delete the unwanted characters that have been input

During the name input process, you can modify or delete the unwanted character if necessary. To delete the input characters, click or tap the Backspace key in the virtual keypad to delete the characters. To modify the characters that have been input, delete the unwanted characters first and then input the new characters.

5. Confirm the input

After completing the input operation, click or tap "OK".

Input a Value

When setting or modifying a parameter, input an appropriate value with the numeric keypad.

- Click or tap the value or unit in the numeric keypad to complete the input.
- Rotate the specified multifunction knob (1 or 2) to move the cursor to select the value and unit. Press down the specified knob to input the selected value or unit.




Figure 4.28 Numeric Keypad

After you input all the values and select the desired units, the numeric keypad is turned off automatically. This indicates that you have completed parameter setting. Besides, after you have input the values, you can also press OK directly to close the numeric keypad. At this time, the unit of the parameter is the default unit. In the numeric keypad, you can perform the following operation:

- Delete the parameter value that has been input;
- Set the parameter to a maximum or minimum value (sometimes, the maximum or minimum value are the specified one for the current state);
- Set the parameter to a default value;
- Clear the parameter input field.

4.8 To Use the Security Lock

If necessary, you can lock the instrument to a fixed location by using the security lock (please purchase it by yourself), as shown in the figure below.

The method is as follows: align the lock with the lock hole and plug it into the lock hole vertically, turn the key clockwise to lock the oscilloscope, and then pull the key out.




Figure 4.29 Use the Security Lock



CAUTION

Please do not insert other objects into the security lock hole to avoid damaging the instrument.

4.9 To Use the Built-in Help System

The built-in help file provides information about the functions and menu

introductions of the instrument. Click or tap  > **Help** to enter the help system.

In the help system, you can get its help information by clicking on or tapping the link for the specified chapter.

4.10 To View the Option Information and the Option Installation

This series oscilloscope provides multiple options to fulfill your measurement requirements. If you need any of these options, order them according to the Order No. available in "Appendix A: Options and Accessories", and then install the options

according to this section. Besides, you can also view the options currently installed on the oscilloscope or activate the newly purchased option.

View the installed option

The instrument is installed with the trial versions of the options before leaving factory. You can use the option for a trial period of 2,160 minutes which is calculated starting from the first time you power on the instrument. Perform the following operations to view the option name and the option status.

- Click or tap the function navigation icon  at the lower-left corner of the screen, and then select **Utility** to enter the "Utility" menu.
- Click or tap **Options** to view the option list. If you have purchased and installed the option, it shows "Forever" state. If you haven't installed the specified option, it shows "Limit".

Install the option

The option license is a string of fixed characters. Each instrument has one unique license. The license file should be in specific format, with the filename extension ".lic". After you purchase an option, you will obtain a key (used for obtaining the license). Then, you can install the option according to the following steps.

1. Obtain an option license

- a. Log in to the RIGOL official website (<http://www.rigol.com>), click **SERVICE CENTRE > License Activation** to enter the license activation interface.
- b. Input the correct key, serial number (click or tap the function navigation icon  > **Utility** > **About** to acquire the serial number of the instrument), and verification code. Click **Generate** to acquire the option license.

2. Install the option

Run the command :SYSTem:OPTion:INSTall <license> to install the option. For detailed operations, refer to *MHO/DHO5000 Programming Guide*. Installing options by inputting the license code manually is not supported.

5 Vertical System

This oscilloscope provides eight analog input channels CH1-CH8. The vertical control system of each channel is independent of each other. The setting method for the vertical system of each channel is the same. This chapter takes CH1 as an example to introduce the setting method for the vertical system.

When a channel is selected, click or tap the channel status label at the bottom of the screen. Then the channel vertical setting menu is displayed.




Figure 5.1 Vertical Menu


5.1 To Enable or Disable the Analog Channel

Enable the Analog Channel

When a signal is connected to CH1, you can enable the channel in the following ways.


- Click or tap the channel status label at the bottom of the screen to enable the channel.
- Press the front-panel 1 key to enable the channel, and the backlight of this key is illuminated.
- In the Vertical menu, select the CH1 tab. Select **ON** for the **Display** menu to turn CH1 on, and select **OFF** to turn CH1 off.

When CH1 is activated, its status label at the bottom of the screen is as shown in the figure below.



The information displayed in the channel status label is related to the current channel setting (irrelevant with the on/off status of the channel). After the channel is turned on, modify the parameters such as the vertical scale, horizontal time base, trigger mode, and trigger level according to the input signal for easy observation and measurement of the waveform.

When CH1 is enabled but not activated, its status label is as shown in the following figure.




Click or tap the channel status label at the bottom of the screen or press the front-panel 1 key to activate CH1. You can also select the **CH1** tab in Vertical menu to activate it.

Disable the Analog Channel

You can disable the analog channel in the following ways.


- If CH1 has been enabled and activated, you can press the front-panel 1 key to disable it directly. You can also click or tap the channel status label at the bottom of the screen to open the Vertical menu and then click or tap the label again to disable the channel.
- If CH1 has been enabled but not activated, first activate the channel. Then press the front-panel 1 key again to disable CH1. You can also click or tap the channel status label to disable CH1.
- You can also disable CH1 by setting **Display** to OFF in the Vertical menu.
- In addition, you can click or drag to slide down the channel label to disable the channel.

If CH1 is disabled, its status label is as shown in the figure below.



5.2 To Adjust the Vertical Scale

Vertical scale indicates the voltage value per grid in the vertical axis of the screen. It is often expressed in V/div. Adjusting the vertical scale increases or decreases the display amplitude of the waveform. The scale information of the channel status label at the bottom of the screen would change accordingly.



The adjustable range of the vertical scale is related to the current probe ratio and input impedance. By default, when (probe ratio x external attenuation ratio) is 1X and the input impedance is 1 MΩ, the range of the vertical scale is from 100 μV/div to 10 V/div.




CAUTION

When the vertical scale is less than or equal to 500μV, the bandwidth limit will be enabled automatically.

When CH1 is turned on and activated, you can adjust the vertical scale in the following ways.

- Rotate the **Vertical SCALE** knob to adjust the vertical scale (clockwise to reduce the scale and counterclockwise to increase the scale).
- Enable the touch screen function, and then adjust the vertical scale with the pinch & stretch gesture on the touch screen. For details, refer to descriptions in *Pinch&Stretch*.
- In the **Vertical** menu, click or tap the icon at the right side of the input field of **Scale** to increase or decrease the scale value or use the specified multifunction knob on the front panel to set the value. You can also click or tap the input field to input a specific value with the displayed numeric keypad.




Input Field

Increase Decrease

In the **Vertical** menu, click or tap the ON/OFF tab for **Fine** to toggle between **ON** (fine adjustment) and **OFF** (coarse adjustment). The default setting is OFF. You can also


press down the **Vertical SCALE** knob to toggle between "coarse adjustment" and "fine adjustment".



- **Fine adjustment:** Use the icons at the right side of **Scale** or rotate the knob to further adjust the vertical scale within a relatively smaller range to improve vertical resolution. If the amplitude of the input waveform is a little bit greater than the full scale under the current scale and the amplitude would be a little bit lower if the next scale is used, fine adjustment can be used to improve the amplitude of waveform display to view signal details.
- **Coarse adjustment:** Use the icons at the right side of **Scale** or rotate the knob to adjust the vertical scale in 1-2-5 step, i.e. 100 $\mu\text{V}/\text{div}$, 200 $\mu\text{V}/\text{div}$, 500 $\mu\text{V}/\text{div}$, 1 mV/div, 2 mV/div, 5 mV/div, 10 mV/div...10 V/div.

5.3 To Adjust the Vertical Offset

Vertical offset indicates the offset of the signal ground level position of the waveform from the screen center in the vertical direction. Its unit is consistent with the currently selected amplitude unit (refer to *Amplitude Unit*). When adjusting the vertical offset, the waveforms of the corresponding channel moves up and down. The vertical offset information (as shown in the following figure) in the channel status label at the bottom of the screen will change accordingly.



The adjustable range of the vertical offset is related to the current input impedance, probe ratio, and vertical scale.

When CH1 is turned on and activated, you can adjust the vertical offset in the following ways.


- Rotate the **Vertical POSITION** knob at the right section of the front panel to adjust the vertical offset within the adjustable range. Rotate this knob clockwise to increase the vertical offset or rotate it counterclockwise to reduce the vertical offset. Pressing down the knob can quickly reset the vertical offset (set the vertical offset to 0).
- Enable the touch screen function, and then adjust the vertical offset with the drag gesture. For details, refer to *Drag*.
- In **Vertical** menu, click or tap the Up/Down arrow icon at the right side of the input field of **Offset** to increase or decrease the offset value or use the specified multifunction knob to set the value. You can also click or tap the input field of **Offset** to input a specific value with the pop-up numeric keypad.



5.4 Channel Coupling


You can remove unwanted signals by setting the coupling mode. For example, the signal under test is a square waveform with DC offset.

Click or tap the channel status label at the bottom of the screen, and then the **Vertical** menu is displayed. Click or tap the drop-down button of **Coupling** to select the coupling mode.



- When the coupling mode is "DC", both the DC and AC components of the signal under test can pass the channel.
- When the coupling mode is "AC", the DC components of the signal under test are blocked.
- When the coupling mode is "GND", the DC and AC components of the signal under test are blocked.

After a coupling mode is selected, it is indicated in the channel status label at the bottom of the screen, as shown in the figure below.



TIP

When the input impedance is set to "50 Ω ", the channel coupling is set to DC coupling by force, and the **Coupling** menu is grayed out and cannot be modified.

5.5 Bandwidth Limit

This oscilloscope supports the bandwidth limit function. Setting the bandwidth limit can reduce the noises in the displayed waveforms. For example, the signal under test is a pulse with high frequency oscillation.

- When the bandwidth limit is turned off, the high frequency components of the signal under test can pass the channel.
- When the bandwidth limit is turned on, the high frequency components found in the signal under test that are greater than the limit are attenuated.

Click or tap the channel status label at the bottom of the screen, and then the **Vertical** menu is displayed. Click or tap the drop-down button of **BW Limit** to select the specified bandwidth. When the bandwidth limit is enabled, the specific bandwidth limit value will be displayed in the channel status label at the bottom of the screen, as shown in the figure below.



The supported bandwidth limits include 250 MHz and 20 MHz.

- When the vertical scale is greater than 500 $\mu\text{V}/\text{div}$, you can turn off the bandwidth limit function.
- When the vertical scale is less than or equal to 500 μV , the 250 MHz bandwidth limit is automatically enabled and the bandwidth limit cannot be turned off;
- When the vertical scale is less than or equal to 200 μV , the 20 MHz bandwidth limit is automatically enabled and the bandwidth limit cannot be turned off.

5.6 Input Impedance

To reduce the circuit load between the oscilloscope and the circuit under test, this oscilloscope provides two input impedance modes: 1 M Ω (default) and 50 Ω . In the **Vertical** menu, click or tap to select "1 M Ω " or "50 Ω " for **Impedance**.

- 1 M Ω : In this mode, the input impedance of the oscilloscope is very high, and the current flowed from the circuit under test can be ignored.
- 50 Ω : makes the oscilloscope match the device whose output impedance is 50 Ω .

After the oscilloscope switches to the 50 Ω mode, the circuit diagram in the **Vertical** menu will also be changed, as shown in the figure below.





Figure 5.2 Input Impedance Switchover

**TIP**


- After the oscilloscope recognizes the probe automatically, the input impedance will also be auto recognized. You do not need to set it manually.
- Setting the input impedance affects the ranges of vertical scale and offset for the specified channel.

5.7 Waveform Invert

Click or tap the channel status label at the bottom of the screen. Then the **Vertical** system menu is displayed. Then click or tap the ON/OFF tab for **Invert** to enable or disable the waveform invert function.



When "ON" is selected, the channel label is as shown in the figure below.



When "OFF" is selected, the waveform is displayed normally; when the waveform invert is enabled, the voltage values of the displayed waveform are inverted, as shown in the following figure below. Enabling the waveform invert will change the result of math function and waveform measurement.




Figure 5.3 Waveform Invert

**TIP**

When the waveform invert is enabled, the trigger edge or the trigger polarity will change (e.g. Edge trigger, Pulse trigger, or Slope trigger).

5.8**Probe**

The analog channel of this oscilloscope not only supports the common passive probe, but also the active probe. It can automatically recognize the currently connected probe type and its probe ratio. For detailed technical information of the probes, please refer to the corresponding Probe User Guide.

Enable the touch screen operation and tap the channel status label at the bottom of the screen. Then the **Vertical** system interface is displayed. Then tap **Probe** to enter the **Probe** setting menu.




Figure 5.4 Probe Setting Menu

If the instrument works with RP7000/PVA7000 series probes (e.g. PVA7250), the probe ratio cannot be modified and you need to calibrate the probe. For specific probe models, please refer to *MHO/DHO5000 Data Sheet*. For detailed technical information of the probes, please refer to the corresponding Probe User Guide.




Figure 5.5 Active Probe Setting Menu

Probe Ratio

The probe ratio is defined as the percentage of the voltage of the signal under test to the probe voltage output to the oscilloscope. The higher the probe ratio, the higher the probe sensitivity, indicating that more low-level signals can be detected.

- The series oscilloscope auto-recognizes certain probes with a fixed attenuation ratio. After being recognized, the probe ratio can be auto recognized. You do not have to set it manually.
- If the oscilloscope is unable to auto-recognize the probe, you are allowed to set the probe ratio manually. To obtain the correct measurement results, you must set the probe ratio properly. By default, the probe ratio is 1X.

When a voltage probe is connected to the oscilloscope, refer to *Amplitude Unit* to set the amplitude unit to V. The following table lists the probe ratio of the voltage probe. You can also set a user-defined probe ratio according to your needs.

Table 5.1 Probe Ratio of the Voltage Probe

Menu	Attenuation (display amplitude of the signal: actual amplitude of the signal under test)
0.001X	0.001:1
0.002X	0.002:1
0.003X	0.003:1
0.005X	0.005:1
0.01X	0.01:1
0.02X	0.02:1
0.03X	0.03:1
0.05X	0.05:1
0.1X	0.1:1
0.2X	0.2:1
0.3X	0.3:1
0.5X	0.5:1
1X (default)	1:1
2X	2:1
3X	3:1
5X	5:1
10X	10:1
15X	15:1
20X	20:1
50X	50:1
100X	100:1
150X	150:1
200X	200:1
500X	500:1
1000X	1000:1
1500X	1500:1
2000X	2000:1
5000X	5000:1

Menu	Attenuation (display amplitude of the signal: actual amplitude of the signal under test)
10000X	10000:1
15000X	15000:1
20000X	20000:1
50000X	50000:1

When a current probe is connected to the oscilloscope, refer to *Amplitude Unit* to set the amplitude unit to A. The following table lists the probe ratio of the current probe. You can also set a user-defined probe ratio according to your needs.

Table 5.2 Probe Ratio of the Current Probe

Menu	Attenuation (display amplitude of the signal: actual amplitude of the signal under test)
0.001 V/A	0.001
0.002 V/A	0.002
0.003 V/A	0.003
0.005 V/A	0.005
0.01 V/A	0.01
0.02 V/A	0.02
0.03 V/A	0.03
0.05 V/A	0.05
0.1 V/A	0.1
0.2 V/A	0.2
0.3 V/A	0.3
0.5 V/A	0.5
1 V/A	1
2 V/A	2
3 V/A	3
5 V/A	5
10 V/A	10

External Attenuation

This oscilloscope allows you to set the external attenuation, supporting setting it in log format.

display amplitude of the signal under test = actual amplitude of the signal under test
x probe ratio x attenuation ratio (not affect the actual amplitude of the signal)

Table 5.3 Range of the External Attenuation

Probe Ratio	Max. Value	Min. Value
≤ 1	100kX	(10 μ /Probe Ratio)X
> 1	(100k/Probe Ratio)X	10 μ X

Skew

To avoid measurement result errors arising from the transmission delay of the probe cable, the oscilloscope provides the probe delay adjustment. Click or tap the input field of **Skew** to set the delay time of the probe with the pop-up numeric keypad. You can also use the specified knob to set it. Its range is from -100.00 ns to 100.00 ns. The default value is 0.00 s.

Bias

The oscilloscope provides the bias voltage adjustment function for active probes. This function is used to adjust the signal under test that exceeds the input dynamic range of the probe amplifier to an appropriate range to ensure the integrity of the signal under test. When working with the RP7000/PVA7000 series probe, you need to click or tap the input field of **Bias** to set the bias voltage of the probe with the pop-up numeric keypad.

Probe Information


After the oscilloscope recognizes the probe automatically, In the probe menu, you can view information about the currently connected probe, such as the vendor, model, serial number, and the last calibration time.

Go Back to the Vertical System Menu

In the **Probe** setting menu, click or tap the **Vertical** menu to go back to the **Vertical** system menu.

5.9 Amplitude Unit

Click or tap the channel status label at the bottom of the screen. Then the **Vertical** system menu is displayed. Click or tap the drop-down button of **Unit** to select W, A, V, or U. The default unit is V.




When the amplitude unit is changed, the unit related to the channel will also be changed accordingly.

5.10 Bias

When you use an oscilloscope to make actual measurements, a small offset that arises from the temperature drift of the component or external environment disturbance may occur on the zero-cross voltage of the channel, which will affect the measurement results of the vertical parameters. This series oscilloscope allows you to set an offset calibration voltage for calibrating the zero point of the corresponding channel, so as to improve the accuracy of the measurement results.

Click or tap the Up and Down arrow icon at the right side of the input field of **Bias** to increase or decrease the bias value. You can also click or tap the input field to input a specific value with the pop-up numeric keypad. Also, you can use the specified knob indicated in the input field to set the value.

Value Input Field Decrease Increase



The range of bias voltage is related to the input impedance and the vertical scale.



TIP

If the zero-cross voltage of the channel has a larger amplitude offset that exceeds the adjustable null range, please perform self-calibration for the instrument to ensure the measurement accuracy. For details, refer to descriptions in *SelfCal*.

5.11 Channel Delay

When using an oscilloscope for actual measurement, the transmission delay of the probe cable may bring relatively greater errors (zero offset). This series oscilloscope allows you to set a delay time for calibrating the zero offset of the corresponding channel. Zero offset is defined as the offset of the crossing point of the waveform and trigger level line relative to trigger position, as shown in the figure below.




Figure 5.6 Zero Offset

In the "Vertical" menu, click or tap the input field for the **Ch-Ch Skew** item to set the channel-to-channel skew time. The available range is from -100 ns to 100 ns.

5.12 Channel Label

The instrument uses the channel number to mark the corresponding channel by default. For ease of use, you can also set a label for each channel. For example, **CH1**. Click or tap the channel status label at the bottom of the screen. Then the **Vertical** system menu is displayed. Click or tap the ON/OFF tab for **Label** to select whether to display the channel label. You can also click or tap the channel label input field to input a specific name for the channel label with the pop-up numeric keypad.



6 Horizontal System

To enter the **Horizontal** system menu, perform any of the following operations:

- Press the front-panel horizontal controls  key to enter the **Horizontal** menu.
- Click or tap the channel status label at the bottom of the screen, and then the **Vertical** menu is displayed. Click or tap the **Acquisition** button to enter the **Horizontal** menu.
- Click or tap the horizontal time base label ("H" icon), acquisition label ("A" icon), or horizontal position label ("D" icon) at the top of the screen to enter the **Horizontal** menu.





Figure 6.1 Horizontal System Menu

6.1 To Adjust the Horizontal Time Base

Horizontal time base, also called the horizontal scale, refers to the time of each grid in the horizontal direction of the screen. It is usually expressed in s/div. The range of the horizontal time base is from 200 ps/div to 500 s/div.


While you change the horizontal time base, the displayed waveforms of all channels are expanded or compressed horizontally relative to the selected time reference

(*Horizontal Expansion*). The horizontal time base in the horizontal time base label ("H" icon) will change accordingly, as shown in the figure below.



You can adjust the horizontal time base in the following ways.

- Rotate the front-panel **Horizontal**  **SCALE** knob to adjust the horizontal time base (clockwise to reduce the scale and counterclockwise to increase).
- Enable the touch screen function, and then adjust the horizontal time base with the Pinch&Stretch gesture. For details, refer to *Pinch&Stretch*.
- In the **Horizontal** menu, click or tap the icon at the right side of the input field of **Scale** to increase or decrease the horizontal time base or use the corresponding multifunction knob to set the value. You can also click or tap the input field to input a specific value with the displayed numeric keypad.



In the **Horizontal** menu, click or tap the ON/OFF tab for **Vernier** to toggle between ON (fine adjustment) and OFF (coarse adjustment). You can also press the front-panel

Horizontal  **SCALE** knob to switch between "coarse adjustment" and "fine adjustment".

- **Coarse adjustment:** Click or tap the icons at the right side of the input field of **Scale** to adjust the horizontal time base of the waveforms of all channels in a 1-2-5 step sequence within the adjustable range.
- **Fine adjustment:** Click or tap the icon at the right side of the input field of **Scale** to adjust the horizontal time base of the waveforms of all channels at a smaller step within the adjustable range.

6.2 To Adjust the Horizontal Position


Horizontal position, also called trigger position, refers to the trigger point position of the waveforms of all channels in the horizontal direction relative to the screen center. When the waveform trigger point is at the left (right) side of the screen center, the horizontal position is a positive (negative) value.

While you change the horizontal position, the waveform trigger points and the displayed waveforms of all channels are moved left and right. The horizontal position at the top of the screen changes accordingly, as shown in the figure below.




You can adjust the horizontal position with the following methods.

- Rotate the front-panel **Horizontal POSITION** multifunction knob to adjust the horizontal position within the adjustable range. Rotate it clockwise to reduce the horizontal position, and counterclockwise to increase the horizontal position. Pressing down the knob can quickly reset the Horizontal position (set the horizontal position to 0).
- Enable the touch screen, and then adjust the horizontal position with the Drag gesture. For details, refer to *Drag*.
- Open the Horizontal system menu, rotate the specified front-panel multifunction knob indicated in the input field of **Position** or click/tap the icon at the right side of the input field to increase or decrease the value, as shown in the figure below. You can also click or tap the input field of **Position** to input a specific value with the displayed numeric keypad.



6.3 Zoom Mode (Delayed Sweep)

Zoom mode (delayed sweep) can be used to horizontally expand a length of waveform to view waveform details. In the **Horizontal** menu, click or tap the ON/OFF tab for **Zoom** to enable or disable the delayed sweep function. When it is enabled, you can set the scale and position in Zoom mode.



- **Zoomed Scale:** Rotate the corresponding multifunction knob or use the icons at the right of the **Scale** input field to increase or decrease the time base for the Zoom window. You can also click or tap the input field to input the specific value directly with the pop-up numeric keypad.
- **Zoomed Position:** Rotate the corresponding multifunction knob or use the icons at the right of the **Position** input field to increase or decrease the position for

the Zoom window. You can also click or tap the input field to input the specific value directly with the pop-up numeric keypad.

When the Zoom mode is enabled, the screen is divided into two display areas as shown in the figure below.



Figure 6.2 Zoom Mode

- **Waveform before expansion:**

The upper portion of the display that is not covered by subtransparent gray shows the normal display of the waveform. Its horizontal time base (called the main time base) is indicated in the label at the upper-left corner of the display. You can move the area left and right by adjusting the horizontal position and increase or decrease the size of the area by adjusting the horizontal scale.

- **Waveform after expansion:**

The lower portion shows the horizontally expanded version of the normal waveform display. Its horizontal time base (called the zoomed time base) is displayed in the middle. Compared with the main time base, the zoomed time base has higher horizontal resolution.

TIP

The zoomed time base should be smaller than or equal to the main time base.



7 Acquisition System

The "Horizontal" menu allows you to configure the instrument's acquisition system.




Figure 7.1 Horizontal Menu

7.1 Acquisition Mode

The acquisition mode is used to control how to generate waveform points from the sample points.

In the **Horizontal** menu, click or tap the desired acquisition mode for the **Acquisition** item. The available choices include Normal, Average, Peak, and High Res.

By default, the acquisition mode is Normal. The acquisition mode will be displayed in the acquisition label at the top of the screen.



Normal

In Normal acquisition mode, the oscilloscope samples the signal at a fixed time interval to rebuild the waveform. For most of the waveforms, this mode is adopted to achieve optimal display effects..

Average

In this mode, the oscilloscope averages the waveforms from multiple acquisitions to reduce the random noise of the input signal and increase the vertical resolution. A greater number of averages lowers the noise and increases the vertical resolution. On

the other hand, the higher the number of averages, the slower the response of the displayed waveform to waveform changes.

When you select "Average" mode, click or tap the **Averages** input field to set the number of averages with the pop-up numeric keypad or use the corresponding multifunction knob to set the value. Its range is from 2 to 65536, and the default is 2.



TIP

The number of averages must be the Nth power of 2. When it is not in N power-of-2 increments, a prompt message "Truncation average error" is displayed. At this time, a value that is smaller than the one you input and the closest to N power-of-2 increments will be input automatically.

Peak

In this mode, the oscilloscope acquires the maximum and minimum values of the signal within the acquisition interval to get the signal envelope or capture narrow pulses that might be lost.

In this mode, signal aliasing can be prevented, but the noise displayed would be larger.

In this mode, the min. detected pulse width is the sample period.

High Resolution

This mode uses a kind of ultra-sample technique to average the neighboring points of the sample waveform to reduce the random noise on the input signal and generate much smoother waveforms on the screen. This is generally used when the sample rate of the digital converter is higher than the storage rate of the acquisition memory.

When you select "High Res" mode, click or tap the drop-down button of **Bits** to select 14 (default) or 16. The bandwidth that corresponds to the selected bit is displayed at the right side of the input field of **Bits**.



TIP

- The averaging modes of the "Average" and "High Res" are different. The former uses "Multi-sample Average" and the latter uses "Single Sample Average".
- In "High Res" mode, the oscilloscope improves the measurement accuracy at the cost of bandwidth. Each time the sample rate changes, the current bandwidth is indicated at the right side of **Bits** in the horizontal system menu.

7.2 Sampling Mode

This oscilloscope only supports the real-time sampling mode. In this mode, the oscilloscope produces the waveform display from samples collected during one trigger event. The maximum real-time sample rate of this series is 4 GSa/s. The current sample rate is displayed in the acquisition label at the top of the screen.

By default, the operating status label at the left top of the screen is illuminated in green, indicating that the instrument is in real-time sampling, and the **STOP/RUN** button on the toolbar is in green. Click or tap the **STOP/RUN** button or press the


front-panel  key to stop sampling. At this time, the operating status label shows "STOP" in red, and the **STOP/RUN** button turns red. Also, the backlight of the front-

panel  key turns red. The oscilloscope will maintain its last captured graph. You can still pan or zoom the waveforms by using the horizontal/vertical controls.

7.3 Sample Rate

Sampling is the process of converting an analog signal into digital data at a specified time interval and then storing them in sequence. The sample rate is the reciprocal of the time interval.


In **Horizontal** menu, the "SaRate" item shows the current sample rate. The current sample rate is also indicated in the acquisition label ("A" icon) at the top of the screen, as shown in the figure below.




The maximum real-time sample rate of this series is 4 GSa/s, with DHO5058 and DHO5108 models supporting a maximum real-time sample rate of 2 GSa/s when all channels are enabled.

A sample rate that is too low might have the following effects on the waveform:

- **Waveform Distortion:** when the sample rate is too low, some waveform details are lost, and the sample waveform displayed is rather different from the actual waveform of the signal.



- **Waveform Aliasing:** when the sample rate is twice lower than the actual signal frequency (Nyquist Frequency), the frequency of the waveform rebuilt from the sample data is smaller than the actual signal frequency.



- **Waveform Leakage:** when the sample rate is too low, the waveform rebuilt from the sample data does not reflect all the actual signal information.



7.4 Memory Depth

Memory depth refers to the number of points that the oscilloscope can store in a single trigger acquisition. It reflects the storage capability of the acquisition memory. The MHO/DHO5000 series oscilloscope is equipped with a standard memory depth of up to 500 Mpts per channel.




Figure 7.2 Memory Depth


$$MDepth \geq SRate \times TScale \times HDivs$$

The following formula shows the relations among memory depth, sample rate, and horizontal time base:

- **MDepth** indicates the memory depth. The unit is pts.
- **SRate** indicates the sample rate. The unit is Sa/s.
- **TScale** indicates the horizontal time base scale. The unit is s/div.
- **HDivs** indicates the number of grids in the horizontal direction. The unit is div.

Therefore, with the same horizontal time base, a higher memory depth can ensure a higher sample rate.

In the **Horizontal** system menu, click or tap the drop-down button of **Mem Depth** to select the memory depth. By default, the memory depth is "10 kpts". The memory depth value will be displayed in the sample rate label at the top of the screen.



Memory Depth

- CH1, CH3, CH5, and CH7 are considered as one group; CH2, CH4, CH6, and CH8 are considered as another group.
- When one or multiple channels in either one of the group are enabled, the memory depths available include Auto, 1 kpts, 10 kpts, 100 kpts, 1 Mpts, 10 Mpts, 25 Mpts, 50 Mpts, 100 Mpts, 125 Mpts, 200 Mpts, 250 Mpts, and 500 Mpts.
- When one or multiple channels in both two groups are enabled, the memory depths available include Auto, 1 kpts, 10 kpts, 100 kpts, 1 Mpts, 10 Mpts, 25 Mpts, 50 Mpts, 100 Mpts, 125 Mpts, and 250 Mpts.



TIP

- In "Auto" mode, the oscilloscope selects the memory depth automatically according to the current sample rate.
- When **Acquisition Mode** is set to "High Res", "Auto" is not available for the memory depth setting.
- When **Acquisition Mode** is set to "Average", only 1 kpts, 10 kpts, 100 kpts, 1 Mpts, and 10 Mpts are available for the memory depth setting.

7.5 Horizontal Expansion

Horizontal expansion indicates the reference position that the screen waveform is referenced to when it is horizontally expanded or compressed in adjusting the horizontal time base.

In the **Horizontal** system menu, click or tap the drop-down button of **Expand** to select the horizontal reference baseline. The available choices include Center, Left, Right, Trigger, and User. The default is "Center".

- **Center:** when the horizontal time base is modified, the waveform will be expanded or compressed horizontally relative to the screen center.
- **Left:** when the horizontal time base is modified, the waveform will be expanded or compressed horizontally relative to the leftmost position of the screen.
- **Right:** when the horizontal time base is modified, the waveform will be expanded or compressed horizontally relative to the rightmost position of the screen.
- **Trigger:** when the horizontal time base is modified, the waveform will be expanded or compressed horizontally relative to the trigger point.
- **User:** when the horizontal time base is modified, the waveform displayed will be expanded or compressed horizontally relative to the user-defined reference position.

When you select "User", click or tap the input field of **User Expansion**. Input the horizontal expansion reference value with the displayed numeric keypad. Its range is from -500 to 500. Its default value is 0.

7.6 Roll Mode

The roll mode causes the waveform to move across the screen from right to left. It allows you to view the acquired data without waiting for a complete acquisition. In the **Horizontal** system menu, click or tap to select "Auto" or "OFF" for the **Roll** menu.

- **Auto:** the Roll mode is enabled. It is automatically enabled when the horizontal scale is 50 ms/div or slower.
- **OFF:** the Roll mode is disabled. The oscilloscope operates at slow sweep speeds when the horizontal scale is 200 ms/div or slower. In slow sweep mode, the oscilloscope acquires the data to the left of the trigger point and then waits for trigger. After the trigger occurs, it continues to acquire the data to the right of the trigger point. When you use this mode to observe low-frequency signals, it is recommended to set the channel coupling mode (*Channel Coupling*) to "DC".



TIP

- If the Zoom mode is currently turned on, enabling the roll mode automatically turns off the Zoom mode.
- The following functions are not available when the roll mode is enabled:

To Adjust the Horizontal Position (available when the operating status of the oscilloscope is STOP), *Zoom Mode (Delayed Sweep)*, *To Trigger the Oscilloscope*, *Zoom Mode (Delayed Sweep)*, *Pass/Fail Test*, *Waveform Recording and Playing*, *Persistence Time*, *Average*, *XY Mode*.

7.7 XY Mode

By default, this series oscilloscope uses the YT mode for waveform display window. In YT mode, Y-axis indicates the Voltage and X-axis indicates the Time. Besides, it supports XY display window. In this display window, X-axis and Y-axis indicate voltage. The two input channels display from "Voltage-Time" to "Voltage-Voltage".

Enable the XY Mode

You can enable the XY display mode in the following ways.

- Click or tap the **Windows** button in the function navigation menu or on the toolbar to enter the **Add Window** menu. In the "Diagram" item, click or tap **XY** > **Add** to enable the XY display mode.
- Click or tap the **XY** button in the function navigation menu or on the toolbar to enable the XY display mode.
- In the "Horizontal" menu, check the checkbox of **XY** to enable the XY mode.

Configure the XY Mode

Click or tap  at the upper-right corner of the XY display window to enter the XY configuration menu.




Figure 7.3 XY Menu

- Source:** Click or tap the drop-down button of **Source X** to select the source channel of the X-axis in the XY window. Click or tap the drop-down button of **Source Y** to select the source channel of the Y-axis in the XY window.
- Grid:** Please refer to *To Set the Screen Grid* to set the grid of the XY window.

Phase Deviation Measurement

In this mode, you can use the Lissajous method to measure the phase deviation of the two input signals whose frequencies are the same. The following figure shows the measurement schematic diagram of phase deviation.




Figure 7.4 Measurement Schematic Diagram of Phase Deviation

According to $\sin\theta = A/B$ or C/D , θ is the phase deviation angle between the two channels. The definitions of A, B, C, and D are shown in the figure above. The phase deviation angle is obtained, that is:

$$\theta = \pm \arcsin(A/B) \text{ or } \pm \arcsin(C/D)$$

If the principal axis of the ellipse is within Quadrant I and III, the phase deviation angle obtained should be within Quadrant I and IV, namely within $(0 \text{ to } \pi/2)$ or $(3\pi/2 \text{ to } 2\pi)$. If the principal axis of the ellipse is within Quadrant II and IV, the phase deviation angle obtained should be within Quadrant II and III, namely within $(\pi/2 \text{ to } \pi)$ or $(\pi \text{ to } 3\pi/2)$.

The XY mode can be used to measure the phase deviation occurred when the signal under test passes through a circuit network. Connect the oscilloscope to the circuit to monitor the input and output signals of the circuit.

8 To Trigger the Oscilloscope

The trigger system allows you to set specific trigger conditions as required. The oscilloscope captures a waveform and its neighboring part to display them on the screen once a particular trigger condition is met. For a digital oscilloscope, it samples waveforms ceaselessly no matter whether it is stably triggered. However, only stable triggering can guarantee the stable display of waveforms. The trigger module ensures that every time base sweep or acquisition starts from the user-defined trigger condition, namely every sweep is synchronous with the acquisition and the waveforms acquired are overlapped so as to display the stable waveforms.

You should set the triggers based on the features of the input signal. To quickly capture your desired waveforms, you need to understand the signal under test. This oscilloscope provides a variety of trigger types that help you focus on the desired waveform details.

You can enter the **Trigger** menu in the following ways.

- Press the front-panel  key to enter the trigger menu.
- In the Vertical menu, click or tap the **Trigger** button to enter the trigger setting menu.
- Click or tap the trigger label (as shown in the figure below) at the top of the screen to enter the trigger menu.




Figure 8.1 Trigger System Menu

8.1 Trigger Source

In the "Trigger" menu, click or tap the drop-down button of **Source** to select the desired source. The available sources include: analog channels, digital channels, EXT (external trigger), and AC Line.

Analog Channel

All of the analog channels can be selected as the trigger source no matter whether the channel selected is enabled or not.

- DHO5058/DHO5108: CH1-CH8
- MHO5056/MHO5106: CH1-CH6
- MHO5054/MHO5104: CH1-CH4

Digital Channel (Only for MHO Series)

All of the digital channels (D0-D15) can be selected as the trigger source no matter whether the channel selected is enabled or not.

AC Line

AC power of the oscilloscope can be used as trigger source. AC trigger is usually used to measure signals relevant to the AC power frequency. For example, stably triggering the waveform output from the transformer of a transformer substation. It is mainly used in the power industry-related measurements.

EXT (External Trigger)

The external trigger source can be used to trigger on the ninth channel while all of the 8 channels are acquiring data. The trigger signal (e.g. external clock or signal of the circuit under test) will be input to the **EXT** trigger source via the **[EXT TRIG]** external trigger input connector. You can set the trigger conditions within the range of the trigger level -8 V to +8 V.

8.2 Trigger Level

Trigger level determines the position of the trigger point on the edge. The adjustment of the trigger level is related to the type of the trigger source.

- When the trigger source is analog channel or digital channel, rotate the front-panel  **LEVEL** knob or use the corresponding multifunction knob (when the trigger menu is opened) to adjust the trigger level. You can also click or tap the input field of **Level** to set the value with the pop-up numeric keypad.

When the trigger source is D0-D15, you can set the threshold level for digital channels in the basic settings tab of the logic analyzer interface shown in *Basic*

Settings. For details, refer to *To Set the Threshold*. The current threshold level is displayed in the trigger information label at the top of the screen.

During the adjustment, a trigger level line (the color of the trigger level line is the same as that of the channel) and a trigger icon " " are displayed on the screen, and they move up and down with the variation of the trigger level. When you stop modifying the trigger level, the trigger level line disappears in about 2s. The current trigger level is displayed in the trigger information label at the top of the screen.

In Runt Trigger, Slope Trigger, and Window trigger, you need to set the upper and lower limits of the trigger level. Two trigger level icons  and  are displayed at the right section of the screen.

- When the trigger source is AC Line, there is no trigger level.
- When the trigger source is EXT, rotate the front-panel  **LEVEL** knob or use the corresponding multifunction knob (when the trigger menu is opened) to adjust the trigger level. You can also click or tap the input field of **Level** to set the value with the pop-up numeric keypad. The current trigger level is displayed in the trigger information label at the top of the screen.

For this trigger source, only the variation of the trigger level value is displayed on the screen during the adjustment of the trigger level, without displaying the trigger level lines on the screen.

To better trigger the waveforms, for a trigger with a single level, you can directly click or tap **50%** in the menu or press down the trigger level knob to make the level move to the middle of the waveform. However, for a trigger with two levels (e.g. Slope trigger, Runt trigger, Window trigger and MIL-STD-1553 trigger), you need to click or tap **90%** for Level A and **10%** for Level B to make the level move within the range of the waveform amplitude.

8.3 Trigger Mode

The following is the schematic diagram of the acquisition memory. To easily understand the trigger event, we classify the acquisition memory into the pre-trigger buffer and post-trigger buffer.




Figure 8.2 Schematic Diagram of the Acquisition Memory

After the oscilloscope starts running, it first fills the pre-trigger buffer. Then, after the pre-trigger buffer is filled, the oscilloscope starts searching for a trigger. While searching for the trigger, the data sampled will still be transmitted to the pre-trigger buffer (the new data will continuously overwrite the previous data). When a trigger is found, the pre-trigger buffer contains the events that occurred just before the trigger. Then, the oscilloscope will fill the post-trigger buffer and display the data in the acquisition memory.

If the acquisition is initiated via the front-panel  key, the oscilloscope will repeat this process. If the acquisition is initiated via , the oscilloscope will stop after finishing a single acquisition (you can pan and zoom the currently displayed waveform).

This series oscilloscope provides Auto, Normal, and Single trigger modes. The default trigger mode is Auto.

Click or tap the trigger information label in the main interface (as shown in the figure below) to enter the trigger setting interface. You can also press the front -panel

 key to enter the trigger setting interface. Then select the desired trigger mode under **Mode**. The trigger mode is displayed in the trigger information label at the top of the screen: A (Auto), N (Normal), and S (Single).



- **Auto:** In this trigger mode, if the specified trigger conditions are not found, triggers are forced and acquisitions are made so as to display the waveforms. This trigger mode should be used when the signal level is unknown or the DC should be displayed as well as when forcible trigger is not necessary as the trigger condition always occurs.
- **Normal:** In this trigger mode, triggers and acquisitions only occur when the specified trigger conditions are found. This trigger mode should be used when the signal is with low repetition rate or only the event specified by the trigger

setting needs to be sampled as well as when auto trigger should be prevented to acquire stable display.

- **Single:** In this trigger mode, the oscilloscope performs a single trigger and acquisition when the specified trigger conditions are found, and then stops. This trigger mode should be used when you need to perform a single acquisition of the specified event and analyze the acquisition result (you can pan and zoom the currently displayed waveform, and the subsequent waveform data will not overwrite the current waveform). After a single trigger mode is initiated, the operating status of the oscilloscope is in "STOP" state.

When the trigger mode is **Normal** or **Single**, click or tap Force in the trigger setting interface to generate a trigger signal forcibly. You can also press the front-panel



to generate a trigger signal forcibly.

8.4 Trigger Coupling

Trigger coupling decides which kind of components will be transmitted to the trigger module. Please distinguish it from channel coupling (*Channel Coupling*). This function is available only when the trigger type is Edge and the trigger source is an analog channel.

In the "Trigger" menu, click or tap the drop-down button of **Coupling** to select the desired coupling mode (by default, it is DC).



- **DC:** allows DC and AC components to pass the trigger circuitry.
- **AC:** blocks the DC components and attenuates the signals.
- **LFR:** blocks the DC components and rejects the low-frequency components.
- **HFR:** rejects the high frequency components.

TIP

When "AC" or "LFR" is selected as the coupling mode, no trigger level lines and trigger icons are displayed. When you adjust the trigger level, you can only see the changes of the trigger level values in the trigger information label at the top of the screen.



8.5 Trigger Holdoff

Trigger holdoff can be used to stably trigger on complex repetitive waveforms that have multiple edges or other events between waveform repetitions (such as pulse series). Holdoff time indicates the time that the oscilloscope waits for re-arming the

trigger module after generating a correct trigger. The oscilloscope will not trigger even if the trigger condition is met during the holdoff time and will only re-arm the trigger module after the holdoff time expires.

For example, to stably trigger the repetitive pulse series as shown in the figure below, the holdoff time should be set to a value that is greater than t_1 and smaller than t_2 .




Figure 8.3 Trigger Holdoff

In the trigger interface, click or tap the input field of **Holdoff** to set the holdoff time with the pop-up numeric keypad to make it to trigger stably. By default, it is 8 ns. You can also rotate the specified multifunction knob indicated in the input field to set the value. The adjustable range of the holdoff time is from 8 ns to 10 s.

8.6 Noise Rejection

Noise rejection can reject the high frequency noise in the signal and reduce the possibility of miss-trigger of the oscilloscope.

Click or tap the ON/OFF tab for **Noise Reject** to enable or disable the noise rejection.



TIP

This function is only valid when the trigger source is an analog channel, digital channel, or EXT.

8.7 Trigger Type

This series oscilloscope provides the following trigger types.

8.7.1 Edge Trigger

Identifies a trigger on the trigger level of the specified edge on the input signal.

Set the Trigger Type

Click or tap the drop-down button of **Type** to select "Edge".

For the Edge trigger menu, refer to *Figure 8.1*.

After a trigger type is selected, the current trigger setting information (including the trigger type, source, and level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Select the Source

Click or tap the drop-down button of **Source** to select analog channel, digital channel, AC Line, or EXT. For the available channels, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Edge Type

In the **Slope** item, select which edge of the input signal will trigger the oscilloscope. The selected slope will be indicated in the trigger information label.

- Rising: triggers on the rising edge of the input signal when the voltage level meets the specified trigger level.
- Falling: triggers on the falling edge of the input signal when the voltage level meets the specified trigger level.
- Either: triggers on the rising or falling edge of the input signal when the voltage level meets the preset trigger level.

TIP

When edge trigger is selected, you can also press the front-panel  key to switch the edge type.



8.7.2 Pulse Trigger

Triggers on the positive or negative pulse with a specified width. In this mode, the oscilloscope will trigger when the pulse width of the input signal satisfies the specified pulse width condition.

In this oscilloscope, positive pulse width is defined as the time difference between the two crossing points of the trigger level and positive pulse; negative pulse width is

defined as the time difference between the two crossing points of the trigger level and negative pulse, as shown in the figure below.




Figure 8.4 Positive/Negative Pulse Width

Trigger Type

Click or tap the drop-down button of **Type** to select "Pulse".




Figure 8.5 Pulse Trigger Setting Menu

After a trigger type is selected, the current trigger setting information (including the trigger type, source, and level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Select the Source

Click or tap the drop-down button of **Source** to select the analog channel or the digital channel as the trigger source. For available channels, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Polarity

In the **Polarity** item, select the desired polarity: positive polarity () or negative polarity ()

Trigger Condition

Set the trigger condition in the **When** item.

- When you select "Positive" for polarity, ">" for trigger condition, the oscilloscope triggers when the positive pulse width of the input signal is greater than the specified pulse width.
- When you select "Positive" for polarity, "<" for trigger condition, the oscilloscope triggers when the positive pulse width of the input signal is smaller than the specified pulse width.
- When you select "Positive" for polarity, "< >" for trigger condition, the oscilloscope triggers when the positive pulse width of the input signal is greater than the specified lower limit of pulse width and smaller than the specified upper limit of pulse width.
- When you select "Negative" for polarity, ">" for trigger condition, the oscilloscope triggers when the negative pulse width of the input signal is greater than the specified pulse width.
- When you select "Negative" for polarity, "<" for trigger condition, the oscilloscope triggers when the negative pulse width of the input signal is smaller than the specified pulse width.
- When you select "Negative" for polarity, "< >" for trigger condition, the oscilloscope triggers when the negative pulse width of the input signal is greater than the specified lower limit of pulse width and smaller than the specified upper limit of pulse width.

Pulse Width Setting

- In the **When** menu, when ">" or "<" is selected, click or tap the input field of **Lower** or **Upper** to set the lower limit value or the upper limit value with the pop-up numeric keypad. You can also use the specified multifunction knob to set the value. The pulse width available is from 1 ns to 10 s.

- In the **When** menu, when "< >" is selected, click or tap the input field of **Upper** and **Lower** respectively to set the lower limit value and the upper limit value with the pop-up numeric keypad. You can also use the specified multifunction knob to set the values. The lower limit of the pulse width must be smaller than the upper limit.

8.7.3 Slope Trigger

In Slope trigger, the oscilloscope triggers on the positive or negative slope of the specified time. This trigger type is applicable to ramp and triangle waveforms.

In this oscilloscope, positive slope time is defined as the time difference between the two crossing points of trigger level line A and B with the rising edge; negative slope time is defined as the time difference between the two crossing points of trigger level line A and B with the falling edge. See the figure below.




Figure 8.6 Positive Slope Time/Negative Slope Time

Trigger Type

Click or tap the drop-down button of **Type** to select "Slope". Then set the parameters for Slope trigger.




Figure 8.7 Slope Trigger Setting Menu

After a trigger type is selected, the current trigger setting information (including trigger type, trigger source, and trigger level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Source Selection

Click or tap the drop-down button of **Source** to select the analog channel as the specified source. For the available channels of the specified model, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Edge Type

Select the input signal edge (in the **Slope** item) on which the oscilloscope triggers.

- Rising: triggers on the rising edge of the input signal.
- Falling: triggers on the falling edge of the input signal.

Trigger Condition

Sets the trigger condition in the **When** item.

- When you select "Rising" for the edge type, ">" for trigger condition, the oscilloscope triggers when the positive slope time of the input signal is greater than the specified time.
- When you select "Rising" for the edge type, "<" for trigger condition, the oscilloscope triggers when the positive slope time of the input signal is smaller than the specified time.
- When you select "Rising" for the edge type, "< >" for trigger condition, the oscilloscope triggers when the positive slope time of the input signal is greater than the specified lower limit time and smaller than the specified upper limit time.
- When you select "Falling" for the edge type, ">" for trigger condition, the oscilloscope triggers when the negative slope time of the input signal is greater than the specified time.
- When you select "Falling" for the edge type, "<" for trigger condition, the oscilloscope triggers when the negative slope time of the input signal is smaller than the specified time.
- When you select "Falling" for the edge type, "< >" for trigger condition, the oscilloscope triggers when the negative slope time of the input signal is greater than the specified lower limit time and smaller than the specified upper limit time.

Slope Time Setting

- In the **When** item, when ">" or "<" is set to trigger conditions, click or tap the input field of **Lower** or **Upper** to set the lower limit value or the upper limit value with the pop-up numeric keypad. You can also use the corresponding knob to set the value. The slope time available is from 1 ns to 10 s.
- In the **When** item, when "< >" is set to trigger conditions, click or tap the input field of **Upper** and **Lower** respectively to set the upper limit value and the lower limit value with the pop-up numeric keypad. You can also use the corresponding knob to set the values. The lower slope time limit must be smaller than the upper slope time limit.

Level Selection and Setting

After the trigger condition setting is completed, you need to adjust the trigger level to correctly trigger the signal and obtain a stable waveform.

Click or tap the **Level A/Level B** input field to set the level A/level B with the pop-up numeric keypad. You can also use the trigger level knob or use the specified multifunction knob to adjust level A/level B. Check the checkbox of **Linkage** to link Level A and Level B. The Level A and Level B will be adjusted synchronously. The upper limit and lower limit values change at the same time. The difference between upper and lower limit remains unchanged. For details, refer to descriptions in *Trigger*

Level. The current trigger level is displayed in the trigger information label at the top of the screen.



TIP

Press down the trigger level knob and rotate it to adjust Level A, Level B, and Level AB (when linkage is enabled) in sequence.

8.7.4 Video Trigger

The video signal can include image information and timing information, which adopts different standards and formats. This series can trigger on the standard video signal field or line of NTSC (National Television Standards Committee), PAL (Phase Alternating Line), or SECAM (Sequential Couleur A Memoire).

Trigger Type

Click or tap the drop-down button of **Type** to select "Video".





Figure 8.8 Video Trigger Setting Menu

After a trigger type is selected, the current trigger setting information (including trigger type, trigger source, and trigger level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Source Selection

Click or tap the drop-down button of **Source** to select the analog as the specified source. For the available channels of the specified model, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Video Polarity

In the **Polarity** item, select the desired polarity: positive polarity () or negative polarity ()

Video Standard

Click or tap the drop-down button of **Standard** to select the desired video standard.

Table 8.1 Video Standard

Video Standard	Frame Frequency (Frame)	Scan Type	TV Scan Line
NTSC	30	Interlaced Scan	525
PAL/SECAM	25	Interlaced Scan	625
480p/60Hz	60	Progressive Scan	525
576p/50Hz	50	Progressive Scan	625
720p/60Hz	60	Progressive Scan	750
720p/50Hz	50	Progressive Scan	750
720p/30Hz	30	Progressive Scan	750
720p/25Hz	25	Progressive Scan	750
720p/24Hz	24	Progressive Scan	750
1080p/60Hz	60	Progressive Scan	1125
1080p/50Hz	50	Progressive Scan	1125
1080p/30Hz	30	Progressive Scan	1125
1080p/25Hz	25	Progressive Scan	1125
1080p/24Hz	24	Progressive Scan	1125
1080i/60Hz	60	Interlaced Scan	1125
1080i/50Hz	50	Interlaced Scan	1125

Sync

In the **Sync** item, select the desired sync type.

- All Lines: triggers on the first line found.
- Line: triggers on the specified line.

When this sync type is selected, you can specify a line number. Click or tap the input field of **Line** to set the line number by using the pop-up numeric keypad. You can also use the corresponding multifunction knob to set the value. The range of the line number is related to the currently selected video standards. The range is from 1 to 525 (NTSC), 1 to 625 (PAL/SECAM), 1 to 525 (480p), 1 to 625 (576p), 1 to 750 (720p), or 1 to 1125 (1080p/1080i).

- Odd: triggers on the rising edge of the first ramp pulse in the odd field. It is only available when the video standard is set to "NTSC" or "PAL/SECAM".
- Even: triggers on the rising edge of the first ramp pulse in the even field. It is only available when the video standard is set to "NTSC" or "PAL/SECAM".



TIP

- To better observe the waveform details in the video signal, you can set a larger memory depth first.
- As RIGOL's digital oscilloscope provides the intensity graded color display function, the frequency in different parts of the signal can be indicated in different brightness levels. In this way, the experienced users can quickly judge the signal quality and discover abnormalities during the debugging process.

8.7.5 Pattern Trigger

The pattern trigger identifies a trigger condition by looking for a specified pattern. This pattern is a logical "AND" combination of channels. Each channel can be set to H (high), L (low), or X (don't care). A rising or falling edge (you can only specify a single edge) can be specified for one channel included in the pattern. When an edge is specified, the oscilloscope will trigger at the edge specified if the pattern set for the other channels are true (namely the actual pattern of the channel is the same as the preset pattern). If no edge is specified, the oscilloscope will trigger on the last edge that makes the pattern true. If all the channels in the pattern are set to "X", the oscilloscope will not trigger.




Figure 8.9 Pattern Trigger

Trigger Type

Click or tap the drop-down button of **Type** to select "Pattern".





Figure 8.10 Pattern Trigger Setting Menu of MHO Series 4-CH Model



Figure 8.11 Pattern Trigger Setting Menu of DHO Series 8-CH Model

After a trigger type is selected, the current trigger setting information (including the trigger type, source, and level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Select the Source

Click or tap the drop-down button of **Source** to select the analog channel or the digital channel as the trigger source. For available channels, refer to descriptions in

Trigger Source. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Pattern Setting

The following five patterns are available:

- 1: sets the pattern of the channel selected to "1", i.e. the voltage level is higher than the trigger level of the channel.
- 0: sets the pattern of the channel selected to "0", i.e. the voltage level is lower than the trigger level of the channel.
- X: sets the pattern of the channel selected to "X", i.e. this channel is not used as a part of the pattern. When all channels in the pattern are set to "X", the oscilloscope will not trigger.
- : sets the pattern to the rising edge of the channel selected.
- : sets the pattern to the falling edge of the channel selected.

The Left/Right arrow key indicates moving left/right to switch the channel pattern. "All" indicates all bits. Select a pattern for a channel and then click or tap **All**. The patterns of all the other channels will be set to the currently selected pattern. The pattern setting is shown in the figure below:



Only one edge (rising or falling edge) can be specified in the pattern. If one edge item is currently defined and then another edge item is defined in another channel in the pattern, then a prompt message "Invalid input" is displayed.

8.7.6 Duration Trigger

In duration trigger, the oscilloscope identifies a trigger condition by searching for the duration of a specified pattern. This pattern is a logical "AND" combination of the channels. Each channel can be set to 1 (high), 0 (low), or X (don't care). The

instrument triggers when the duration (ΔT) of this pattern meets the preset time, as shown in the figure below.




Figure 8.12 Duration Trigger

Trigger Type

Click or tap the drop-down button of **Type** to select "Duration".




Figure 8.13 Duration Trigger Setting Menu of MHO Series 4-CH Model





Figure 8.14 Duration Trigger Setting Menu of DHO Series 8-CH Model

After a trigger type is selected, the current trigger setting information (including the trigger type, source, and level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Select the Source

Click or tap the drop-down button of **Source** to select the analog channel or the digital channel as the trigger source. For available channels, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Pattern Setting

The following three patterns are available:

- 1: sets the pattern of the channel selected to "1", i.e. the voltage level is higher than the trigger level of the channel.
- 0: sets the pattern of the channel selected to "0", i.e. the voltage level is lower than the trigger level of the channel.
- X: sets the pattern of the channel selected to "X", i.e. this channel is not used as a part of the pattern. When all channels in the pattern are set to "X", the oscilloscope will not trigger.

The Left/Right arrow key indicates moving left/right to switch the channel pattern.

"All" indicates all bits. Select a pattern for a channel, then click or tap **All**. The patterns of all the other channels will be set to the currently selected pattern.

Trigger Condition

Set the trigger condition in the **When** item.

- **>**: triggers when the duration of the pattern is greater the preset time. Click or tap the input field of **Lower** to set the lower limit of the duration of the pattern with the pop-up numeric keypad. You can also use the corresponding multifunction knob to set the value. The available range is from 1 ns to 10 s.
- **<**: triggers when the duration of the pattern is smaller than the preset time. Click or tap the input field of **Upper** to set the upper limit of the duration of the pattern. You can also use the corresponding multifunction knob to set the value. The available range is from 1 ns to 10 s.
- **< >**: triggers when the duration of the pattern is smaller than the upper limit of the preset time and greater than the lower limit of the preset time. Click or tap the input field of **Upper** to set the upper limit of the duration of the pattern, and the range is from 1.01 ns to 10 s. Click or tap the input field of **Lower** to set the lower limit of the duration of the pattern, and the range is from 1 ns to 9.9 s. You can also use the corresponding multifunction knob to set the upper/lower limit. The lower time limit must be smaller than the upper time limit.
- **> <**: triggers when the duration of the pattern is greater than the upper limit of the preset time or smaller than the lower limit of the preset time. Click or tap the input field of **Upper** to set the upper limit of the duration of the pattern, and the range is from 1.01 ns to 10 s. Click or tap the input field of **Lower** to set the lower limit of the duration of the pattern, and the range is from 1 ns to 9.9 s. You can also use the corresponding multifunction knob to set the upper and lower limit. The lower time limit must be smaller than the upper time limit.

8.7.7 Timeout Trigger

In Timeout trigger, the oscilloscope triggers when the time interval (ΔT) (the time from when the rising edge (or falling edge) of the input signal passes through the trigger level to the time from when the neighboring falling edge (or rising edge) passes through the trigger level) is greater than the preset timeout value, as shown in the figure below.




Figure 8.15 Timeout Trigger

Trigger Type

Click or tap the **Type** drop-down button to select "Timeout".





Figure 8.16 Timeout Trigger Menu

After a trigger type is selected, the current trigger setting information (including the trigger type, source, and level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Select the Source

Click or tap the drop-down button of **Source** to select the analog channel or the digital channel as the trigger source. For available channels, refer to descriptions in

Trigger Source. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Edge Type

In **Slope** item, select the edge type from which the input signal passes through the trigger level.

- Rising: starts timing when the rising edge of the input signal passes through the trigger level.
- Falling: starts timing when the falling edge of the input signal passes through the trigger level.
- Either: starts timing when either edge of the input signal passes through the trigger level.

Timeout Value

Timeout value represents the maximum time that the signal remains idle before the signal passes through the trigger level. Click or tap the input field of **Timeout**, and then use the pop-up numeric keypad to set the timeout value of Timeout trigger. You can also use the corresponding multifunction knob to set the value.

8.7.8 Runt Trigger

The Runt trigger is used to trigger pulses that pass through one trigger level but fail to pass through another trigger level, as shown in the figure below.




Figure 8.17 Runt Trigger

Trigger Type

Click or tap the drop-down button of **Type** to select "Runt".





Figure 8.18 Runt Trigger Setting Menu

After a trigger type is selected, the current trigger setting information (including the trigger type, source, and level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Source Selection

Click or tap the drop-down button of **Source** to select the analog channel as the specified source. For the available channels of the specified model, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Polarity

Select the pulse polarity of Runt trigger under the **Polarity** item.

- Positive : indicates that the instrument triggers on the positive runt pulse.
- Negative : triggers on the negative runt pulse.

Trigger Condition

Set the Runt trigger condition in the **When** item.

- **None**: indicates not setting the trigger condition of Runt trigger.
- **>**: triggers when the runt pulse width is greater the Lower limit of pulse width. Click or tap the input field of **Lower** to set the minimum pulse width of Runt trigger with the pop-up numeric keypad. You can also use the corresponding multifunction knob to modify the value.
- **<**: triggers when the runt pulse width is smaller than the upper limit of pulse width. Click or tap the input field of **Upper** to set the maximum pulse width of Runt trigger with the pop-up numeric keypad. You can also use the corresponding multifunction knob to modify the value.
- **< >**: triggers when the runt pulse width is greater than the lower limit and smaller than the upper limit of pulse width. Click or tap the input field of **Upper** to set the maximum pulse width of Runt trigger with the pop-up numeric keypad. Click or tap the input field of **Lower** to set the minimum pulse width of Runt trigger with the pop-up numeric keypad. You can also use the corresponding multifunction knob to modify the maximum and minimum pulse width. The lower limit of the pulse width must be smaller than the upper limit.

Level Selection and Setting

After the trigger condition setting is completed, you need to adjust the trigger level to correctly trigger the signal and obtain a stable waveform.

Click or tap the **Level A/Level B** input field to set the level A/level B with the pop-up numeric keypad. You can also use the trigger level knob or use the corresponding multifunction knob to adjust level A/level B. Check the checkbox of **Linkage** to link Level A and Level B. The Level A and Level B will be adjusted synchronously. The upper limit and lower limit values change at the same time. The difference between upper and lower limit remains unchanged. For details, refer to descriptions in *Trigger Level*. The current trigger level is displayed in the trigger information label at the top of the screen.



TIP

Press down the trigger level knob and rotate it to adjust Level A, Level B, and Level AB (when linkage is enabled) in sequence.

8.7.9

Window Trigger

Window trigger provides a high trigger level and a low trigger level. The instrument triggers when the input signal passes through the high trigger level or the low trigger level.

Trigger Type

Selects the "Window" trigger type, and then set the parameters for Window trigger.




Figure 8.19 Window Trigger Setting Menu

After selecting the trigger type, and then the current trigger setting information (including trigger type, trigger source, and trigger level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Source Selection

Click or tap the drop-down button of **Source** to select the desired analog channel from the drop-down list. For available channels, refer to descriptions in *Trigger Source*. The current trigger source is displayed in the trigger information label at the top of the screen.

Only when we select the channel (that has been input with signals) as the trigger source, can we obtain a stable trigger.

Edge Type

Selects the desired input signal edge on which the oscilloscope triggers.

- **Rising:** triggers on the rising edge of the input signal when the voltage level is higher than the preset high trigger level.
- **Falling:** triggers on the falling edge of the input signal when the voltage level is lower than the preset low trigger level.

- **Either:** triggers on the rising or falling edge of the input signal when the voltage level meets the preset trigger level.

Trigger Position

Sets the time point of trigger.

- **Enter:** triggers when the input signal enters the specified trigger level range.
- **Exit:** triggers when the input signal exits the specified trigger level range.
- **Time:** triggers when the accumulated hold time since the input signal entered the specified trigger level range is equal to the window time. After selecting this option, you can set the time. The available range is from 1 ns to 10 s.

Set the Trigger Level

Sets the trigger level to trigger the signal properly and obtain a stable waveform.

- **Level A:** only adjusts the upper limit of the trigger level, and the lower limit of the trigger level remains unchanged.
- **Level B:** only adjusts the lower limit of the trigger level, and the upper limit of the trigger level remains unchanged.
- **Linkage:** When you check the checkbox of Linkage, the upper and lower trigger level can be adjusted synchronously. The trigger level deviation (the difference between the upper limit and lower limit) remains unchanged.

You can set "Level A" and "Level B" with the pop-up numeric keypad. You can also rotate the Trigger Level knob on the front panel or the specified multifunction knob indicated in the input field of **Level A** and **Level B** to set the value. For details, refer to descriptions in *Trigger Level*.



TIP

Press down the trigger level knob and rotate it to adjust Level A, Level B, and Level AB (when linkage is enabled) in sequence.

8.7.10 Delay Trigger

In Delay trigger, you need to set Source A and Source B. The oscilloscope triggers when the time difference (ΔT) between the specified edges (Edge A and Edge B) of Source A and Source B meets the preset time limit, as shown in the figure below. See the figure below.




Figure 8.20 Delay Trigger

Trigger Type

Click or tap the drop-down button of **Type** to select "Delay".




Figure 8.21 Delay Trigger Setting Menu

After a trigger type is selected, the current trigger setting information (including trigger type, trigger source, and trigger level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Source Setting

- **Source A**

Click or tap the drop-down button of **Source A** to select analog channel or digital channel as the trigger source of Source A. For details, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel that has signal inputs as the trigger source, can you obtain a stable trigger.

- **Edge A**

Select the trigger edge type ("Rising" or "Falling") of Source A in Delay trigger in the **Edge A** item.

- **Source B**

Click or tap the drop-down button of **Source B** to select analog channel or digital channel as the trigger source of Source B. For details, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

- **Edge B**

Select the trigger edge type ("Rising" or "Falling") of Source B in Delay trigger in the **Edge B** item.

Set the Trigger Condition

Sets the time limit condition of Delay trigger for **When** menu item.

- **>**: triggers when the time difference (ΔT) between the specified edges of Source A and Source B is greater than the preset time lower limit. Click or tap the input field of **Lower** to set the delay time lower limit in Delay trigger with the pop-up numeric keypad. You can also use the specified multifunction knob to set the value.
- **<**: triggers when the time difference (ΔT) between the specified edges of Source A and Source B is smaller than the preset time upper limit. Click or tap the input field of **Upper** to set the delay time upper limit in Delay trigger with the pop-up numeric keypad. You can also use the specified multifunction knob to set the value.
- **< >**: triggers when the time difference (ΔT) between the specified edges of Source A and Source B is greater than the lower limit of the preset time and smaller than the upper limit of the preset time. Click or tap the input field of **Upper** to set the delay time upper limit in Delay trigger with the pop-up numeric keypad. Click or tap the input field of **Lower** to set the delay time lower limit in Delay trigger with the pop-up numeric keypad. You can also use the specified multifunction knob to set the upper and lower limit. The lower time limit must be smaller than the upper time limit.

- $> <$: triggers when the time difference (ΔT) between the specified edges of Source A and Source B is smaller than the lower limit of the preset time or greater than the upper limit of the preset time. Click or tap the input field of **Upper** to set the delay time upper limit in Delay trigger with the pop-up numeric keypad. Click or tap the input field of **Lower** to set the delay time lower limit in Delay trigger with the pop-up numeric keypad. You can also use the specified multifunction knob to set the upper and lower limit. The lower time limit must be smaller than the upper time limit.

Level Selection and Setting

After the trigger condition setting is completed, you need to adjust the trigger level to correctly trigger the signal and obtain a stable waveform.

Click or tap the input field of **Level A/Level B** to set the level A/level B with the pop-up numeric keypad. You can also use the specified multifunction knob to adjust level A/level B or use the trigger level knob to adjust the level (the focus of the trigger level knob is the last modified level). For details, refer to descriptions in *Trigger Level*. The current trigger level is displayed in the trigger information label at the top of the screen.

8.7.11 Setup/Hold Trigger

In setup&hold trigger, you need to set the clock source and data source. The setup time starts when the data signal passes the trigger level and ends at the coming of the specified clock edge; the hold time starts at the coming of the specified clock edge and ends when the data signal crosses the trigger level again, as shown in the figure below. The oscilloscope triggers when the setup time or hold time is smaller than the preset time.




Figure 8.22 Setup/Hold Trigger

Trigger Type

Click or tap the drop-down button of **Type** to select "Setup/Hold".




Figure 8.23 Setup/Hold Trigger Setting Menu

After a trigger type is selected, the current trigger setting information (including the trigger type, source, and level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Clock Source

Click or tap the drop-down button of **SCL** to select specified analog channel or digital channel. For details, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Edge Type

Select the desired clock edge type in the **Slope** item, and it can be set to "Rising" or "Falling".

Data Source

Click or tap the drop-down button of **SDA** to select analog channel or digital channel. For details, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel that has signal inputs as the trigger source, can you obtain a stable trigger.

Data Type

Select the effective pattern of the data signal in the **Data Type** item. It can be set to H (high level) or L (low level).

Trigger Condition

Set the Setup/Hold trigger condition in the **When** item.

- **Setup**: the oscilloscope triggers when the setup time is smaller than the specified setup time. After selecting this type, click or tap the input field of **Setup** to set the setup time with the pop-up numeric keypad. You can also use the specified multifunction knob to set the value.
- **Hold**: the oscilloscope triggers when the hold time is smaller than the specified hold time. After selecting this type, click or tap the input field of **Hold** to set the hold time with the pop-up numeric keypad. You can also use the specified multifunction knob to set the value.
- **Setup/Hold**: the oscilloscope triggers when the setup time or hold time smaller than the specified time value. After selecting this type, click or tap the input field of **Setup** and **Hold** respectively to set the setup and hold time with the pop-up numeric keypad. You can also use the specified multifunction knob to set the values.

Level Selection and Setting

After the trigger condition setting is completed, you need to adjust the trigger level to correctly trigger the signal and obtain a stable waveform.

Click or tap the input field of **SCL Level** or **SDA Level** to set SCL level and SDA level with the pop-up numeric keypad, respectively. You can also use the specified multifunction knob to adjust SCL level and SDA level or use the trigger level knob to adjust the level (the focus of the trigger level knob is the last modified level). For details, refer to descriptions in *Trigger Level*. The current trigger level is displayed in the trigger information label at the top of the screen.

8.7.12 Nth Edge Trigger

Triggers on the Nth edge that appears after the specified idle time. For example, in the waveform as shown in the figure below, the instrument should trigger on the second rising edge after the specified idle time (the time between two neighboring rising edges), and the idle time should be within the range between P and M ($P < \text{Idle Time} < M$). Wherein, M is the time between the first rising edge and its previous rising edge; P is the maximum time between the rising edges that participate in counting.




Figure 8.24 Nth Edge Trigger

Trigger Type

Click or tap the drop-down button of **Type** to select "Nth Edge".




Figure 8.25 Nth Edge Trigger Setting Menu

After a trigger type is selected, the current trigger setting information (including trigger type, trigger source, and trigger level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Select the Source

Click or tap the drop-down button of **Source** to select the analog channel or the digital channel as the trigger source. For available channels, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Edge Type

Select the input signal edge (in the **Slope** item) on which the oscilloscope triggers.

- Rising: triggers on the rising edge of the input signal when the voltage level meets the specified trigger level.
- Falling: triggers on the falling edge of the input signal when the voltage level meets the specified trigger level.

Idle Time

Click or tap the input field of **Idle Time**, and then use the pop-up numeric keypad to set the idle time before starting the edge counting in Nth edge trigger. You can also use the specified multifunction knob to set the value.

Edge Count

Click or tap the input field of **Edges**, then use the pop-up numeric keypad to set the value of "N" in Nth edge trigger. You can also use the specified multifunction knob to set the value. The available range is from 1 to 65,535.

8.7.13 RS232 Trigger

RS232 bus is a serial communication mode used in data transmission between PCs or between a PC and a terminal. In RS232 serial protocol, a character is transmitted as a frame of data. The frame consists of 1 start bit, 5-8 data bits, 1 check bit, and 1-2 stop bits. Its format is as shown in the figure below. This series oscilloscope triggers when the start frame, error frame, check error, or the specified data of the RS232 signal is detected.




Figure 8.26 Schematic Diagram of RS232 Protocol

Trigger Type

Click or tap the drop-down button of **Type** to select "RS232".





Figure 8.27 RS232 Trigger Setting Menu

After a trigger type is selected, the current trigger setting information (including the trigger type, source, and level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Select the Source

Click or tap the drop-down button of **Source** to select the analog channel or the digital channel as the trigger source. For available channels, refer to descriptions in [Trigger Source](#). The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Polarity

Select the polarity of data transmission in the **Polarity** item. It can be set to "Positive"



Trigger Condition

Set the desired trigger condition in the **When** item.

- **Start:** triggers on the start frame position.
- **Error:** triggers when an error frame is detected.
- **Check Error:** triggers when a check error is detected.
- **Data:** triggers on the last bit of the preset data bits. Click or tap the input field of **Data**, and then use the pop-up numeric keypad to set the data of RS232 trigger. You can also use the specified multifunction knob to set the value.

Baud Rate

You can select the baud rate of data transmission (i.e. specifies a clock frequency). Click or tap the drop-down button of **Baud Rate**, then select the preset baud rate. The available baud rates include 50 bps, 75 bps, 110 bps, 134 bps, 150 bps, 300 bps, and etc. You can also self-define the baud rate.

Data Bits

Indicate the number of bits per frame. Click or tap the drop-down button of **Data Bits** to select the desired data bits. The available data bits include "5 Bits", "6 Bits", "7 Bits", and "8 Bits".

Stop Bit

Indicates when to stop outputting data. Select the desired stop bit in the **Stop Bit** item. The available data bits include 1 Bit, 1.5 Bits, and 2 Bits.

Parity

Used to check whether the data are properly transmitted. Select None, Even, or Odd in the **Parity** item.

- **None:** indicates that no check bit appears during the transmission.
- **Even:** indicates that the total number of "1" in the data bit and check bit is an even number. For example, when 0x55 (01010101) is sent, "0" should be added to the check bit.
- **Odd:** indicates that the total number of "1" in the data bit and check bit is an odd number. For example, when 0x55 (01010101) is sent, "1" should be added to the check bit.

8.7.14 I2C Trigger

I2C is a 2-wire serial bus used to connect the microcontroller and its peripheral device. It is a bus standard widely used in the microelectronic communication control field.

The I2C serial bus consists of SCL and SDA. Its transmission rate is determined by SCL, and its transmission data is determined by SDA, as shown in the figure below. The instrument series triggers on the start condition, restart, stop, missing

acknowledgment, specific device address, or data value. Besides, it can also trigger on the specific device address and data values at the same time.




Figure 8.28 Sequential Chart of I2C Bus

Trigger Type

Click or tap the drop-down button of **Type** to select "I2C" from the drop-down list.





Figure 8.29 I2C Trigger Setting Menu

At this time, the current trigger setting information (including trigger type, trigger source, and trigger level) is displayed at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Source Selection

Click or tap the drop-down button of **SCL** and **SDA** to select the analog channel or the digital channel as the source of serial clock line (SCL) and serial data line (SDA). For details, refer to descriptions in *Trigger Source*. The current trigger source is displayed in the trigger information label at the top of the screen.

Only when we select the channel (that has been input with signals) as the trigger source, can we obtain a stable trigger.

Trigger Condition

Sets the the desired trigger condition in the **When** menu.

- **Start:** triggers when SDA data transitions from high level to low level while SCL is high level.
- **Stop:** triggers when SDA data transitions from low level to high level while SCL is high level.
- **Restart:** triggers when another start condition occurs before a stop condition.
- **MissedAck:** triggers when ACK is 1.
- **Address:** the trigger searches for the specified address value. When this event occurs, the oscilloscope will trigger on the read/write bit. After this trigger condition is selected:
 - Click or tap the drop-down button of **Direction** to select Write, Read, or R/W.
The **Direction** menu is disabled when **AddrBits** is set to "8 Bits".
 - Click or tap the drop-down button of **AddrBits** to select the desired address bits. The available address bits are "7 Bits", "8 Bits", and "10 Bits".
 - Click or tap the input field of **Address** to set the address of the I2C trigger with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it.
- **Data:** the trigger searches for the specified data value on the data line (SDA). When this event occurs, the oscilloscope will trigger on the clock line (SCL) transition edge of the last bit of data. After selecting Data as the trigger condition, you can set the address bits, data, and bytes.
 - Click or tap the drop-down button of **AddrBits** to select the desired address bits. The available address bits are "7 Bits", "8 Bits", and "10 Bits".
 - Click or tap the input field of **Bytes** to set the data bytes with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The range of the bytes is from 1 to 5.
 - Click or tap the input field of **Data**, and then the "Format" interface is displayed. You can select "Bin" or "Hex" format to set the data format.




Figure 8.30 Bin Format Setting




Figure 8.31 Hex Format Setting

- **A&D:** the oscilloscope searches for the specified address and data at the same time, then triggers when both the address and data meet the conditions. After this condition is selected, you need to set the sub-menu items such as **Direction**, **Bytes**, **AddrBits**, **Address**, and **Data**. For the setting methods, refer to descriptions in "Address" and "Data" conditions.

Level Selection and Setting

After the trigger condition setting is completed, you need to adjust the trigger level to properly trigger the signal and obtain a stable waveform.

- You can set the value of "SCL Level" with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field of **SCL Level** or use the trigger level knob to adjust the SCL Level value.
- You can set the value of "SDA Level" with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field of **SDA Level** or use the trigger level knob to adjust the SDA Level value.

For details, refer to descriptions in *Trigger Level*. The current trigger level is displayed in the trigger information label at the top of the screen.

8.7.15 SPI Trigger

In SPI trigger, after the CS or timeout condition is satisfied, the oscilloscope triggers when the specified data is found. When using SPI trigger, you need to specify the CLK clock sources and MISO data sources.

Below is the sequential chart of SPI bus.




Figure 8.32 Sequential Chart of SPI Bus

Trigger Type

Click or tap the drop-down button of **Type** to select "SPI" from the drop-down list. Then set the parameters for SPI trigger.





Figure 8.33 SPI Trigger Setting Menu

After selecting the trigger type, and then the current trigger setting information (including trigger type, trigger source, and trigger level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Source Selection

Click or tap the drop-down button of **CLK** and **MISO** to select the analog channel or the digital channel as the source of CLK and MISO. For available channels, refer to descriptions in *Trigger Source*. The current trigger source is displayed in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Edge Type

Click or tap the drop-down button of **Slope** to select the desired clock edge type.

- Rising: samples the MISO data on the rising edge of the clock.
- Falling: samples the MISO data on the falling edge of the clock.

Trigger Condition

Click or tap to select "With CS" or "Timeout" under **When** as the trigger condition.

- With CS: if the CS signal is valid, the oscilloscope will trigger when the data (SDA) satisfying the trigger conditions is found.
 - Click or tap the drop-down button of **CS** to select the analog channel or the digital channel as the CS channel. The current CS channel will be displayed in the trigger information label at the top of the screen.
 - Click or tap to select "Positive" (high level is valid) or "Negative" (low level is valid) under **CS Mode**.
- Timeout: the oscilloscope starts to search for the data (MISO) on which to trigger after the clock signal (CLK) stays in the idle state for a specified period of time. After selecting this condition, you can click or tap the input field of **Timeout** to set the timeout value with the pop-up numeric keypad. You can also use the specified knob to set it. The available range of the timeout value is from 8 ns to 10 s.

Data

Click or tap the input field of **Data**, then the "Format" interface is displayed. You can set the data bit that needs to be operated on. For details, refer to descriptions in *I2C Trigger*.

Data Bits

Click or tap the input field of **Data Bits** to set the number of bits in the serial data with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The range of the data bits is from 4 to 32.

Level Selection and Setting

After the trigger condition setting is completed, you need to adjust the trigger level to properly trigger the signal and obtain a stable waveform.

- **CLK Level:** Set "CLK Level" with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field of **CLK Level** or use the trigger level knob to adjust the CLK Level value.
- **MISO Level:** Set "MISO Level" with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field of **MISO Level** or use the trigger level knob to adjust the MISO Level value.
- **CS Level:** Set "CS Level" with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field of **CS Level** or use the trigger level knob to adjust the CS Level value.

For details, refer to descriptions in *Trigger Level*. The current trigger level is displayed in the trigger information label at the top of the screen.

8.7.16 CAN Trigger

This series oscilloscope can trigger on the start of a frame, end of a frame, frame of the specified type (e.g. Remote, Overload, Data, etc.), or error frame of the specified type (e.g. Answer Error, Check Error, Format Error, etc.) of the CAN signal.

The data frame format of the CAN bus is as shown in the figure below.




Figure 8.34 Data Frame Format of the CAN Bus

Trigger Type

Click or tap the drop-down button of **Type** to select "CAN".





Figure 8.35 CAN Trigger Setting Menu

After a trigger type is selected, the current trigger setting information (including trigger type, trigger source, and trigger level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Select the Source

Click or tap the drop-down button of **Source** to select the analog channel or the digital channel as the trigger source. For available channels, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Signal Type

Click or tap the drop-down button of **Signal Type** to select the desired signal type.

- CAN_H: indicates the actual CAN_H bus signal.
- CAN_L: indicates the actual CAN_L bus signal.
- TX/RX: indicates the Transmit signal and Receive signal from the CAN bus transceiver.
- DIFF: indicates the CAN differential bus signals connected to an analog channel by using a differential probe. Connect the probe's positive lead to the CAN_H bus signal and connect the negative lead to the CAN_L bus signal.

Baud Rate

Click or tap the drop-down button of **Baud** to select the preset baud rate. The available baud rates include 10 kbps, 20 kbps, 33.3 kbps, 50 kbps, 62.5 kbps, 83.3 kbps, and etc. You can also self-define the baud rate.

Sample Position

Sample position is a point within a bit's time. The oscilloscope samples the bit level at this point. The sample position is represented by the proportion of "the time from the start of the bit to the sample position" to the "bit time", as shown in the figure below.




Figure 8.36 Sample Position (CAN Trigger)

Click or tap the input field of **Sample Position** to set it by using the pop-up numeric keypad. You can also use the specified multifunction knob to set the value. The settable range is from 10% to 90%.

Trigger Condition

Click or tap the drop-down button of **When** to select the desired trigger condition.

- SOF: triggers at the start of a frame.
- EOF: triggers at the end of a frame.
- Remote ID: triggers on the specified ID of Remote frame. When you select **Remote ID**, you need to set the following parameters.
 - Click or tap the ON/OFF tab for **Extended ID** to enable or disable the extended ID.
 - Click or tap the input field of **ID**, and then the "Format" interface is displayed. You can set the ID that needs to be operated on. For details, refer to descriptions in *I2C Trigger*.
- Overload: triggers on the overload frames.
- Frame ID: triggers on the data frames with the specified ID. After you select **Frame ID**, you can refer to the "Remote ID" mentioned above to set the **Extended ID** and **ID**.
- Frame Data: triggers on the data frames with the specified Data. When you select **Frame Data**, you need to set the following parameters.
 - Click or tap the input field of **Data**, and then the "Format" interface is displayed. You can set the data bit that needs to be operated on. For details, refer to descriptions in *I2C Trigger*.
 - Click or tap the input field of **Bytes**, and then use the pop-up numeric keypad to set the length of the data. You can also use the corresponding multifunction knob to set the value. Its range is from 1 to 8.
- Data & ID: triggers on the data frames with the specified ID and data. When you select **Data & ID**, you need to set the **ID**, **Extended ID**, **Data**, and **Bytes**.
- Frame Error: triggers on the error frame.
- Bit Fill: triggers on the error frame with the bit fill.
- Answer Error: triggers on the answer error frame.
- Check Error: triggers on the check error frame.
- Format Error: triggers on the format error frame.
- Random Error: triggers on the random error frame, such as the format error frame, answer error frame, etc.

8.7.17 FlexRay Trigger (Option)

This series can trigger on the specified frame, symbol, error, or position of the FlexRay bus. FlexRay is a type of differential serial bus configured with three consecutive segments (i.e. packet header, payload, and packet trailer). Its data transmission rate is up to 10 Mb/s. Each frame contains a static segment and a dynamic segment, with each frame ending with the bus idle time.

Its format is as shown in the figure below.




Figure 8.37 Frame Format of FlexRay Bus

Trigger Type

Click or tap the drop-down button of **Type** to select "FlexRay" from the drop-down list. Then set the parameters for FlexRay trigger.





Figure 8.38 FlexRay Trigger Setting Menu

After selecting the trigger type, and then the current trigger setting information (including trigger type, trigger source, and trigger level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Select the Source

Click or tap the drop-down button of **Source** to select the analog channel or the digital channel as the trigger source. For available channels, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Baud Rate

You can set the baud rate of the signal. Click or tap the drop-down button **Baud** to select a FlexRay baud rate that matches the FlexRay bus signal. The available baud rates include 2.5 Mbps, 5 Mbps, and 10 Mbps.

Trigger Condition

Select the trigger condition in the **When** menu.

- **Post:** triggers on the specified position of the FlexRay bus. Select **Post** as the trigger condition, and then click or tap its drop-down button to select "TSS End", "FSS_BSS End", "FES End", or "DTS End" from the drop-down list.
- **Error:** triggers when an error occurs to the FlexRay bus. Click or tap the drop-down button of **Error** to select the error type. It includes Head CRC Err, Tail CRC Err, Decode Err, and Random Err.
- **Frame:** triggers on the frame of FlexRay bus.
 - Click or tap the drop-down button of **Frame** to select the frame type. The types of frames include null, Sync, Start, and All.
 - Select "Cyc Count" or "ID" under the **Define** menu.

When you select "Cyc Count", set the following parameters: Cyc Comp, Count Min, and Count Max. Click or tap the drop-down button of **Cyc Comp** to select the comparison conditions. The available choices include =, ≠, >, <, > <, and < >. When a certain condition is selected, click or tap the input field of **Count Min** or **Count Max**.

When you select "ID", set the following parameters: ID Comp, ID Min, and ID Max. Click or tap the drop-down button of **ID Comp** to select the comparison conditions. The available choices include =, ≠, >, <, > <, and <

>. When a certain condition is selected, click or tap the input field of **ID** **Max** or **ID Min**.

As the occurrence possibility of specified FlaxRay frame is very low, it is recommended that you set the oscilloscope to Normal trigger mode when the trigger condition is set to "Frame", so as to prevent the instrument from triggering automatically while waiting for the specified frame. The same goes for "Error" trigger condition.

8.7.18 LIN Trigger (Option)

This series can trigger on the sync field of LIN signal, and can also trigger on the specified identifier, data, or frame.

The data frame format of the LIN bus is as shown in the figure below.




Figure 8.39 Data Frame Format of the LIN Bus

Trigger Type

Click or tap the drop-down button of **Type** to select "LIN" from the drop-down list. Then set the parameters for LIN trigger.




Figure 8.40 LIN Trigger Setting Menu

After a trigger type is selected, the current trigger setting information (including the trigger type, source, and level) is displayed in the trigger information label at the top

of the screen, as shown in the figure below. The information will change based on the trigger settings.



Select the Source

Click or tap the drop-down button of **Source** to select the analog channel or the digital channel as the trigger source. For available channels, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Protocol Version

In **Version**, select the protocol version that matches the signal under test. The available versions include 1.X, 2.X and Both.

Baud Rate

Click or tap the drop-down button of **Baud** to select the preset baud rate. The available baud rates include 1.2 kbps, 2.4 kbps, 4.8 kbps, 9.6 kbps, 19.2 kbps, and etc. You can also self-define the baud rate.

Sample Position

Sample position is a point within a bit's time. The oscilloscope samples the bit level at this point. The sample position is represented by the proportion of "the time from the start of the bit to the sample position" to the "bit time", as shown in the figure below.




Figure 8.41 Sample Position (LIN Trigger)

Click or tap the input field of **Sample Position** to set it by using the pop-up numeric keypad. You can also use the specified multifunction knob to set the value. The settable range is from 10% to 90%.

Trigger Condition

Click or tap the drop-down button of **When** to select the desired trigger condition.

- **Sync:** triggers on the last bit of the sync field.
- **ID:** triggers when the frames with the specified ID are found.

Click or tap the input field of **ID**, and then use the pop-up numeric keypad to set ID. You can also use the corresponding multifunction knob to set the value.

- **Data:** triggers when the data that meet the preset conditions are found.
 - Click or tap the input field of **Data**, and then the "Format" interface is displayed. You can set the data bit that needs to be operated on. For details, refer to descriptions in *I2C Trigger*.
 - Click or tap the input field of **Bytes**, and then use the pop-up numeric keypad to set the length of the data. You can also use the corresponding multifunction knob to set the value. Its range is from 1 to 8.
- **Data&ID:** triggers when the frames with the specified ID and data that meet the preset conditions are both found.

When **Data&ID** is selected, you need to set the **Data**, **Bytes**, and **ID**.

- **Sleep:** triggers when the sleep frame is found.
- **Wakeup:** triggers when the wakeup frame is found.
- **Error:** triggers on the specified type of error frame. Click or tap the drop-down button of **Error Type** to select the error type: Sync, Even Odd, or Check Sum.

8.7.19 I2S Trigger (Option)

In I2S trigger, the oscilloscope searches for the specified data value and take it as the condition for identifying the trigger. You need to specify the serial clock line (SCLK, 1 pulse is found on the clock line once 1 bit of digital audio data is sent), frame clock line (WS, used for switch the audio channel data), and serial data line (SDA, used for transmit audio data represented in binary (2's complement)).

Below is the sequential chart of I2S bus.




Figure 8.42 Sequential Chart of I2S Bus

Trigger Type

Click or tap the drop-down button of **Type** to select "I2S" from the drop-down list. Then set the parameters for I2S trigger.





Figure 8.43 I2S Trigger Setting Menu

After selecting the trigger type, then the current trigger setting information (including trigger type, trigger source, and trigger level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Source Selection

Click or tap the drop-down button of **SCLK**, **WS**, and **SDA** to select the analog channel or the digital channel as the source of serial clock (SCLK), word select (WS), and serial data (SDA) signal. For available channels, refer to descriptions in *Trigger Source*. The current trigger source is displayed in the trigger information label at the top of the screen.

Only when we select the channel (that has been input with signals) as the trigger source, can we obtain a stable trigger.

Edge Type

Selects the desired clock edge from the drop-down list of **SCLK Edge**.

- Rising: samples the SDA data on the rising edge of the clock.
- Falling: samples the SDA data on the falling edge of the clock.

Audio

Click or tap the drop-down button of **Audio** to select the audio channel ("Left", "Right", or "Either").

Trigger Condition

In the **When** item, select the desired trigger condition.

- **=**: triggers when the channel's data equal the set data value. Click or tap the input field of **Data**, and then the "Format" interface is displayed. You can set the data bit that needs to be operated on.
- **≠**: triggers when the channel's data do not equal the set data value. Click or tap the input field of **Data**, and then the "Format" interface is displayed. You can set the data bit that needs to be operated on.
- **>**: triggers when the channel's data value is greater than the set data value. Click or tap the input field of **Data Min**, and then the "Format" interface is displayed. You can set the lower limit of the data value.
- **<**: triggers on when the channel's data value is smaller than the set data value. Click or tap the input field of **Data Max**, and then the "Format" interface is displayed. You can set the upper limit of the data value.
- **< >**: triggers when the channel's data value is smaller than the upper limit of the data value and greater than the lower limit of the data value. Click or tap the input field of **Data Max** and **Data Min**, and then the "Format" interface is displayed. You can set the upper limit and lower limit of the data value.
- **> <**: triggers when the channel's data value is greater than the upper limit of the data value or smaller than the lower limit of the data value. Click or tap the input field of **Data Max** and **Data Min**, and then the "Format" interface is displayed. You can set the upper limit and lower limit of the data value.

For details, refer to descriptions in *I2C Trigger*.

User Width

You can set the value of "User Width" with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field to adjust the value. Its range is from 4 to 32.

The user width is smaller than or equal to the width.

Width

You can set the value of "Width" with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field to adjust the value. Its range is from 4 to 32.

Alignment

Click or tap the drop-down button of **Alignment** to select the alignment way for data signal.

- **I2S:** data transmission (MSB first) begins at the second edge of the WS transition.
- **LJ:** data transmission (MSB first) begins at the edge of the WS transition.
- **RJ:** data transmission (MSB first) is right-justified to the WS transition.

Trigger Level

- **SCLK Level:** You can set the value of "SCLK Level" with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field of **SCLK Level** or use the trigger level knob to adjust the SCLK Level value.
- **WS Level:** You can set the value of "WS Level" with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field of WS Level or use the trigger level knob to adjust the WS Level value.
- **SDA Level:** You can set the value of "SDA Level" with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field of **SDA Level** or use the trigger level knob to adjust the SDA Level value.

For details, refer to descriptions in *Trigger Level*. The current trigger level is displayed in the trigger information label at the top of the screen.

8.7.20 MIL-STD-1553 Trigger (Option)

1553B is the abbreviation for the MIL-STD-1553 bus. This series can trigger on the sync field of 1553B bus, and can also trigger on the specified data word, command word, status word, or error type.

The command word, data word, and status word format of the 1553B bus is as shown in the figure below.




Figure 8.44 Formats of the Command Word, Data Word, and Status Word of the 1553B Bus

Trigger Type

Click or tap the drop-down button of **Type** to select "1553B" from the drop-down list. Then set the parameters for MIL-STD-1553 trigger.





Figure 8.45 MIL-STD-1553 Trigger Setting Menu

After a trigger type is selected, the current trigger setting information (including trigger type, trigger source, and trigger level) is displayed in the trigger information label at the top of the screen, as shown in the figure below. The information will change based on the trigger settings.



Select the Source

Click or tap the drop-down button of **Source** to select the analog channel or the digital channel as the trigger source. For available channels, refer to descriptions in *Trigger Source*. The selected trigger source is indicated in the trigger information label at the top of the screen.

Only when you select the channel (that has been input with signals) as the trigger source, can you obtain a stable trigger.

Polarity

In the **Polarity** item, select the desired polarity: positive polarity () or negative polarity ().

Level Selection and Setting

After the trigger condition setting is completed, you need to adjust the trigger level to correctly trigger the signal and obtain a stable waveform.

Click or tap the **Level A/Level B** input field to set the level A/level B with the pop-up numeric keypad. You can also use the trigger level knob or use the specified multifunction knob to adjust level A/level B. Check the checkbox of **Linkage** to link Level A and Level B. The Level A and Level B will be adjusted synchronously. The upper limit and lower limit values change at the same time. The difference between upper and lower limit remains unchanged. For details, refer to descriptions in *Trigger Level*. The current trigger level is displayed in the trigger information label at the top of the screen.



TIP

Press down the trigger level knob and rotate it to adjust Level A, Level B, and Level AB (when linkage is enabled) in sequence.

Trigger Condition

Click or tap the drop-down button of **When** to select the desired trigger condition.

- **Sync:** triggers on the specified sync type. After this trigger condition is selected, click or tap the drop-down button of **Sync** to select the desired sync type: Data Sync, Cmd/Status Sync, or All Sync.
- **Data:** triggers on the specified data word. After this trigger condition is selected, click or tap the comparison conditions from the **Comp** menu. The available choices include =, ≠, >, <, > <, and < >.
 - **=:** triggers when the channel's data word equals the set data word. Click or tap the input field of **Min**, and then the "Format" interface is displayed. You can set the lower limit of the data word. For details, refer to descriptions in *I2C Trigger*.
 - **≠:** triggers when the channel's data word does not equal the set data word. Click or tap the input field of **Min**, and then the "Format" interface is displayed. You can set the lower limit of the data word. For details, refer to descriptions in *I2C Trigger*.
 - **>:** triggers when the channel's data word is greater than the set data word. Click or tap the input field of **Min**, and then the "Format" interface is displayed. You can set the lower limit of the data word. For details, refer to descriptions in *I2C Trigger*.
 - **<:** triggers when the channel's data word is smaller than the set data word. Click or tap the input field of **Max**, and then the "Format" interface is displayed. You can set the upper limit of the data word. For details, refer to descriptions in *I2C Trigger*.
 - **< >:** triggers when the channel's data word is smaller than the upper limit of the data word and greater than the lower limit of the data word. Click or tap the input field of **Max** and **Min**, and then the "Format" interface is displayed. You can set the upper limit and lower limit of the data word. For details, refer to descriptions in *I2C Trigger*.

- > <: triggers when the channel's data word is greater than the upper limit of the data word or smaller than the trigger lower limit of the data word. Click or tap the input field of **Max** and **Min**, and then the "Format" interface is displayed. You can set the upper limit and lower limit of the data word. For details, refer to descriptions in *I2C Trigger*.
- **RTA**: triggers on the specified remote terminal address. After this trigger condition is selected, click or tap the input field of **RTA**, then the "Format" interface is displayed. You can set the remote terminal address. For details, refer to descriptions in *I2C Trigger*.
- **RTA+11Bit**: triggers on the RTA and the remaining 11 bits.
After this trigger condition is selected:
 - Click or tap the input field of **RTA**, and then the "Format" interface is displayed. You can set the remote terminal address. For details, refer to descriptions in *I2C Trigger*.
 - Click or tap the input field of **Bit Time**, and then the "Format" interface is displayed. You can set the bit time position value to 0 (low), 1 (high), or X (don't care). For details, refer to descriptions in *I2C Trigger*.
- **Error**: triggers on the specified error type. After this trigger condition is selected, click or tap the drop-down button of **Err Type** to select the error type.
 - **Sync Error**: triggers when an invalid sync pulse is found.
 - **Check Error**: triggers when the parity bit is incorrect for the data in the word.

8.8 Zone Trigger

This series oscilloscope supports the zone trigger and provides two rectangle areas: Trigger zone A and Trigger zone B. You can set the trigger conditions to "Intersect" or "Not intersect". Refer to "*Rectangle Drawing*" to draw a rectangular in the waveform view. When you move your finger away from the screen, the sub-menus are displayed. Click or tap to select "Trigger zone A" or "Trigger zone B". Double-click the area to enter the specified zone trigger interface. Also, in the Trigger menu, you can click or tap **Zone trig** to enter the zone trigger interface.

Set the Trigger Zone

In the rectangle drawing mode, the region that you draw in the waveform view called the trigger zone. In the trigger zone interface, you can set "Center X" and "Center Y" to adjust the position of the trigger zone. Set "Width" and "Height" to adjust the area of the trigger zone.

Enable or Disable the Trigger Zone

Click or tap the ON/OFF tab for **Zone A** and **Zone B** to enable or disable the specified trigger zone in the waveform view. They can be controlled independently.

Select the Source


Selects the source for trigger zone A and B. The available sources are CH1-CH8. The color of the zone name and the zone region are the same as that of the selected channel.

Select the Trigger Condition

If you enable Zone A, select CH1 as the source for Zone A, select "Intersect" as the condition, the following figure is displayed.



If you enable Zone A, select CH1 as the source for Zone A, select "Not intersect" as the condition, the following figure is displayed.



TIP

If both trigger zone A and trigger zone B are enabled, the logic "And" operation is the final trigger condition.

Set the Trigger Logic for the Zone Trigger

- **A or B:** triggers when one of the trigger conditions set for Zone A and Zone B is met.
- **A & B:** triggers when both of the trigger conditions set for Zone A and Zone B are met.

8.9 Trigger Output Connector

The trigger output connector ([**AUX OUT**]) on the rear panel of this series oscilloscope can output trigger signals (trigger hardware) based on the current setting.


Click or tap the function navigation icon  > **Utility**. Click or tap **Setup**, and then in the **AUX Out** menu, select "TrigOut". A signal which reflects the current oscilloscope capture rate can be output from [**AUX OUT**] connector each time a trigger is generated by the oscilloscope. If this signal is connected to a waveform display device to measure the frequency, the measurement result is the same as the current capture rate.

If "PassFail" is selected for the **AUX Out** menu, the instrument can output a pulse from the [**AUX OUT**] connector when a pass/failed event is detected during the pass/fail test.

9 Math Operation

This series of oscilloscopes can realize multiple math operations between waveforms of different channels, including arithmetic operation, spectrum operation, logic operation, function operation, and digital filter. To enter the **Math** menu, perform any of the following operations:

- Click or tap the function navigation icon  at the lower-left corner of the screen, and then select **Math** to enter the "Math" menu.
- Click or tap **Math** on the toolbar at the upper-right of the interface to enter the "Math" menu.
- Click or tap the math label (M) at the bottom of the screen. Then the math operation label is displayed below.



Click or tap the specified math operation label to enable the specified math operation, and the specified math operation window is displayed on the screen, as shown in *Figure 9.2*. Click or tap the specified math label again or click/tap



at the upper-right corner of the math operation window to enter the math operation setting menu.

- Press the front-panel  key to enter the math operation menu.




Figure 9.1 Math Operation Menu

This oscilloscope provides four math operations: Math1, Math2, Math3, and Math4. Click or tap the **Math1**, **Math2**, **Math3**, or **Math4** tab to enter the specified math operation menu. You can also slide on the current math operation menu to switch among different math operation tabs. This manual takes Math1 as an example to introduce math operation.

By default, the math operation is disabled. When the specified math operation is enabled respectively, the corresponding math operation is displayed on the screen, as shown in the figure below.




Figure 9.2 Math Operation Result Display Window

Users can drag the title bar of the display window to change the position of the window. You can also click/tap the close button  at the upper-right corner of the window to close it.

9.1 Arithmetic Operation

In the **Math** menu, click or tap the drop-down button of **Operator** to select the desired math operation. The arithmetic operations supported by this oscilloscope include $A+B$, $A-B$, $A \times B$, and $A \div B$.

- **$A+B$** adds the waveform voltage values of signal source A and B point by point and displays the results.
- **$A-B$** subtracts the waveform voltage values of signal source B from that of source A point by point and displays the results.
- **$A \times B$** multiplies the waveform voltage values of signal source A and B point by point and displays the results.
- **$A \div B$** divides the waveform voltage values of signal source A by that of source B point by point and displays the results. It can be used to analyze the Multiple relation of the two channels waveforms.

For the arithmetic operation menu, refer to *Figure 9.1*.

Arithmetic Operation Result Display Window

Click or tap the ON/OFF tab for **Operation** to enable or disable the display of the arithmetic operation result window. The source and the vertical scale parameters are displayed at the top of the window, as shown in the figure below.




Figure 9.3 Arithmetic Operation Result Display Window

Source

Click or tap the drop-down button of **SourceA** or **SourceB** to select CH1~CH8 or Ref1~Ref10. When a source channel is selected, the selected channel automatically switches to the ON state.



TIP

In addition to CH1~CH8 and Ref1~Ref10, the available sources for Math2 also include Math1; the sources for Math3 also include Math1 and Math2; the sources for Math4 also include Math1, Math2, and Math3. The selected Math channel and operation status will automatically be enabled.

9.2 Function Operation




Figure 9.4 Function Operation Menu

Function Operation Result Display Window

Click or tap the ON/OFF tab for **Operation** to enable or disable the display of the operation result window. The parameters such as source and the vertical scale are displayed at the top of the window, as shown in the figure below.




Figure 9.5 Function Operation Result Display Window

Source

Click or tap the drop-down button of **Source** to select CH1~CH8 or Ref1~Ref10. When a source channel is selected, the selected channel automatically switches to the ON state.

TIP

In addition to CH1~CH8 and Ref1~Ref10, the available sources for Math2 also include Math1; the sources for Math3 also include Math1 and Math2; the sources for Math4 also include Math1, Math2, and Math3. The selected Math channel and operation status will automatically be enabled.

Auto Set

Click or tap **AutoSetting** to adjust the vertical scale and the offset of the operation results to the optimal value according to the current configuration for you to better observe.

Parameter Setting

- When the operator is "Intg", click or tap the input field of **Offset** and use the pop-up numeric keypad to set the DC offset calibration factor of the input signal. You can also use the specified multifunction knob to set the value.
- When the operator is "Diff", click or tap the input field of **Smooth** and use the pop-up numeric keypad to set the number of smooth times for the differential operation. You can also use the specified multifunction knob to set the value.

9.3 FFT Operation

FFT (Fast Fourier Transform) is used to transform time-domain signals to frequency-domain components (frequency spectrum). This oscilloscope provides FFT operation function which enables you to observe the time-domain waveform and spectrum of the signal at the same time. FFT operation can facilitate the following works:

- Measure harmonic components and distortion in the system;
- Display the characteristics of the noise in DC power;
- Analyze vibration.

In the **Math** menu, click or tap the drop-down button of **Operator** to select **FFT** to go to the FFT operation menu. Then configure the parameters of FFT.




Figure 9.6 FFT Operation Menu

Operation

Click or tap the ON/OFF tab for **Operation** to enable or disable the FFT operation result window. The parameters such as center frequency, frequency span, and resolution are displayed at the top of the window, as shown in the figure below. Of which, FFT resolution is the quotient of the sample rate and the number of FFT points. If the number of FFT points is a fixed value (65535 at most), then the higher the sample rate, the higher the resolution.




Figure 9.7 FFT Operation Result Display Window

Source

Click or tap the drop-down button of **Source** to select CH1~CH8. When a source channel is selected, the selected channel automatically switches to the ON state.

Frequency Range

In **X**, select "Span-Center" or "Start-End" mode and then configure the frequency range setting.

- **Span-Center (frequency span to center frequency):** Span specifies the frequency range represented by the width from the frequency at the left side of the window to the frequency at the right side of the window. Divide the frequency span by 10 to obtain the frequency per division.

Click or tap the input field of **Center Freq** to set the frequency of the frequency-domain waveform relative to the horizontal center of the screen. You can also use the specified multifunction knob to set the value. Its range is from 5 Hz to 1 GHz. Click or tap the input field of **Span** to set the frequency span with the pop-up numeric keypad. You can also use the specified multifunction knob to set the value. Its range is from 10 Hz to 1 GHz.

- **Start-End (start frequency to stop frequency):** Start frequency specifies the frequency at the left side of the window. Click or tap the input field of **Start Freq** to set the start frequency with the pop-up numeric keypad or use the specified multifunction knob to set the value. Its range is from 0 Hz to (stop frequency - 10 Hz). Stop frequency specifies the frequency at the right side of the window. Click or tap the input field of **End Freq** to set the stop frequency with the pop-

up numeric keypad or use the specified multifunction knob to set the value. Its range is from (start frequency + 10 Hz) to 1 GHz. By default, it is 10 MHz.

Vertical Scale/Offset

Selects **dBm/dBV** or **Vrms** as the unit for **Scale** and **Offset**.

Window Function

Spectral leakage can be considerably minimized when a window function is used. The oscilloscope provides 6 FFT window functions which have different characteristics and are applicable to measure different waveforms, as shown in the table below. You need to select the window function according to the characteristics of the waveform to be measured. Click or tap the drop-down button of **Window** to select the desired window function.

Table 9.1 Window Function

Window Function	Characteristics	Waveforms Applicable to the Window Function
Rectangular	Best frequency resolution Poorest amplitude resolution Similar to the situation when no window is applied.	Transient or short pulse, the signal levels before and after the multiplication are basically the same Sine waveforms with the same amplitudes and rather similar frequencies Wide band random noise with relatively slow change of waveform spectrum
Blackman-Harris	Best amplitude resolution Poorest frequency resolution	Single frequency signal, searching for higher order harmonics
Hanning	Better frequency resolution and poorer amplitude resolution compared with Rectangular	Sine, periodic, and narrow band random noise
Hamming	A little bit better frequency resolution than Hanning	Transient or short pulse, the signal levels before and after the multiplication are rather different
Flat Top	Measure the signals accurately	Measure the signal that has no accurate reference and requires an accurate measurement

Window Function	Characteristics	Waveforms Applicable to the Window Function
Triangle	Better frequency resolution	Measure the narrow band signal and that has strong noise interference

Color Grade

Click or tap the ON/OFF tab for **Color Grade** to enable/disable the color grade display of FFT operation results. When enabled, different colors are displayed on the screen to indicate the times of data acquisition or acquisition probability. Click or tap the **Reset** button for the **Color Grade** menu to clear the color grade display and display the color grade again.

Peak Search

Click or tap the icon  at the right side of **Peak Search** to enter the peak search menu, as shown in the figure below.




Figure 9.8 Peak Search

- **Peak Search ON/OFF:** click or tap the ON/OFF tab for **Peak Search** to enable or disable the display of the peak search window. By default, it is OFF.
- **Peak Number:** click or tap the input field of **Peak Number** and use the pop-up numeric keypad to set the number of peaks. You can also use the specified knob to set the value. Its range is from 1 to 15. Its default value is 5.
- **Threshold:** click or tap the input field of **Threshold** to set the threshold of the peak with the pop-up numeric keypad. You can also use the multifunction menu

to set the value. The range of the threshold is related to the current FFT scale and offset.

- **Excursion:** click or tap the input field of **Excursion** to set the excursion of the peak or use the specified multifunction knob to set the value. The minimum value of Excursion is 0 and its unit is consistent with that of FFT.
- **Table Order:** click or tap to select **Amp Order** or **Freq Order** as the sorting mode. By default, it is "Amp Order".

Click or tap **Export**, then the export setting interface is displayed. You can export the peak search results to the internal memory or the external USB storage device in CSV format. In the menu, click or tap the input field of **File Name** to set the file name. Click or tap the input field of **File Path**, then the disk management menu (*Disk Management*) is displayed. Select the desired location to export the file, and then click or tap **Export** to export the peak search results.

Clicking or tapping the icon  at the right side of **Peak Search** can close the the peak search menu.

9.4 Logic Operation

In the **Math** menu, click or tap the drop-down button of **Operator** to select the desired math operation. The logic operations supported by this oscilloscope include $A \& B$, $A || B$, $A - B$, $A \wedge B$, and $\neg A$. After selecting the desired logic operation from the drop-down button of **Operator**, you can configure its settings for the selected logic operation type.




Figure 9.9 Logic Operation Menu

- **A&&B:** Performs logic "AND" operation on the waveform voltage values of the specified sources point by point and displays the results. In operation, when the voltage value of the source channel is greater than the threshold of the corresponding channel, it is regarded as logic "1"; otherwise it is logic "0".
- **A||B:** Performs logic "OR" operation on the waveform voltage values of the specified sources point by point and displays the results. In operation, when the voltage value of the source channel is greater than the threshold of the corresponding channel, it is regarded as logic "1"; otherwise it is logic "0".
- **A^B:** Performs logic "XOR" operation on the waveform voltage values of the specified sources point by point and displays the results. In operation, when the voltage value of the source channel is greater than the threshold of the corresponding channel, it is regarded as logic "1"; otherwise it is logic "0".
- **!A:** Performs logic "NOT" operation on the waveform voltage values of the specified sources point by point and displays the results. In operation, when the voltage value of the source channel is greater than the threshold of the corresponding channel, it is regarded as logic "1"; otherwise it is logic "0".

Table 9.2 Logic Operation

A	B	A&&B	A B	A^B	!A
0	0	0	0	0	1
0	1	0	1	1	1

A	B	A&&B	A B	A^B	!A
1	0	0	1	1	0
1	1	1	1	0	0

Logic Operation Result Display Window

Click or tap the ON/OFF tab for **Operation** to enable or disable the display of the logic operation result window. The source and the waveform sizes parameters are displayed at the top of the window, as shown in the figure below.




Figure 9.10 Logic Operation Result Display Window

Source

Click or tap the drop-down button of **SourceA** or **SourceB** to select the analog channels or digital channels. When a source channel is selected, the selected channel automatically switches to the ON state.



NOTE

For the channel sources supported by different models, refer to *Content Conventions in this Manual*.

Waveform Size

You can select "Small", "Medium", or "Large" as the waveform display mode.



Sensitivity

Sets the sensitivity of the digital signal converted from the analog signal on the source. Click or tap the input field of **Sensitivity** to set the sensitivity with the pop-up numeric keypad. You can also use the specified knob to set it.

Threshold

Sets the threshold of the channel source. Click or tap the input field of the specified channel threshold to set the threshold with the pop-up numeric keypad. You can also use the specified knob to set it.

9.5 Digital Filter

In the **Math** menu, click or tap the drop-down button of **Operator** to select the desired math operation. The digital filter supported by this oscilloscope includes: low-pass filter, high-pass filter, band-pass filter, and band-stop filter.

- **LowPass** only allows the signals whose frequencies are lower than the current upper limit frequency to pass.
- **HighPass** only allows the signals whose frequencies are higher than the current lower limit frequency to pass.
- **BandPass** only allows the signals whose frequencies are higher than the current lower limit frequency and lower than the current upper limit frequency to pass.
- **BandStop** only allows the signals whose frequencies are lower than the current lower limit frequency or higher than the current upper limit frequency to pass.




Figure 9.11 Digital Filter Menu

Digital Filter Operation Result Display Window

Click or tap the on/off tab for the **Operation** menu to enable or disable the display of the operation result window. The source and the vertical scale parameters are displayed at the top of the window, as shown in the figure below.




Figure 9.12 Digital Filter Operation Result Display Window

Source

Click or tap the drop-down button of **Source** to select CH1~CH8 or Ref1~Ref10. When a source channel is selected, the selected channel automatically switches to the ON state.

TIP

In addition to CH1~CH8 and Ref1~Ref10, the available sources for Math2 also include Math1; the sources for Math3 also include Math1 and Math2; the sources for Math4 also include Math1, Math2, and Math3. The selected Math channel and operation status will automatically be enabled.

Frequency Limit

- **LowPass:** click or tap the input field of **ωc** and use the pop-up numeric keypad to set the upper frequency limit or use the specified multifunction knob to set the value.
- **HighPass:** click or tap the input field of **ωc** and use the pop-up numeric keypad to set the lower frequency limit or use the specified multifunction knob to set the value.
- **BandPass:** click or tap the input field of **ωc1** and use the pop-up numeric keypad to set the lower frequency limit. Click or tap the input field of **ωc2** and

use the pop-up numeric keypad to set the upper frequency limit. You can also use the specified multifunction knob to set the value.

- **BandStop:** click or tap the input field of **ωc1** and use the pop-up numeric keypad to set the lower frequency limit. Click or tap the input field of **ωc2** and use the pop-up numeric keypad to set the upper frequency limit. You can also use the specified multifunction knob to set the value.

The settable ranges of the upper and lower limit of frequencies are related to the Math sample rate (displayed at the bottom of the screen when the Math function is enabled). The sample rate of the analog channel or the changes of the memory depth can affect the Math sample rate.

9.6 Parameter Settings of the Math Operation Result

After configuring the operator and source, you can adjust the math operation result waveforms with the following methods to get better view effects.

Display Area

Sets where the math operation result is displayed.

- **Math:** By default, the waveforms of math operation are displayed in the math operation result window.
- **Main:** displays the math operation result waveforms in the waveform view.

Scale

Sets the vertical scale of the math operation result window. To set the vertical scale, perform the following operations:

- In the "Math" menu, rotate the specified front-panel multifunction knob indicated in the input field of **Scale** or click/tap the icon at the right side of the input field of **Scale** to increase or decrease the vertical scale. You can also click or tap the input field of Scale to input a specific value with the pop-up numeric keypad.
- When you close the Math menu, you can use the pinch & stretch gesture to adjust the vertical scale. You can also use the multifunction knob to adjust the value.

Offset

Sets the vertical offset of the operation result window. To set the vertical offset, perform the following operations:

- In the "Math" menu, rotate the specified front-panel multifunction knob indicated in the input field of **Offset** or click/tap the icon at the right side of the input field of **Offset** to increase or decrease the vertical offset. You can also click

or tap the input field of **Offset** to input a specific value with the pop-up numeric keypad.

- When you close the Math menu, you can use the drag gesture to adjust the vertical offset. To use the multifunction knob to adjust the value, you should move the cursor to the input field before you close the menu, then the specified knob appears so that you can use the specified knob to adjust the value.

Auto Setting

Click or tap **Auto Setting**, and then the vertical scale and offset of the math operation result window will be automatically adjusted to optimal values based on the current configurations, so that users can get a better observation of the results.

Invert

Sets to enable or disable the inverted display of the waveform. For setting methods, refer to descriptions in *Waveform Invert*.

FFT operation does not support Invert.

Waveform

Sets the time base region of the math operation waveform.

- **Main:** the waveform is within the main time base region. By default, it is Main.
- **Zoom:** the waveform is within the zoomed time base region.

When you select "Zoom", you need to enable *Zoom Mode (Delayed Sweep)* in *Horizontal System*.

FFT does not support zoom region display.

Vertical Expansion

Sets the vertical expansion of the math operation result window.

- **GND:** when the vertical scale is changed, the math operation waveform will be expanded or compressed around the signal ground level position.
- **Center:** when the vertical scale is changed, the math operation waveform will be expanded or compressed around the screen center.

FFT does not support Center expansion.

Label

Sets whether to enable or disable the display of the math operation label of the waveform. For setting methods, refer to descriptions in *Channel Label*.

Grid

When the Display Area is set to "Math", you can set the screen grid. For setting methods, refer to *To Set the Screen Grid*.

10 Measurements

This series oscilloscope provides the quick measurements after "Auto" is selected, auto measurements for 41 waveform parameters, as well as the cursor measurement function.

10.1 Measurement Parameter

This oscilloscope supports the measurement of 41 waveform parameters, including time parameters, count values, delay and phase parameters, voltage parameters and other parameters.

10.1.1 Time Parameters




Figure 10.1 Time Parameters

- **Period:** defined as the time between the middle threshold points of two consecutive, like-polarity edges.
- **Frequency:** defined as the reciprocal of period.
- **Rise Time:** indicates the time for the signal amplitude to rise from the threshold lower limit to the threshold upper limit.
- **Fall Time:** indicates the time for the signal amplitude to rise from the threshold upper limit to the threshold lower limit.
- **+Width:** indicates the time between the threshold middle value of a rising edge to the threshold middle value of the next falling edge.
- **-Width:** indicates the time between the threshold middle value of a falling edge to the threshold middle value of the next rising edge.

- **+Duty:** indicates the ratio of the positive pulse width to the period.
- **-Duty:** indicates the ratio of the negative pulse width to the period.
- **Tvmax:** indicates the time that corresponds to the maximum value of the waveform (Vmax).
- **Tvmin:** indicates the time that corresponds to the minimum value of the waveform (Vmin).


The default values for threshold upper limit, threshold middle value, and threshold lower limit are 90%, 50%, and 10%, respectively.

10.1.2 Count Values

The default values for threshold upper limit and threshold lower limit are 90% and 10%, respectively.


Positive Pulse Count

It is specified as the number of positive pulses that rise from under the threshold lower limit to above the threshold upper limit.




Negative Pulse Count

It is specified as the number of negative pulses that fall from above the threshold upper limit to below the threshold lower limit.




Rising Edge Count

It is specified as the number of rising edges that rise from under the threshold lower limit to above the threshold upper limit.



Falling Edge Count

It is specified as the number of falling edges that fall from above the threshold upper limit to below the threshold lower limit.



10.1.3 Delay and Phase Parameters




Figure 10.2 Delay and Phase Parameters

1. **Delay(r-r):** indicates the time difference between the threshold middle values of the rising edge of Source A and that of Source B. Negative delay indicates that the rising edge of Source A occurred after that of Source B.
2. **Delay(f-f):** indicates the time difference between the threshold middle values of the falling edge of Source A and that of Source B. Negative delay indicates that the falling edge of Source A occurred after that of Source B.
3. **Delay(r-f):** indicates the time difference between the threshold middle values of the rising edge of Source A and the falling edge of Source B. Negative delay indicates that the rising edge of Source A occurred after the falling edge of Source B.
4. **Delay(f-r):** indicates the time difference between the threshold middle values of the falling edge of Source A and the rising edge of Source B. Negative delay indicates that the falling edge of Source A occurred after the rising edge of Source B.
5. **Phase(r-r):** indicates the phase deviation between the threshold middle values of the rising edge of Source A and that of Source B. The phase formula is as follows:

$$PhaseA_{RB_R} = \frac{DelayA_{RB_R}}{Period_{sourceA}} \times 360^\circ$$

Wherein, $PhaseA_{RB_R}$ represents Phase(r-r), $DelayA_{RB_R}$ represents Delay(r-r), and $Period_{sourceA}$ represents the period of Source A.

6. **Phase(f-f):** indicates the phase deviation between the threshold middle values of the falling edge of Source A and that of Source B. The phase formula is as follows:

$$PhaseA_{FB_F} = \frac{DelayA_{FB_F}}{Period_{sourceA}} \times 360^\circ$$

Wherein, $PhaseA_F B_F$ represents Phase (f-f), $DelayA_F B_F$ represents Delay(f-f), and $Period_{sourceA}$ represents the period of Source A.

- 7. Phase(r-f):** indicates the phase deviation between the threshold middle values of the rising edge of Source A and the falling edge of Source B. The phase formula is as follows:

$$PhaseA_R B_F = \frac{DelayA_R B_F}{Period_{sourceA}} \times 360^\circ$$

Wherein, $PhaseA_R B_R$ represents Phase (r-r), $DelayA_R B_R$ represents Delay(r-r), and $Period_{sourceA}$ represents the period of Source A.

- 8. Phase(f-r):** indicates the phase deviation between the threshold middle values of the falling edge of Source A and the rising edge of Source B. The phase formula is as follows:

$$PhaseA_F B_R = \frac{DelayA_F B_R}{Period_{sourceA}} \times 360^\circ$$

Wherein, $PhaseA_F B_R$ represents Phase (f-r), $DelayA_F B_R$ represents Delay(f-r), and $Period_{sourceA}$ represents the period of Source A.



TIP

- Source A and Source B can be any analog channels and Math1~Math4.
- The default threshold middle value is 50%.

10.1.4 Voltage Parameters




Figure 10.3 Voltage Parameters

1. **Vmax:** indicates the voltage value from the highest point of the waveform to the GND.
2. **Vmin:** indicates the voltage value from the lowest point of the waveform to the GND.
3. **Vpp:** indicates the voltage value from the highest point to the lowest point of the waveform.
4. **Vtop:** indicates the voltage value from the flat top of the waveform to the GND.
5. **Vbase:** indicates the voltage value from the flat base of the waveform to the GND.
6. **Vamp:** indicates the voltage value from the top of the waveform to the base of the waveform.
7. **Vupper:** indicates the actual voltage value that corresponds to the threshold maximum value.
8. **Vmid:** indicates the actual voltage value that corresponds to the threshold middle value.
9. **Vlower:** indicates the actual voltage value that corresponds to the threshold minimum value.
10. **Vavg:** indicates the arithmetic average value on the whole waveform or in the gating area. The formula is shown as follows:

$$Average = \frac{\sum_{i=1}^n x_i}{n}$$

Wherein, x_i is the i th point, and n is the number of points being measured.

11. **VRMS:** indicates the root mean square value on the whole waveform or in the gating area. The formula is as follows:

$$RMS = \sqrt{\frac{\sum_{i=1}^n x_i^2}{n}}$$

Wherein, x_i is the measurement result of the i th point, and n is the number of points being measured.

12. **Per.VRMS:** indicates the root mean square value within a period. The formula is as shown above.
13. **Overshoot:** indicates the ratio of the difference between the maximum value and the top value of the waveform to the amplitude value.
14. **Preshoot:** indicates the ratio of the difference between the minimum value and the base value of the waveform to the amplitude value.

- 15. AC RMS:** indicates the root-mean-square value of the waveforms, with the DC component removed. The formula is shown as follows:

$$\text{Std.Dev} = \sqrt{\frac{\sum_{i=1}^n (x_i - \text{Average})^2}{n}}$$

Wherein, x_i is the amplitude of the i th point, *Average* is the waveform average value, and n is the number of points being measured.

10.1.5 Other Parameters

- **Positive Slew Rate:** On the rising edge, first calculate the difference between the high value and the low value, then use the difference to divide the corresponding time value to obtain the positive slew rate.
- **Negative Slew Rate:** On the falling edge, first calculate the difference between the low value and the high value, then use the difference to divide the corresponding time value to obtain the negative slew rate.
- **Area:** indicates the area of the whole waveform within the screen. The unit is V*s. The area of the waveform above the zero reference (namely the vertical offset) is positive, and the area of the waveform below the zero reference is negative. The area measured is the algebraic sum of the area of the whole waveform within the screen.
- **Period Area:** indicates the area of the first period of waveform on the screen. The unit is V*s. The area of the waveform above the zero reference (namely the vertical offset) is positive, and the area of the waveform below the zero reference is negative. The area measured is the algebraic sum of the whole period area.

10.2 To Select the Measurement Item

In the **Measure** menu, click or tap **Horizontal**, **Vertical**, or **Other** to go to the desired menu. You can also slide to select the measurement item to enter the corresponding interface. Click or tap any of the measurement items to enable the measurements. This series oscilloscope allows you to enable measurements of up to 14 items at the same time.



TIP

You can also refer to *Multi-pane Windowing* to enable all measurements.

- **Vertical:** Vmax, Vmin, Vpp, Vtop, Vbase, Vamp, Vupper, Vmid, Vlower, Vavg, VRMS, Per. VRMS, Overshoot, Preshoot, Area, Per.Area, and AC.RMS.

- **Horizontal:** Period, Frequency, Rise Time, Fall Time, +Width, -Width, +Duty, -Duty, Positive Pulse Count, Negative Pulse Count, Rising Edge Count, Falling Edge Count, Tvmax, Tvmin, +Slew Rate, and -Slew Rate.
- **Other:** Delay (r-r), Delay (r-f), Delay (f-r), Delay (f-f), Phase (r-r), Phase (r-f), Phase(f-r), and Phase (f-f).

After selecting the specified measurement item, the "Result" sidebar on the right side of the screen displays the measurement results of the specified measurement item. You can click or tap the measurement results of the specified item, then its sub-menus are displayed. You can perform relevant settings, such as setting the measurement parameters and removing the measurement results.

10.3 Measurement Settings

You can enter the measurement setting menu in the following ways:

- In the **Measure** menu, click or tap the **Setting** button to enter the measurement setting menu.
- Click or tap the measurement results labels on the "Result" sidebar on the right side of the screen and then select **Setting** in the pop-up window.




Figure 10.4 Measurement Settings Menu

Histogram

When completing the measurement of specified parameters, you can view the data distribution of measurement results through the "Histogram" function.

Click or tap the ON/OFF tab for **Histogram** to enable (**ON**) or disable (**OFF**) the histogram function.

When the histogram function is enabled, the histogram window opens and displays the histogram waveform, and the measurement histogram label is displayed in the **Result** sidebar on the right side of the screen. The histogram measurement results include the following parameters.

- Type: indicates the measurement items.
- Sum: indicates the sum of all bins (buckets) in the histogram.
- Peaks: indicates the maximum number of hits in any single bin.
- Max: indicates the value that corresponds to the maximum bin that has any hits.
- Min: indicates the value that corresponds to the minimum bin that has any hits.
- Pk_Pk: indicates the Delta between the max. value and the min. value.
- Mean: indicates the average value of the histogram.
- Median: indicates the median value of the histogram.
- Mode: indicates the mode value of the histogram.
- Bin width: indicates the width of each bin (bucket) in the histogram.
- Sigma: indicates the standard deviation of the histogram.
- XScale: indicates the horizontal scale of the histogram. It is 100 times the value of Bin width.

Indicator

Click or tap the ON/OFF tab for **Indicator** to enable (**ON**) or disable (**OFF**) the indicator function.

If enabled, one or more cursors will be displayed on the screen. Before enabling the indicator, you need to enable at least one auto measurement parameter and the number of cursors will change with the measurement parameter enabled.

TIP

When no measurement parameter is selected or there is no source input, the indicator is not available. The indicator changes when the waveform is expanded or compressed horizontally.



Measurement Threshold

- First, select **%** or **Abs** as the display type.
- Click or tap the drop-down button of **Source** to select the desired channel. You can select from analog channel or Math1 to Math4.



NOTE

For the supported channels of each model, refer to *Content Conventions in this Manual*.

- Click or tap the input field of **Upper** and use the pop-up numeric keypad to set the upper limit of the measurement or use the corresponding multifunction knob to set the value. When the upper limit is set to be smaller than or equal to the current middle value, a prompt message "Set at lower limit" is displayed. Then, the oscilloscope will automatically adjust the upper limit and make it greater than the middle value. By default, it is 90%. The default absolute value varies with the vertical setting of the channel.
- Click or tap the input field of **Mid** and use the pop-up numeric keypad to set the middle value of the measurement or use the corresponding multifunction knob to set the value. The middle value is limited by the settings of the upper limit and lower limit. By default, it is 50%. The default absolute value varies with the vertical setting of the channel.
- Click or tap the input field of **Lower** and use the pop-up numeric keypad to set the lower limit of the measurement or use the corresponding multifunction knob to set the value. When the lower limit is set to be greater than or equal to the current middle value, a prompt message "Set at upper limit" is displayed. Then, the oscilloscope will automatically adjust the lower limit and make it smaller than the middle value. By default, it is 10%. The default absolute value varies with the vertical setting of the channel.
- Click or tap **Default** to return the upper, middle, and lower limits to their default values.

Click or tap the ON/OFF tab for **Threshold** to enable or disable the threshold settings.



TIP

Modifying the threshold will affect the measurement results of time, delay, and phase parameters.

Measurement Range

Click or tap the drop-down button of the **Region** to select "Main" or "Zoom".

- **Main:** indicates that the measurement range is within the main time base region.
- **Zoom:** indicates that the measurement range is within the zoomed time base region.


To use "Zoom", you need to enable the *Zoom Mode (Delayed Sweep)* first.

- **Cursor:** When **CursorAB** is set to ON, the two cursors will be displayed on the screen. At this time, click or tap the input field of **CursorA** and **CursorB** respectively and use the pop-up numeric keypad to modify the cursor position and determine the measurement range.



Amplitude Measurement Method

Click or tap **Auto** or **Manual** as the amplitude measurement method, which affects the measurement method for the top and base values.



If you select "Manual", set the following parameters:

- Click or tap the **Top** toggle button to select **Histogram** or **Max-Min** as the top value measurement method.
- Click or tap the **Base** toggle button to select **Histogram** or **Max-Min** as the base value measurement method.



TIP

If you select "Manual" for the amplitude method, the measurement results of other parameters may be affected.

"Histogram" and "Max-Min" are the internal measurement algorithm for the oscilloscope.

10.4 Statistics of Measurement Results

In the measurement setting interface, you can set where to display the statistics of the measurement results. You can select to display the statistics at the bottom of the screen, at the right section of the screen, or display them both at the bottom of the screen and at the right section of the screen.



Figure 10.5 Display Statistics at the Right Section of the Screen

Display Result Statistics of All Measurement Items

In the result list at the right section of the screen, click or tap  at the lower-right part of the displayed measurement item to unfold all the statistical results of the specified measurement item. Click or tap  to fold all the displayed statistical results of the specified measurement item, with only the current value being displayed.

In the setting menu of the specified measurement item, click or tap the ON/OFF tab for **Statistic** to display all statistical results or only the current value of the specified measurement item in the result list.

Set the Measurement Count

In the measurement setting menu, click or tap the input field of **Count** to set the statistical count of with the pop-up virtual numeric keypad. You can also rotate the specified knob indicated in the input field to set it. Its range is from 2 to 100,000. Its default value is 1,000.

Reset the Statistics of the Measurement Results

In the result list at the right section of the screen, click or tap any measurement item, then the sub-menus are displayed. Click or tap **Reset Stat.** to clear the history statistics of all the measurement values, then make statistics again. You can also click or tap **Reset Stat.** in the measurement setting menu to reset statistics.

10.5 To Remove the Measurement Results

After completing the measurement, you can remove the specified measurement item or remove all the measurement items.

Remove the Specified Measurement Item

- In the **Setting** menu of the specified measurement item, click or tap **Remove** to remove the current measurement item.
- Click or tap the specified measurement item result list. Then the sub-menu is displayed. Click or tap **Remove** to remove the current measurement item.
- Click or tap to drag the specified measurement item result list to the right to remove it quickly.

Remove All Measurement Items

- In the **Setting** menu, click or tap **Remove All** to remove all of the measurement items.
- Click or tap any measurement item shown in the result list. Then the sub-menu is displayed. Click or tap **Remove All** to remove results of all the measurement items.

10.6 Auto Measurement

When the oscilloscope is properly connected and received a valid signal, click or tap the function navigation icon  at the lower-left corner of the screen to select the **Auto** icon to enable the waveform auto setting function and open the auto setting function menu. You can also press  on the front panel to enable the waveform auto setting and open the auto setting interface.



- Click or tap the first icon, and then signal in two periods is displayed automatically on the screen. Meanwhile, the system will make measurements for the "period" and "frequency" of the currently displayed waveforms. The measurement results are displayed at the right side of the screen under the "Result" list.
- Click or tap the second icon, and then multiple periods of the signal are displayed automatically on the screen. Meanwhile, the system will make measurements for the "period" and "frequency" of the currently displayed waveforms in a multiple periods. The measurement results are displayed at the right side of the screen under the "Result" list.
- Click or tap the third icon, and then "rise time" measurement item is enabled. Its measurement results are displayed at the right side of the screen under the "Result" list. By default, it is intended for the fast edge signal.

- Click or tap the fourth icon, and then "fall time" measurement item is enabled. Its measurement results are displayed at the right side of the screen under the "Result" list. By default, it is intended for the fast edge signal.
- Click or tap the fifth icon to cancel the auto setting and recovers to the parameter settings prior to pressing the **Auto** key.
- Click or tap the sixth icon to enter the **Auto Config** sub-menu under the **Utility** menu. For details on how to operate this menu, please refer to *Auto Config*.



TIP

The waveform auto setting function requires that the frequency of the signal should be greater than or equal to 35 Hz, the amplitude greater than or equal to 10 mV. If not meeting the conditions, the waveform auto setting function may be invalid.

10.7 Cursor Measurements

Cursor measurement can measure the X axis values (e.g. Time) and Y axis values (e.g. Voltage) of the selected waveform. Before making cursor measurements, connect the signal to the oscilloscope to acquire stable display. The cursor measurement function provides the following two cursors.




Figure 10.6 Cursors

- X Cursor**

X cursor is a vertical solid/dotted line that is used to make horizontal adjustments. It can be used to measure time (s) and frequency (Hz).

- Cursor A is a vertical solid line (AX is displayed at the bottom of the screen), and Cursor B is a vertical dotted line (BX is displayed at the bottom of the screen).

- In the XY cursor mode, X cursor is used to measure the waveform amplitude of Source X.
- **Y Cursor**
Y cursor is a horizontal solid/dotted line that is used to make vertical adjustments. It can be used to measure amplitude (the unit is the same as that of the source channel amplitude).
 - Cursor A is a horizontal solid line ( is displayed at the right section of the screen), and Cursor B is a horizontal dotted line ( is displayed at the right section of the screen).
 - In XY cursor mode, Y cursor is used to measure the waveform amplitude of Source Y.

You can enable cursor measurements in the following ways.

- Click or tap the function navigation icon  > **Cursors** to enable cursor measurements.
- Click or tap the **Cursors** button on the toolbar to enable cursor measurements.
- Press the front-panel  key to enable cursor measurements.

The measurement results are displayed in the "Result" bar at the right side of the screen.



- AX: indicates the X value at Cursor A.
- AY: indicates the Y value at Cursor A.
- BX: indicates the X value at Cursor B.
- BY: indicates the Y value at Cursor B.
- ΔX: indicates the horizontal spacing between Cursor A and Cursor B.
- ΔY: indicates the vertical spacing between Cursor A and Cursor B.

- $1/\Delta X$: indicates the reciprocal of the horizontal spacing between Cursor A and Cursor B.

Click or tap the result bar and then select **Remove** or **Setting** in the pop-up window.

- Click or tap **Remove**. Then the current cursor measurement results will be cleared.
- Click or tap **Setting**. Then the "Cursors" menu is displayed. You can select the cursor mode: Manual, Track, and XY.

10.7.1 Manual Mode

In the manual cursor mode, you can adjust the cursor manually to measure the value of the waveforms of the specified source at the current cursor. If the settings for the parameter such as the cursor type and measurement source are different, the measurement results will be different for cursor measurement.

In the **Cursors** menu, click or tap **Manual** for the **Mode** item to enable the Manual cursor measurement. The measurement results are displayed in the Result list at the right side of the screen. When you change the cursor position, the measurement results will be changed accordingly.




Figure 10.7 Manual Mode Setting Menu

Select the Measurement Source

Click or tap the drop-down button of **Source** to select the desired channel (None, CH1~CH8, or Math1-Math4).

When a specified channel is selected as the source, it will be automatically turned on.

Select Cursor Type

Click or tap the **Select** toggle button to select "X" or "Y".

- **X:** It is a pair of vertical solid (Cursor A)/dotted (Cursor B) lines, used for measuring time parameters. The measurement results include AX, BX, ΔX , and $1/\Delta X$.
- **Y:** It is a pair of horizontal solid (Cursor A)/dotted (Cursor B) lines, used for measuring voltage parameters. The measurement results include AY, BY, and ΔY .

Adjust Cursor Position

1. When "X" is selected, you can adjust the position of X cursor.

- Click or tap the input field of **AX** and use the pop-up numeric keypad to set the horizontal position of Cursor A (X cursors). The horizontal axis indicates time, and the unit of its setting value is the same as that of the horizontal unit. Its adjustable range is limited within the screen.
- Click or tap the input field of **BX** and use the pop-up numeric keypad to set the horizontal position of Cursor B (X cursors). The horizontal axis indicates time, and the unit of its setting value is the same as that of the horizontal unit. Its adjustable range is limited within the screen.
- Click or tap the ON/OFF tab for **AX BX** to enable or disable adjusting the horizontal position of Cursor A and Cursor B (X cursors) simultaneously. The horizontal spacing between Cursor A and Cursor B (X cursors) remains unchanged.

2. When "Y" is selected, you can adjust the position of Y cursor.

- Click or tap the input field of **AY** and then use the pop-up numeric keypad to set the vertical position of Cursor A (Y cursors). The vertical axis indicates voltage, and the unit of its setting value is the same as that of the vertical unit.
- Click or tap the input field of **BY** and use the pop-up numeric keypad to set the vertical position of Cursor B (Y cursor). The vertical axis indicates voltage, and the unit of its setting value is the same as that of the vertical unit.
- Click or tap the ON/OFF tab for **AY BY** to enable or disable adjusting the vertical position of Cursor A and Cursor B (Y cursors) simultaneously. The vertical spacing between Cursor A and Cursor B (Y cursors) remains unchanged.

You can also use the specified multifunction knob to adjust the cursor position.

Measurement Example

Measure the period of a sine wave by using the manual cursor measurement and auto measurement respectively. The measurement results are both 8 μs .




Figure 10.8 Manual Cursor Measurement Example

10.7.2 Track Mode

In the Track mode, you can adjust the two pairs of cursors (Cursor A and Cursor B) to measure the X and Y values on two different sources respectively. When the cursors are moved horizontally/vertically, the markers will position on the waveform automatically. When the waveform is expanded or compressed horizontally/vertically, the markers will track the points being marked at the last adjustment of the cursors.

In the **Cursors** menu, click or tap **Track** for the **Mode** item to enable the Track cursor measurement function. The measurement results are displayed in the "Result" list at the right section of the screen.




Figure 10.9 Track Mode Setting Menu

Select the Measurement Source

- Click or tap the drop-down button of **Source A** to select the desired channel (None, CH1~CH8, or Math1~Math4).
- Click or tap the drop-down button of **Source B** to select the desired channel (None, CH1~CH8, or Math1~Math4).

If the specified channel is selected as the source, the channel will be enabled automatically.

Select the Track Mode

Click or tap to select "X" or "Y" under **Track** as the current track axis. By default, it is "X".

- **X:** When you adjust the X cursor position, Y cursors will automatically track the intersection point between X cursor and source signal.
- **Y:** When you adjust the Y cursor position, X cursors will automatically track the intersection point between Y cursor and source signal.

Adjust the Cursor Position

- When "X" is selected, you can adjust the position of X cursor.
 - Click or tap the input field of **AX** and use the pop-up numeric keypad to set the horizontal position of Cursor A (X cursors). Its adjustable range is limited within the screen.
 - Click or tap the input field of **BX** and use the pop-up numeric keypad to set the horizontal position of Cursor B (X cursors). Its adjustable range is limited within the screen.

- Click or tap the ON/OFF tab for **AX BX** to enable or disable adjusting the horizontal position of Cursor A and Cursor B (X cursors) simultaneously. The horizontal spacing between Cursor A and Cursor B (X cursors) remains unchanged.
- When "Y" is selected, you can adjust the position of Y cursor.
 - Click or tap the input field of **AY**, and then use the pop-up numeric keypad to set the vertical position of Cursor A (Y cursors).
 - Click or tap the input field of **BY** and use the pop-up numeric keypad to set the vertical position of Cursor B (Y cursors).
 - Click or tap the ON/OFF tab for **AY BY** to enable or disable adjusting the vertical position of Cursor A and Cursor B (Y cursors) simultaneously. The vertical spacing between Cursor A and Cursor B (Y cursors) remains unchanged.

You can also use the specified multifunction knob to adjust the cursor position.

Measurement Example

Set **Source A** to CH1, **Source B** to CH2, and **Track** to "X".

When the AX cursor position is adjusted, AY cursor will automatically track the intersection point between AX cursor and source signal (CH1); When the BX cursor position is adjusted, BY cursor will automatically track the intersection point between BX cursor and source signal (CH2). The measurement results are displayed in the Result list, as shown in *Figure 10.10*. Then, expand the waveforms horizontally, and you will find that the cursor will track the point that has been marked, as shown in *Figure 10.11*.




Figure 10.10 Track Measurement (before Horizontal Expansion)




Figure 10.11 Track Measurement (after Horizontal Expansion)

10.7.3 XY Mode

In the **Cursors** menu, click or tap **XY** for **Mode** to enable the XY cursor measurement. The measurement results are displayed in the Result list at the right side of the screen.




Figure 10.12 XY Mode Setting Menu



TIP

By default, XY mode is unavailable. It is available only when the horizontal time base mode is "XY". To enable the XY mode, please refer to *XY Mode*.

Adjust Cursor Position

- Click or tap to select the "X" tab under the **Select** menu item to select X cursors.
 - Click or tap the input field of **AX** and use the pop-up numeric keypad to set the X value at Cursor A.

- Click or tap the input field of **BX** and use the pop-up numeric keypad to set the X value at Cursor B.
- Click or tap the ON/OFF tab for **AX BX** to enable or disable adjusting the X value at Cursor A and the X value at Cursor B simultaneously.
- Click or tap to select "Y" under the **Select** item to select Y cursors.
 - Click or tap the input field of **AY** and use the pop-up numeric keypad to set the Y value at Cursor A.
 - Click or tap the input field of **BY** and use the pop-up numeric keypad to set the Y value at Cursor B.
 - Click or tap the ON/OFF tab for **AY BY** to enable or disable adjusting the Y value at Cursor A and the Y value at Cursor B simultaneously.

You can also use the specified multifunction knob to adjust the cursor position.

11 Digital Voltmeter (DVM) and Frequency Counter


This series oscilloscope provides a built-in digital voltmeter (DVM) and frequency counter, which enable you to perform more accurate measurements, improving user experience in counter and frequency measurement.

11.1 Digital Voltmeter (DVM)

The built-in DVM of this series oscilloscope provides 4-digit voltage measurements on any analog channel. DVM measurements are asynchronous from the oscilloscope's acquisition system and are always acquiring. To enable the DVM measurement, perform the following operations:

- Click or tap the function navigation icon  > **DVM** to enable DVM measurements.
- Click or tap the **DVM** button on the toolbar to enable DVM measurements.
- Press the front-panel  key and then select **DVM** in the displayed "Analyse" menu to enable the DVM measurements.

After the DVM measurement is enabled, the "DVM" label displaying the current voltage value and voltage mode appears in the "Result" list at the right section of the screen, as shown in the figure below.



The voltage value above shows the measurement extrema over the last 3 seconds.

Click or tap the "DVM" label and then a window is displayed. Click or tap **Setting** to enter the DVM setting menu. Click or tap **Remove** to remove the DVM measurement results and exit the DVM measurement.

11.1.1 Measurement Settings

After the DVM measurement is enabled, the DVM result list is displayed at the right section of the screen. Click or tap the result list, the sub-menus are displayed. Click or tap **Setting** to enter the DVM setting menu.




Figure 11.1 DVM Setting Menu

Select the Measurement Source

Click or tap the drop-down button of **Source** to select the desired source from the drop-down list. The analog channel (CH1 to CH8) can be selected to be the measurement source.

Even if the analog channel (CH1 to CH8) is not enabled, you can still perform the DVM measurement.

Select the Measurement Mode

In the **Mode** item, you can select the DVM mode. The DVM measurement modes include AC RMS, DC, and AC+DC RMS.

- AC RMS: displays the root-mean-square value of the acquired data, with the DC component removed.
- DC: displays the average value of the acquired data.
- AC+DC RMS: displays the root-mean-square value of the acquired data.

Set the Limits

Click or tap the ON/OFF tab for **Beeper** to enable or disable the beeper. When enabled, you can set when ("In Limits" or "Out Limits") to sound an alarm.

- Limits Condition Setting

Click or tap to select "In Limits" or "Out Limits" under **When**.

- In Limits: when the voltage value is within the limits, you can enable or disable the beeper to sound an alarm.

- Out Limits: when the voltage value is outside of the limits, you can enable or disable the beeper to sound an alarm.
- Upper/Lower Limit Setting

Click or tap the input field of **Upper**, then use the pop-up numeric keypad to set the upper limit of the voltage or use the specified multifunction knob to set the value.

Click or tap the input field of **Lower**, and then use the pop-up numeric keypad to set the lower limit of the voltage or use the specified multifunction knob to set the value.

The available range of the upper limit is from 1 nV to 500 V. By default, it is 1 V. The available range of the lower limit is from -500 V to 990.00 mV. By default, it is 0 V.

11.1.2 To Remove the Measurement

Click or tap the DVM label in the result list, then the sub-menus are displayed. Click or tap **Remove** to remove the measurement results and exit the DVM measurement. You can also click or tap **Remove** in the DVM setting menu to remove the measurement results.


11.2 Frequency Counter

The frequency counter analysis function provides frequency, period, or edge event counter measurements on any analog channel.

You can enable the counter in the following ways:

- Click or tap  > **Counter** to enable the counter.
- Click or tap the **Counter** button on the toolbar to enable the counter.
- Press the front-panel  key and then select **Counter** in the displayed "Analyse" menu to enable the counter.

After the counter is enabled, the "Counter" label displaying the counter measurement results appears in the "Result" bar at the right section of the screen, as shown in the figure below.



You can click or tap the "Counter" label in the "Result" bar and select **Reset Stat**, **Setting**, or **Remove** in the displayed window.

11.2.1 Measurement Settings

After the frequency counter is enabled, the frequency counter result list is displayed at the right section of the screen. Click or tap the result list, and then select **Setting**. Then the frequency counter interface is displayed.




Figure 11.2 Frequency Counter Setting Menu

Select the Measurement Source

Click or tap the drop-down button of **Source** to select the desired source from the drop-down list. Analog channels, digital channels, and EXT can all be selected as the source of the frequency counter.



NOTE

For the channel sources supported by different models, refer to *Content Conventions in this Manual*

Select the Measurement Item

In the **Measure** item, you can select the desired measurement item. Available options include Frequency, Period, and Totalize. Wherein, Totalize indicates the count of edge events on the signal.

Set Resolution

For Period and Frequency measurements, you need to set the readout resolution. Click or tap the input field of **Resolution** to set the resolution by using the pop-up numeric keypad. You can also use the corresponding multifunction knob to set the value. The range of resolution is from 3 bits to 6 bits. By default, it is 4 bits.

The greater the resolution, the longer the gate time. In this way, the measurement time will be longer.

Clear Count

When "Totalize" is selected as the measurement item, the oscilloscope measures the count of edge events on the signal. At this time, click or tap **Clear Count** to clear the measurement results and start the measurements again.

Disable the Frequency Counter

After completing the measurement, click or tap **Remove** in the frequency counter setting interface to disable the frequency counter. All the frequency counter menu and statistics results are closed.

You can also click or tap the result list, then click or tap **Remove** from the displayed sub-menus to clear the measurement result. The frequency counter result list disappears.

11.2.2 To Reset Statistics

Statistics Results

In the Counter setting menu, click or tap the ON/OFF tab for **Statistic** to enable or disable the display of the counter statistics. When enabled, all the statistical results will be displayed in the "Counter" result list.

Reset Statistics

Click or tap **Reset Stat.** in the Counter setting interface to reset the statistics of the counter measurement results. You can also click or tap the Counter result list first. Then the sub-menus are displayed. Click or tap **Reset Stat.** to reset the statistics of the counter measurement results.

12 Digital Channels (Available Only for MHO Series)

Only the MHO series oscilloscope provides the standard configuration of the logic analyzer (LA) function. The MHO series has 16 digital channels, with D3-D0 as one group, D7-D4 as one group, D11-D8 as one group, D15-D12 as one group.

The oscilloscope compares the voltages acquired in each sample with the preset logic threshold. If the voltage of the sample point is greater than the threshold, it will be stored as logic 1; otherwise, it will be stored as logic 0. The oscilloscope displays logic levels ("1" and "0") in the form of a graph for you to easily detect and analyze the errors in circuit design (hardware design and software design).

To enter Logic Analyzer (LA) menu, perform one of the following operations:

- Press  on the front panel to enter the LA menu.
- Click or tap the "L" label at the bottom of the screen to enter the logic analyzer (LA) menu.

Before using the digital channels, connect the PLA3204 active logic analyzer probe (option, required to purchase by yourself) to the oscilloscope and the device under test (DUT). For details about how to use the PLA3204 probe, refer to *PLA3204 Active Logic Probe User Guide*.

12.1 Basic Settings

In the **Basic Settings** tab, you can enable or disable the specified digital channel, set the channel label, and set the threshold for the channel.





Figure 12.1 Basic Settings Tab of Logic Analyzer Interface

12.1.1 To Enable or Disable the Digital Channel

The LA function allows you to enable or disable all the channels of the specified group; enable or disable each single digital channel. The digital channel label at the bottom of the screen displays the on/off status of the digital channel. The channels indicated in gray are disabled and those indicated in green are enabled.



Enable or Disable a Single Channel

You can click or tap the **ON/OFF** tab following the specified digital channel to enable or disable any of digital channels (D0-D15).



TIP

When the specified group of digital channels is enabled or disabled, you can still set the on/off status independently for the specified channel in this group.

Enable or Disable the Channels of a Specified Group

In the LA interface, you can enable or disable all the digital channels in the specified group with the global on/off tab for the specified group (**D15-D12**, **D11-D8**, **D7-D4**, or **D3-D0**).

On/Off Control of All Channels

When some digital channels have been enabled and you want to disable all the enabled channels, click to drag the digital channel label downward. You can also drag it downward on the touch screen to disable all the enabled digital channels.

12.1.2 To Set the Label

By default, the instrument takes D0-D15 as the channel label of the 16 digital channels respectively. You can set a user-defined label for each digital channel to differentiate the channel and their input signal.

Enable or Disable the Label Display

Click or tap the ON/OFF tab for the channel label to display or hide the channel label of the specified group channel. If enabled, the labels of the specified channel group will be displayed at the leftmost side of the waveform view.

Use Preset Labels

This oscilloscope presets the common signal type names for the channel label, including ACK, ADO, ADDR, BIT, CAS, CLK, and DATA.

Click or tap the drop-down button of the specified channel label name to select the preset channel label for the channel.

Set the User-defined Label

To set a user-defined label for the channel, click or tap to select **User** from the drop-down list, then you can use the pop-up numeric keypad to set the channel label.

12.1.3 To Select the Digital Channel

When the digital channels are enabled, click or tap the digital channel label or the channel waveforms on the screen to select the specified channel. By default, the waveforms of the digital channels are displayed in green. When you click or tap the specified channel label or waveform of the specified channel, the selected waveform of the channel is displayed in red.



TIP

Only the enabled digital channels can be selected.

12.1.4 To Set the Threshold

The MHO series oscilloscope allows you to set the threshold for each group of digital channels. The threshold levels for the four groups (D15-D12, D11-D8, D7-D4, and D3-D0) of digital channels are set independently. When the voltage of the input signal is greater than the currently set threshold, it is treated as logic 1; otherwise, it is treated as logic 0.

Use the Preset Threshold

To facilitate operation, the system has preset the threshold for the common signals, including TTL(1.4 V), CMOS5.0(2.5 V), CMOS3.3(1.65 V), CMOS2.5(1.25 V), CMOS1.8(0.9 V), ECL(-1.3 V), PECL(3.7 V), and LVDS(1.2 V).

Click or tap the drop-down button of **Thres** to select the desired preset threshold for the channel group.

Set the User-defined Threshold

To set a user-defined threshold for the channel, click or tap the drop-down button of **Thres** to select "User". Then set the threshold with the pop-up numeric keypad. The range of the threshold is from -15 V to 15 V.

12.2 Other Settings

In the **Other Settings** tab, you can set the waveform size of the digital channels, the channel sequence, probe delay, probe calibration, and etc.




Figure 12.2 "Other Settings" Tab of Logic Analyzer Interface

12.2.1 To Set the Waveform Size

This series oscilloscope allows you to set the waveform size for the digital channels. If you need to observe several waveforms of the digital channels, you can set the waveform size to small, medium, and large to make them easy to observe.



TIP

"Large" is only available when the number of currently enabled digital channels is less than or equal to 8.

12.2.2 To Set the Channel Sequence

You can set the waveform sequence for the enabled channels according to your needs.

- D0-D15: the waveforms of D0-D15 are displayed in sequence on the screen in the waveform view.
- D15-D0: the waveforms of D15-D0 are displayed in sequence on the screen in the waveform view.

You can also drag the waveform of the specified digital channel to a specified position to adjust the channel waveform sequence.

12.2.3 Priority of the Waveform Display

When the waveform of the digital channel and that of the analog channel are overlapped, you can enable or disable the priority of the waveforms of the analog channels and the digital channels to be displayed.

- When set to OFF, the waveform of the analog channel is displayed in high priority. The waveforms of the digital channels are overlaid.

- When set to ON, the waveform of the digital channel is displayed in high priority.
The waveforms of the analog channels are overlaid.

12.2.4 To Set the Probe Delay

To avoid measurement result errors arising from the transmission delay of the probe cable, you can set the probe delay on the oscilloscope.

In the LA interface, click or tap the **Other Settings** tab to enter the other settings interface. Click or tap the input field of **Probe Delay** to set the probe delay with the pop-up numeric keypad. Its range is from -200 ns to 200 ns. By default, it is set to 0 s. You can also use the Up/Down arrow to adjust the probe delay. Also, if no probe delay is required, you can directly click or tap 0 to reset it to zero.

13 Histogram Analysis

The histogram analysis function provides you a statistical view of the waveforms or measurement results, enabling you to judge the trend of waveforms, and quickly locate the potential problems of the signal. This series oscilloscope supports horizontal histogram, vertical histogram and and measurement histogram.

Click or tap the function navigation icon  at the lower-left corner of the screen, and then select **Histogram** to enter the histogram setting menu.




Figure 13.1 Histogram Setting Menu

13.1 To Enable or Disable the Histogram

In the "Histogram" setting menu, click or tap the ON/OFF tab for **Enable** to enable or disable the histogram analysis function. When enabled, with the on-going acquisition and measurement of the waveforms, the height of the bar graph of the histogram will change within the set range of the histogram window to indicate the number of times for data statistics.

Here takes the horizontal histogram as an example. When enabled, the histogram is displayed on the screen as shown in the figure below. The histogram result is displayed in the "Result" list at the right section of the screen.




Figure 13.2 Histogram Analysis Interface

When the histogram is enabled, click or tap the histogram result list, the sub-menus of histogram are displayed. Click or tap **Setting** to enter the histogram setting interface.



TIP

For the definitions of the measurement items in the histogram result, refer to *Histogram Analysis Results*.

13.2 To Select the Histogram Type

In the "Histogram" setting menu, click or tap the drop-down button of **Type** to select the histogram type from the drop-down list.

- Horizontal: displays the number of times for statistics making in the forms of columns in the histogram bar graph at the bottom of the graticule.
- Vertical: displays the number of times for statistics making in the forms of rows in the histogram bar graph at the left of the graticule.

13.3 To Select the Histogram Source

In the "Histogram" setting menu, click or tap the drop-down button of **Source** to select the desired source from the drop-down list. All the analog channels can be selected to be the Histogram source.

For the channel sources supported by different models, refer to *Content Conventions in this Manual*.

13.4 To Set the Histogram Height

The histogram height indicates the number of grids that fall into the bar of the histogram graph.

In the histogram setting interface, click or tap the input field of **Height** to set the height of the histogram with the pop-up numeric keypad. The range of the histogram height is from 1 div to 4 div. By default, it is 2 div.

13.5 To Set the Histogram Range

When the histogram type is set to Vertical or Horizontal, you need to set the histogram range. Set "Left Limit", "Right Limit", "Top Limit", and "Bottom Limit" respectively to adjust the size and position of the histogram.

Click or tap the input field of the specified limit to set the limit of the histogram with the pop-up numeric keypad. You can also use the specified knob indicated in the input field of the specified limit to set it. You also directly drag the left, right, top, or bottom edge of the white histogram diagram window to adjust the position and size the histogram.



NOTE

The adjustment for the horizontal time base and vertical scale will not affect the histogram range, but only shows variation with the change of the scale.

13.6 Histogram Analysis Results

When the histogram function is enabled, the histogram result is displayed in the "Result" list at the right section of the screen. The test result includes the following test items:

- Sum: indicates the sum of all bins (buckets) in the histogram.
- Peaks: indicates the maximum number of hits in any single bin.
- Max: indicates the value that corresponds to the maximum bin that has any hits.
- Min: indicates the value that corresponds to the minimum bin that has any hits.
- Pk_Pk: indicates the Delta between the max. value and the min. value.
- Mean: indicates the average value of the histogram.
- Median: indicates the median value of the histogram.
- Mode: indicates the mode value of the histogram.
- Bin width: indicates the width of each bin (bucket) in the histogram.
- Sigma: indicates the standard deviation of the histogram.
- $\mu \pm \sigma$: indicates the proportion of the number of frequencies or counts of the histogram hits that lie within one standard deviation of the mean to the total number of histogram hits. μ indicates the mean value in normal distribution. It is

the average of the numbers. σ indicates the standard deviation in the normal distribution.

- $\mu \pm 2\sigma$: indicates the proportion of the number of frequencies or counts of the histogram hits that lie within two standard deviations of the mean to the total number of histogram hits. μ indicates the mean value in normal distribution. It is the average of the numbers. σ indicates the standard deviation in the normal distribution.
- $\mu \pm 3\sigma$: indicates the proportion of the number of frequencies or counts of the histogram hits that lie within three standard deviations of the mean to the total number of histogram hits. μ indicates the mean value in normal distribution. It is the average of the numbers. σ indicates the standard deviation in the normal distribution.

13.7 To Remove the Measurement

- Click or tap the histogram result list, then the sub-menus of the histogram function are displayed. Click or tap **Remove** to remove the measurement results and close the histogram result list and exit the histogram function.
- Click or tap to drag the result list to the right, then release it to remove the measurement results and exit the histogram function.

13.8 To Clear Statistics

Click or tap the histogram result list, then the sub-menus of the histogram function are displayed. Click or tap **Clear** to clear the statistics.


14 Function/Arbitrary Waveform Generator (Available Only for MHO5054/5104)

With an optional configuration of built-in dual-channel, 50 MHz Function/Arbitrary Waveform Generator, the MHO5054 and MHO5104 series integrates the Function/Arbitrary Waveform Generator and the oscilloscope into one, thus providing great convenience for engineers who need to use the Function/Arbitrary Waveform Generator and oscilloscope at the same time. This chapter introduces how to use the built-in Function/Arbitrary Waveform Generator option.

To enable the AFG function, perform any of the following operations:

- Press **GI** or **GII** on the front panel to enable GI or GII, then enter the specified setting interface.
- Click or tap the GI or GII label at the bottom of the screen to enter the specified AFG setting interface.

The on/off status of the specified AFG channel is indicated in its label color. When enabled, the label is highlighted in orange, with output waveform information on it. When disabled, the label is grayed out.



To disable the AFG function, press **GI** or **GII** on the front panel to disable GI or GII. You can also click or tap the enabled GI or GII label at the bottom of the screen to exit the specified AFG interface. Also, you can drag the label downward to disable the enabled AFG channel and exit the specified AFG interface.

14.1 To Output Basic Waveforms




Figure 14.1 AFG Menu

The front-panel G1 and GII can output different waveform types at the same time. You can set parameters for G1 and GII output channels respectively.

The built-in AFG (G1 and GII) can output various types of waveforms.

- Standard waveforms: Sine, Square, Ramp, Pulse, and Noise
- Built-in waveforms: DC, Sinc, Exp.Rise, Exp.Fall, ECG1, Gauss, Lorentz, and Haversine

After completing the waveform parameter settings, set **Output** to "ON". The waveforms set in the AFG interface can be output from the specified front-panel AFG channel (G1 or GII).

14.1.1 Sine

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "Sine". Then you can set the Sine parameters. At this time, you can set the parameters for the Sine waveform.

Set the Frequency/Period

Click or tap the input field of **Freq/Period** to set the frequency or period of the current Sine signal with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. Different waveforms have different frequency or period (reciprocal of the frequency) ranges.

- Sine: 1 μ Hz to 50 MHz
- Square/Pulse: 1 μ Hz to 30 MHz
- Ramp: 1 μ Hz to 2 MHz
- DC and Noise: no frequency parameter.

Set the Amplitude

Click or tap the input field of **Amp** to set the amplitude of the current Sine signal with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The amplitude range of the Sine waveform is as follows:

- 2 mVpp to 10 Vpp (1 M Ω)
- 1 mVpp to 5 Vpp (50 Ω)

Set the Offset

Click or tap the input field of **Offset** to set the offset of the current Sine signal with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The offset range is from 1 nV to 1 μ V.

- -9 V to 9 V (1 M Ω)
- -4.5 V to 4.5 V (50 Ω)

Set the High/Low Level

In the amplitude and offset setting of the output waveform, you can also click or tap to select **HighL** or **LowL** to set the high level and low level of the output waveforms.

- Amplitude = (High Level - Low Level)/2
- Offset = (High Level + Low Level)/2

The available range of high level is from -2.5 V to +10 V. By default, it is 1 V. The available range of low level is from -10 V to +2.5 V. By default, it is -1 V.

Set the Start Phase

Click or tap the input field of **Phase** to set the start phase with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The available range of start phase is from 0° to 360°. By default, it is 0°.

Align Phase

Click or tap **Align Phase** to re-configure the two channels to output according to the set frequency and phase. If these two signals whose frequencies are identical or in multiple, you can click or tap this menu to align their phases.

Use the oscilloscope to acquire the waveforms of the two channels and stably display the waveforms. After switching the channel status, the phase deviation between the

(Available Only for MHO5054/5104)

two waveforms is changed. At this time, click or tap **Align Phase**, then the phase deviation shown on the oscilloscope will restore to the current phase deviation between the two waveforms automatically.


14.1.2 Square

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "Square". Then you can set the Square parameters. At this time, you can set the parameters for the Square waveform.

Refer to *Sine* to set the frequency, phase, amplitude, and offset parameters. This section will only elaborate on how to set the duty cycle.

Set the Duty Cycle

Duty cycle is defined as the percentage that the high level takes up in the whole period, as shown in the figure below. This parameter is only available when Square is selected.



Click or tap the of input field of **Duty** to set the duty cycle with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The available range of duty cycle is from 1% to 99%. By default, it is 50%.


14.1.3 Ramp

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "Ramp". Then you can set the Ramp parameters. At this time, you can set the parameters for the ramp waveform.

Refer to *Sine* to set the frequency, phase, amplitude, and offset parameters. This section will only elaborate on how to set the symmetry.

Symmetry

Symmetry is defined as the percentage that the rising period of the ramp takes up in the whole period (as shown in the figure below). This parameter is only available when Ramp is selected.




Click or tap the of input field of **Symm** to set the symmetry with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The available range of symmetry is from 0.1% to 99.9%. By default, it is 50%.

14.1.4 Pulse

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "Pulse". Then you can set the Pulse parameters. Refer to *Sine* to set the frequency, phase, amplitude, and offset parameters. For the duty cycle, refer to descriptions in *Square*. This section only elaborates on how to set the rising edge and falling edge.

The rising edge time is defined as the duration of the pulse amplitude rising from 10% to 90% threshold, while falling edge time is defined as the duration of the pulse amplitude moving down from 90% to 10% threshold.



Click or tap the input field of **Rise Edge** to set the pulse rising edge time. Click or tap the input field of **Fall Edge** to set the pulse falling edge time with the pop-up numeric keypad. You also use the specified knob indicated in the input field to set the rising and falling edge time. The rising/falling edge time ranges from 1 ps to 1 s. By default, it is 300 ps.

14.1.5 Noise

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "Noise". Then you can set Noise parameters.

You can click or tap **Amp** to set the amplitude of Noise waveform. Its available range is from 2 mV to 2 V. Click or tap **Offset** to set the offset of the Noise waveform. The range of the offset is related to its amplitude value.

(Available Only for MHO5054/5104)

You can also click or tap to switch to the **HighL** and **LowL** tab to set the high level and low level of the Noise waveform. For details, refer to descriptions in *Sine*.

14.1.6 DC

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "DC". Then you can set the DC parameters.

Click or tap the input field of **Offset** to set the offset of the DC signal with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The available range of offset is from -10 V to 10 V.

14.1.7 Exp.Rise

The Exp.Rise waveform is as shown in the figure below




Figure 14.2 Exp.Rise

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "Exp.Rise". Then set the Exp.Rise parameters. For setting methods, refer to descriptions in *Sine*.

14.1.8 Exp.Fall

The Exp.Fall waveform is as shown in the figure below.




Figure 14.3 Exp.Fall

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "Exp.Fall". Then set the Exp.Fall parameters. For setting methods, refer to descriptions in *Sine*.

14.1.9 ECG1

The ECG1 waveform is as shown in the figure below





Figure 14.4 ECG1

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "ECG1". Then set the ECG1 parameters. For setting methods, refer to descriptions in *Sine*.

14.1.10 Gauss


The Gauss waveform is as shown in the figure below:

**Figure 14.5 Gauss**

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "Gauss". Then set the Gauss parameters. For detailed setting methods, refer to descriptions in *Sine*.

14.1.11 Lorentz

The Lorentz waveform is as shown in the figure below:

**Figure 14.6 Lorentz**

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "Lorentz". Then set the Lorentz parameters. For detailed setting methods, refer to descriptions in *Sine*.

14.1.12 Haversine

The Haversine waveform is as shown in the figure below:



Figure 14.7 Haversine

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "Haversine". Then set the Haversine parameters. For detailed setting methods, refer to descriptions in *Sine*.

14.1.13 Sinc

The Sinc waveform is as shown in the figure below




Figure 14.8 Sinc

In the Basic Waveforms tab, click or tap the drop-down button of **Type** to select "Sinc". Then set the Sinc parameters. For setting methods, refer to descriptions in *Sine*.

14.2 Modulation

Modulation is a process of converting analog or digital signals into high-frequency signals that are suitable for transmission. We called the original signal as the modulating waveform; the high-frequency signal used to carry the modulating signal is called the carrier waveform.

The AFG function supports AM, FM, and PM modulation types. The modulating signal is the built-in waveform of AFG; the carrier waveform signal is the basic waveform output by the AFG.

In the AFG interface (G1 or G2), click or tap the **Modulation** tab to enter the modulation setting menu.




Figure 14.9 Modulation Setting Interface

Please configure the modulation settings according to the following procedures.

1. In the Basic Waveforms tab, click or tap **ON** to enable the output for the specified channel.
2. Click or tap the drop-down button of **Type** to select the desired waveform type.

Then configure the parameter settings for the selected waveform type. For details of the parameter configurations, refer to *To Output Basic Waveforms*. The DC, Noise, and Pulse waveforms are not supported as carrier waveforms. If you select

those waveforms that are not supported as the carrier waveforms, the modulation function is unavailable.

3. Click or tap the drop-down button of **Mod Type** to select the desired modulation type. Then configure the parameter settings for the selected modulation type.
4. Set the **Mod. State** to "ON". The modulated signal can be output from the specified front-panel AFG channel (G1 or G2).

The following section introduces the three modulation types.

14.2.1 AM

AM (Amplitude Modulation), namely the amplitude of the carrier waveform changes with that of the modulating waveform, as shown in the figure below.




Figure 14.10 AM

Select the Modulation Type

Click or tap the drop-down button of **Mod. Type** to select "AM".

Select the Modulating Waveform

The instrument uses the built-in signal to perform waveform modulation. Click or tap the drop-down button of **Waveform** to select the modulating waveform. The available waveform types include:

- Sine
- Square with 50% duty cycle
- Triangle with 50% symmetry

(Available Only for MHO5054/5104)

- UpRamp with 100% symmetry
- DnRamp with 0% symmetry
- Noise - white gaussian noise

Set the Modulation Depth

Modulation depth is a percentage that represents the amplitude variation. Click or tap the input field of **Mod. Depth** to set the modulation depth with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The available range of the modulation depth is from 0% to 120%. By default, it is 100%.

- At 0% depth, the output amplitude is half of the carrier waveform amplitude.
- At 100% depth, the amplitude is identical to the carrier's amplitude setting.
- At >100% depth, the output amplitude of the instrument will not exceed 10 Vpp.

Set the Modulation Frequency

When you select the modulating waveforms other than Noise, you can set the modulation frequency. Click or tap the input field of **Mod. Freq** to set the modulation frequency with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The available range of the AM frequency is from 2 mHz to 1 MHz.

Enable the Modulation Output

Click or tap ON for **Mod. State** to enable the modulation function. In the Basic Waveforms interface, click or tap ON for **Output** to enable the waveform output. Then the modulated waveforms will be output from the specified AFG terminal based on the settings.

DSSC

Click or tap ON for **DSSC** to enable the DSSC function. It can remove the carrier components from the output signal, improve the bandwidth usage, and improve the efficiency of transmission power.

14.2.2 FM

FM (Frequency Modulation), namely the frequency of the carrier waveform changes with the voltage of the modulating waveform.




Figure 14.11 FM

Select the Modulation Type

Click or tap the drop-down button of **Mod. Type** to select "FM".

Select the Modulating Waveform

The instrument uses the built-in signal to perform waveform modulation. Click or tap the drop-down button of **Waveform** to select the modulating waveform. The available waveform types include:

- Sine
- Square with 50% duty cycle
- Triangle with 50% symmetry
- UpRamp with 100% symmetry
- DnRamp with 0% symmetry
- Noise - white gaussian noise

Set the Frequency Deviation

It represents the peak variation in frequency of the modulated waveform from the carrier frequency. Click or tap the input field of **Deviation** to set the frequency deviation with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The settable FM frequency deviation range is from 2 mHz to the current frequency of the carrier waveform.

(Available Only for MHO5054/5104)

**TIP**

The frequency deviation plus the carrier frequency must be less than or equal to the selected carrier's maximum frequency.

Set the Modulation Frequency

When you select the modulating waveforms other than Noise, you can set the modulation frequency. Click or tap the input field of **Mod. Freq** to set the modulation frequency with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The available range of the FM frequency is from 2 mHz to 1 MHz.

Enable the Modulation Output

Click or tap ON for **Mod. State** to enable the modulation function. In the Basic Waveforms interface, click or tap ON for **Output** to enable the waveform output. Then the modulated waveforms will be output from the specified AFG terminal based on the settings.

14.2.3 PM

PM (Phase Modulation), namely the phase of the carrier waveform changes with the voltage of the modulating waveform.




Figure 14.12 PM

Select the Modulation Type

Click or tap the drop-down button of **Mod. Type** to select "PM".

Select the Modulating Waveform

The instrument uses the built-in signal to perform waveform modulation. Click or tap the drop-down button of **Waveform** to select the modulating waveform. The available waveform types include:

- Sine
- Square with 50% duty cycle
- Triangle with 50% symmetry
- UpRamp with 100% symmetry
- DnRamp with 0% symmetry
- Noise - white gaussian noise

To Set the Phase Deviation

The phase deviation represents the peak variation in phase of the modulated waveform from the carrier waveform. Click or tap the input field of **Phase Dev** to set the phase deviation with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The available setting range of the phase deviation is from 0° to 360°. By default, it is 90°.

Set the Modulation Frequency

When you select the modulating waveforms other than Noise, you can set the modulation frequency. Click or tap the input field of **Mod. Freq** to set the modulation frequency with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set it. The available range of the PM frequency is from 2 mHz to 1 MHz.

Enable the Modulation Output

Click or tap ON for **Mod. State** to enable the modulation function. In the Basic Waveforms interface, click or tap ON for **Output** to enable the waveform output. Then the modulated waveforms will be output from the specified AFG terminal based on the settings.

15 Bode Plot (Available Only for MHO5054/5104)

Bode plot is a way of graphically displaying the frequency response of a system. In the switching power supply and operational amplifier's circuit feedback network, the Bode plot provides the curves displaying the variation of gain and phase with the frequency for a loop analysis. The analysis on the system's gain and phase margins enables you to test the stability of the system.

With the built-in signal generator module, the digital oscilloscope generates the sweep signal of a specified frequency range and outputs to the switching power supply circuit under test. Then, the oscilloscope draws a Bode plot displaying the variation of phase and gain with different frequencies. Click or tap the function

navigation icon , and then select **Bode Plot** to enter the Bode plot setting menu.




Figure 15.1 Bode Plot Setting Menu

Click or tap  to minimize the Bode plot window.




Figure 15.2 Minimized Bode Plot Window

**NOTE**

The Bode plot function can only test the response of basic devices such as amplifiers, but cannot test circuits with greater noise.

15.1 Basic Setting

Click or tap the **Basic Setting** tab to enter the basic setting menu. In this menu, you can enable or disable the Bode plot function, start or stop the Bode plot operation, set the input/output source, set the sweep type and display type, and check the connection diagram.

In the Bode Plots setting menu, click or tap the ON/OFF tab for **Bode Plot** to enable or disable the Bode function. After the Bode plot function is enabled, the Bode plot window will be displayed on the screen.

15.1.1 To Enable or Disable the Bode Plot Function

In the Bode plot setting interface, click or tap the ON/OFF tab for **Bode Plot** to enable or disable the Bode plot function. After the Bode plot function is enabled, the Bode plot window will be displayed on the screen. For the Bode plot display interface, refer to *To Set the Display Type*.

15.1.2 To Run or Stop the Drawing of the Bode Plot

When the Bode plot is enabled, in the Bode plot interface, click or tap  for **Operating Status** to start the loop analysis and Bode plot drawing based on the current Bode plot settings. In the running status,  is displayed for **Operating Status**. After completing the Bode plot drawing, the icon after the **Operating Status** menu turns out to be .

To stop Bode plot drawing during the drawing process, click or tap  to suspend drawing.

**NOTE**

After completing the Bode plot test, the Bode plot setting interface is closed automatically. To open the Bode plot setting interface again, click or tap  at the upper-right corner of the Bode plot window.

15.1.3 To Set the Input/Output Source

- **Input Source:**

The input source indicates the channel input with the reference signal. The current frequency takes the frequency of this channel as the reference. The analog channel can be selected as the input source. The default input channel is CH1. Before selecting the input source, connect the signal under test to the analog channel input terminal of the oscilloscope.

- **Output Source:**

The output source indicates the channel that connects the feedback output signal. The analog channel can be selected as the output source. The default output channel is CH2. Before selecting the output source, connect the signal under test to the analog channel output terminal of the oscilloscope.

The analog channels are available for the input and output sources. For available analog channels for different models, refer to *Content Conventions in this Manual*.

15.1.4 To Set the Sweep Signal

Sweep Source

Selects the AFG channel from the drop-down list of **AFG Chan** as the channel source to output the sweep signal. The default channel is AFG1.

Sweep Type

Click or tap the drop-down button of **Sweep Type** to select "Log" or "Linear".

- **Linear:** the frequency of the swept sine wave varies linearly with the time.
- **Log:** the frequency of the swept sine wave varies logarithmically with the time.

15.1.5 To Set the Display Type

Click or tap the drop-down button of **Disp Type** to select "Wave" or "Chart".

Waveform Display

The Bode plot waveform display is as shown in the figure below. The X-axis in the Bode plot represents the frequency; and the Y-axis represents gain or phase. The magnitude-frequency curve (indicated in red) represents the gain between system input and output. The phase-frequency curve (indicated in green) represents the phase deviation between system input and output.




Figure 15.3 Bode Plot Displayed in Waveform Display Form

1. Cursor: rotate the specified multifunction knob to move the cursor. The cursor information is displayed in the upper-left corner of the Bode plot.
2. Bode plot curves: magnitude-frequency curve (indicated in red) and phase-frequency curve (indicated in green).
3. Cursor information display:
 - Freq: indicates the X-axis value where the cursor is located in the Bode plot.
 - Gain: indicates the Y-axis value of the crossing point between the cursor and the red magnitude-frequency curve.
 - Phase: indicates the Y-axis value of the crossing point between the cursor and the green phase-frequency curve.

The cursor appears as a white vertical line in the Bode plot waveform display. You can rotate the specified multifunction knob to adjust the cursor position and view information about each point.
4. Margin result (displayed when the Bode plot operation stops):
 - PM: phase margin. It is the difference in phase between the phase at 0 dB gain frequency point and 0-degree phase.
 - GM: gain margin. It is the gain measurement difference between the value at 0 dB and the frequency point at 0-degree phase. That is, $GM = 0 \text{ dB} - \text{Gain Measurement Value}$.
5. Operation button: click or tap  to open the Bode plot setting menu. Click or tap  to close the Bode plot waveform display window and disable the Bode function.

Chart Display

The Bode plot chart display is as shown in the figure below. It shows the frequency, gain, and phase of all sample points. Click or tap  to open the bode plot setting menu. Click or tap  to close the Bode plot chart and disable the Bode function.

Bode Plot   			
Index	Freq	Gain	Phase
1	100Hz	8.70dB	22.83°
2	125.89Hz	3.32dB	133.41°
3	158.48Hz	4.64dB	-35.00°
4	199.52Hz	-1.63dB	-31.39°
5	251.18Hz	-0.18dB	-33.55°
6	316.22Hz	-5.86dB	100.27°
7	398.10Hz	-9.54dB	-7.38°
8	501.18Hz	6.80dB	-150.68°
9	630.95Hz	-12.39dB	-34.44°
10	794.32Hz	-7.42dB	-128.75°
11	1kHz	6.01dB	168.11°
12	1.2589kHz	3.57dB	65.11°
13	1.5848kHz	6.96dB	-73.35°
14	1.9952kHz	-9.04dB	68.02°
15	2.5118kHz	-3.91dB	-73.77°
16	3.1622kHz	-7.34dB	179.73°
17	3.9810kHz	7.18dB	18.78°
			

Figure 15.4 Bode Plot Chart Display

15.1.6 To View the Connection Diagram

Before enabling the Bode plot function, make a proper loop connection. Click or tap **Connection Diagram** to view the loop connection diagram. According to the connection diagram, connect the front-panel AFG output interface of the oscilloscope to the isolation transformer. Input the output signal of the isolation transformer to the ends of the injection resistor of the circuit under test. Then measure the signals at the input terminal and the output terminal.

15.2 Ampl/Freq Setting

Click or tap the **Ampl/Freq Setting** tab to enter the Ampl/Freq Setting menu. Then set the following parameters.

- **Start Frequency:** click or tap the input field of **Start Freq** to set the start frequency of the Sine waveform with the pop-up numeric keypad. You can also use the specified multifunction knob to set the value. The settable range is from 10 Hz to 3 MHz.
- **Stop Frequency:** click or tap the input field of **Stop Freq** to set the stop frequency of the Sine waveform with the pop-up numeric keypad. You can also use the specified multifunction knob to set the value. The available range of stop frequency is from 100 Hz to 30 MHz. Stop Frequency $\geq 10 \times$ Start Frequency.
- **Points/Decade:** click or tap the input field of **Points/Decade** to set the number of displayed points per decade. You can also use the specified multifunction knob to set the value. The setting range is from 10 to 100. By default, it is 10.
- **Amplitude:** click or tap the input field of **Amp** to set the voltage amplitude of the Sine waveform when the **Var.Amp.** is set to "OFF".
- **Variable Amplitude:** click or tap the ON/OFF tab for **Var.Amp.** to enable or disable the variable amplitude. When enabled, you can set the voltage amplitude of the Sine waveform under different frequency ranges.



TIP

The stop frequency shall be greater than the start frequency.

15.3 To Save and Load the Bode Plot File

Click or tap the **Save** tab to enter the save setting interface. Here you can save and load the Bode plot data.

Save the Test Data

1. Click or tap the drop-down button of **Format** to select the format of the saved Bode plot. The available file types include "*.csv" and "*.html".
2. Click or tap the input field of **File Name** to input the filename with the pop-up virtual keypad.
3. Click or tap the input field of **File Path**, and then the "Disk" interface is displayed. Select the desired destination path, and then click or tap **OK** to confirm the operation. For details about the disk management, refer to *Disk Management*.
4. Click or tap **Save** to save the Bode plot file according to the settings.

Load the Test Data

1. Click or tap the drop-down button of **File Type** to select "*.csv" as the format of the file to be loaded.
2. Click or tap the input field of **File Path**, and then the "Disk" interface is displayed. Select the desired file from the specified path, and then click or tap **OK** to confirm the operation. For details about the disk management, refer to *Disk Management*.
3. Click or tap **Load** to load the Bode plot file. The test data of the loaded file will be displayed on the screen in a wave/chart format (depending on the display type that you select).

16 Power Analysis (Option)

The power analysis function can help engineers to quickly complete the measurement and analysis of power-related parameters, such as switching loss, power efficiency, ripple, greatly improving test efficiency and optimizing power design.



TIP

Power analysis function is available only when the PWRA option is installed. For details, please go to <http://www.rigol.com> to acquire the Power Analysis Application Guide.

To enter the **UPA** menu, perform any of the following operations:

- Click or tap  and select **UPA** to enter the "UPA" menu.
- Press the front-panel  key and then select **UPA** to enter the "UPA" menu.




Figure 16.1 Power Analysis Menu

Test Items

The power analysis function supports various measurement and analysis items, such as power quality, ripple, switching loss, modulation analysis, transient response, slew rate, power efficiency, turn-on/off, inrush current, harmonic analysis, and Safe Operating Area (SOA) test.




Figure 16.2 Power Analysis Test Items

Connection Diagram

To ensure the smooth test of the above items, the oscilloscope provides connection diagrams for each test and displays the complete measurement results, helping users perform power analysis tests quickly and correctly.




Figure 16.3 Power Analysis Test Connection Diagram

Test Results

The oscilloscope displays the complete measurement results when the test is completed.



Figure 16.4 Power Analysis Test Results

17 Reference Waveform

This series oscilloscope provides 10 reference waveform positions (Ref1~Ref10). In the actual test process, you can compare the signal waveform with the reference waveform to locate the failure.

17.1 To Enable the Ref Function

To enter the **Ref** interface, perform any of the following operations:

- Click or tap the function navigation icon  at the lower-left corner of the screen, and then select **Ref** to enter the reference waveform function menu.
- Press the front-panel  key to enter the reference waveform function menu.




Figure 17.1 Reference Waveform Menu

17.2 To Set the Reference Waveform

In the **Ref** menu, you can specify a channel to serve as the reference channel, save and clear the reference channel.

Select the Reference Channel

Click or tap the drop-down button of **Current** to select the reference waveform channel (Ref1-Ref10). By default, Ref1 is enabled.

Select the Ref Source

Click or tap the drop-down button of **Source** to select the desired source of the reference waveform. The available sources include analog channels, digital channels, and Math1~Math4.



NOTE

For the channel sources supported by different models, refer to *Content Conventions in this Manual*.

Save the Reference Waveform to Internal Memory

Click or tap **SaveToRef** to save the displayed waveform for the specified source to the internal memory as the reference waveform.



CAUTION

This operation only saves the reference waveform to the volatile memory, and the waveform will be cleared at power-off or restoring to the default settings. If you want to store reference waveforms that can be recalled when necessary, please export the waveform to internal or external memory (*To Export and Import the Reference Waveform*).

Clear the Specified Reference Waveform


Click or tap **Clear** to clear the specified reference waveform for the current channel. You can also click or tap **Clear** in the function navigation menu or press the front-panel  key to clear the reference waveforms of all the reference channels.

17.3 To Set the Ref Waveform Display

After clicking or tapping **SaveToRef** to save the current channel as reference waveform channel, you can adjust the vertical scale, vertical offset, and horizontal offset of the reference waveform specified under **Current**.

Adjust the Vertical Scale

Click or tap the input field of **VScale** to input the vertical scale of the reference waveform with the pop-up numeric keypad. You can also click or tap the icon  at the right of the input field of **VScale** to increase or decrease the vertical scale. Also, you can use the specified multifunction knob indicated in the input field to set the value.



Modify the Vertical Offset

Click or tap the input field of **VOffset** to set the vertical offset of the reference waveform with the pop-up numeric keypad. You can also click or tap the icon  at the right of the input field of **VOffset** to increase or decrease the vertical offset. Also, you can use the specified multifunction knob indicated in the input field to set the value.



Horizontal Offset

Click or tap the input field of **HOffset** to set the horizontal offset of the reference waveform with the pop-up numeric keypad. You can also click or tap the icon  at the right of the input field of **HOffset** to increase or decrease the horizontal offset. Also, you can use the specified multifunction knob indicated in the input field to set the value.

Reset the Reference Waveform

After you have done the save operation for the reference waveform and you want to restore the reference waveform to the position prior to its last **Save** operation, Click or tap **Reset**.

Set the Reference Waveform Color

This series oscilloscope provides five colors (gray, green, light blue, red, and orange) to mark the reference waveforms of different channels to distinguish them.

Click or tap the drop-down button of **Color** to select the color of the reference waveform of the channel.

Set the Reference Waveform Label

Click or tap the ON/OFF tab for **Label** to enable or disable the label display of the specified reference waveform.

Click or tap the input field of **Label** to set the label of the specified reference waveform with the pop-up numeric keypad.

17.4 To Export and Import the Reference Waveform

Export to Internal or External Memory

After saving the reference waveform, the reference waveform will be saved to the internal memory or external USB storage device. The format of the reference waveform file can be "*.ref", "*.bin", or "*.csv".

Click or tap **Export** to enter the reference waveform file exporting interface.

- **Set the Format**

In the file exporting interface, click or tap the drop-down button of **Format** to select "*.ref", "*.bin", or "*.csv" as the file format.

- **Set the Filename**

Click or tap the input field of **File Name**, then filename editing interface is displayed. Input the filename with the pop-up numeric keypad.

For the methods of using the numeric keypad, refer to descriptions in *Parameter Setting Method*.

- **Set the File Path**

Click or tap the input field of **File Path**, then the disk management interface is displayed. Through the disk management menu, you can save the current reference waveform to the internal memory or external USB storage device. After selecting the desired storage path, click or tap **Export** to export the desired file. For the disk management operation, refer to descriptions in *Disk Management*.

**TIP**

- Only when the reference waveform is saved, can this export function be valid.
- This series oscilloscope only supports the flash memory USB storage device of FAT32 format.
- For the "*.bin" format file, refer to "*Binary Data Format (.bin)*".

Import from Internal or External Memory

You can import the stored reference waveform file from the internal memory or external USB storage device to the internal instrument and display the file on the screen.

Click or tap **Import** to enter the reference waveform file importing interface.

- **Set the Format**

In the file importing interface, click or tap the drop-down button of **Format** to select "*.ref" as the file format.

- **Set the Import Path**

Click or tap the input field of **File Path**, then the disk management interface is displayed.

Through the disk management menu, you can import the saved reference waveform to the oscilloscope and display it in the waveform view of the oscilloscope. After selecting the desired reference waveform, click or tap **Import** to import the waveform file. For the disk management operation, refer to descriptions in *Disk Management*.

18 Pass/Fail Test

During the product design and manufacturing process, you usually need to monitor the variations of the signal or judge whether the product is up to standard. The pass/fail test function of this series oscilloscope can accomplish this task perfectly. With this function, you can set the test mask based on the known "basic" waveforms, then compare the signal under test with the "basic" waveforms to display the test result. When a successful or failed event is detected, you can set the error action performed by the instrument, such as stopping immediately, enabling the beeper to sound, and capturing the current screen shot.

Click or tap the function navigation icon  at the lower-left corner of the screen to open the function navigation menu. Click or tap to select **Pass/Fail** to enter the pass/fail test interface. You can also press  on the front panel, then click or tap **Pass/Fail** to enter the pass/fail test interface.




Figure 18.1 Pass/Fail Test Menu

18.1 To Enable or Disable the Pass/Fail Test Function

In the "Pass/Fail" setting menu, click or tap the ON/OFF tab for **Enable** to enable or disable the pass/fail test function.

When enabled, you can select the source, set the test mask, and set the parameters for the output of the test results.

18.2 To Select the Source

Click or tap the drop-down button of **Source** to select the desired source from the drop-down list. The available channels include CH1-CH8.



TIP

When the disabled channel is selected as the source, it will be enabled automatically.

18.3 To Set the Test Mask

In the **Pass/Fail** menu, you can self-define the pass/fail test mask, save and load the test mask.

Create a Mask

Click or tap the input field of **X Mask** and **Y Mask** respectively to set the horizontal tolerance range and vertical tolerance range with the pop-up numeric keypad. You can also use the Up/Down arrow at the right side of the input field of **Y Mask** to adjust the value of Y Mask; use the Left/Right arrow at the right side of the input field of **X Mask** to adjust the value of X Mask. Also, you can use the specified knob indicated in the input field of **Y Mask** and **X Mask** to set it respectively. After configuring the settings, click or tap **Create** to apply the currently created mask (the region not covered by blue within the screen).

Load a Mask

When the pass/fail test function is enabled, you can load the test mask files from the internal memory or external USB storage device (when detected) and apply them to the current pass/fail test function.

Click or tap **Load** to enter the file loading interface. Click or tap the input field of **File Path** to load the specified test mask files (in *.pf format) and apply them to the current pass/fail test function. For detailed operations, refer to descriptions of *Disk Management* in *To Store and Load*.

Save a Mask

When the pass/fail test function is enabled, you can save the current test mask range to the internal memory or external USB storage device (when detected) in "*.pf" format.

Click or tap **Save** to enter the file saving interface. Click or tap the input field of **File Name** and **File Path** to input the filename and select the desired file path to save the test mask file to the internal or external memory. For detailed operations, refer to descriptions of *Disk Management* in *To Store and Load*.

18.4 To Set the Output Form of the Test Results

In the "Option" menu of the pass/fail test interface, you can set the follow-up operations that the oscilloscope will do when test results are generated according to your needs.

Set the Output Event and Aux Output

- Click or tap the ON/OFF tab for **Aux Output** to enable or disable the Aux output.
 - When enabled, in the **Utility** menu, the sub-menu **AUX Out** under the **Setup** menu is automatically set to "PassFail". When a successful or failed event is detected, a pulse will be output from the **[AUX OUT]** connector.
 - If disabled, in the **Utility** menu, the sub-menu **AUX Out** under the **Setup** menu is automatically set to "TrigOut". The output of the **[AUX OUT]** connector is irrelevant with the pass/fail test.
- Click or tap to select "Pass" or "Fail" for the **Output Event** menu. Then when the specified output event is detected, a pulse will be output from the **[AUX OUT]** connector.

Set the Output Polarity and Output Pulse Width

Click or tap to select "Positive" or "Negative" for the **Polarity** menu. Then click or tap the input field of **Pulse** to set the pulse width with the pop-up numeric keypad. You can also use the specified knob indicated in the input field to set the value. The available range is from 100 ns to 10 ms. By default, it is 1 μ s.

Set the Error Action

In the **Err Action** menu, you can set the follow-up operations that the oscilloscope will do when a failed event is detected.

- **Stop:** indicates stopping sampling when a failed test event is detected.
- **Beeper:** indicates that the beeper sounds an alarm (irrelevant with the on/off status of the beeper of the instrument) when a failed test event is detected.
- **Screenshot:** captures the screen when a failed test event is detected. If an external storage device is detected, the screenshot will be saved to the external storage device directly. Otherwise, it will be saved to the local disk.

If "Screenshot" is selected, "Stop" action will be executed forcibly. The sampling operation will be stopped automatically. After the Screenshot operation is completed, the sampling will continue.

18.5 To Start or Stop the Pass/Fail Test Operation

After you have enabled the pass/fail test and completed the settings in the **Pass/Fail** menu, click or tap  for the **Operate** menu item to start the test. During testing, click or tap  to suspend testing at any time.

During the test process, the oscilloscope will test the waveforms, display the test information, and output the test information based on the current of settings. The "Pass/Fail" measurement results are displayed in the "Result" list. The test interface is as shown in the figure below.




Figure 18.2 Pass/Fail Test Interface




TIP

- Only when the pass/fail test function is enabled, can you start or stop the pass/fail test operation, save and load the test mask.
- After starting the test operation, you can neither modify the source channel nor adjust the test mask.

18.6 To Display the Statistics Information of the Test Results

When the "Pass/Fail" test is enabled, the test results are displayed under the "Result" list at the right side of the screen. Click or tap the icon  at the lower-right part of the waveform view to fold the result list.

The statistics information in the pass/fail test results includes number of failed frames, number of passed frames, and the total number of frames, as shown in the figure below.



Click or tap the test results under the result list, then the sub-menus are displayed. You can perform the following operations:

- Click or tap **Reset Stat.** to reset the test results to zero.
- Click or tap **Setting** to enter the pass/fail setting interface.
- Click or tap **Remove** to disable the pass/fail function and exit the current interface.

19 Protocol Decoding

You can use the protocol analysis to discover errors, debug hardware, and accelerate development easily, ensuring you to accomplish the projects with high speed and good quality. Protocol decoding is the basis of protocol analysis. Only protocol analyses with correct protocol decoding are acceptable, and only correct protocol decoding can identify more error information. This oscilloscope provides four bus decoding modules (Decode 1, Decode 2, Decode 3, and Decode 4) to make common protocol decoding for the input signals of the analog channels. It provides standard serial decodes including Parallel, RS232/UART, I2C, CAN, and SPI; optional serial decodes including LIN, CAN-FD, FlexRay, I2S and MIL-STD-1553. As the decoding functions and setting methods of Decode1, Decode2, Decode3, and Decode4 are the same, this chapter takes Decode1 as an example for illustration.

- Click or tap  > **Decode** to enter the "Decode" menu.
- Click or tap the **Decode** button on the toolbar to enter the "Decode" menu.

To get the decoding option information, refer to descriptions in [Appendix A: Options and Accessories](#).

If you have purchased the decoding option, activate it according to the descriptions in [To View the Option Information and the Option Installation](#).

19.1 Parallel Decoding

Parallel bus consists of clock line and data line. As shown in the figure below, CLK is the clock line, Bit0 and Bit1 are the 0 bit and 1st bit on the data line. The oscilloscope will sample the channel data on the rising edge, falling edge, or the rising/falling edge of the clock and judge each data point (logic "1" or logic "0") according to the preset threshold level.




Figure 19.1 Schematic Diagram of Parallel Decoding

In the **Decode** menu, click or tap the drop-down button of **Bus Type** to select **Parallel**, then configure the parameters for Parallel decoding.




Figure 19.2 Parallel Decoding Menu

Bus Status

Click or tap the ON/OFF tab for **Bus Status** to enable or disable the bus decoding.

19.1.1 Clock Setting (CLK)

Clock Setting (CLK)

Click or tap the drop-down button of **CLK** to select the analog channels or digital channels as the clock channel. If "OFF" is selected, no clock channel is set, and sampling is performed when a hop occurs to the data of the data channel during decoding.

NOTE

For the available channels, refer to *Content Conventions in this Manual*.

Threshold

You need to set a threshold when configuring the clock channel. Click or tap the input field of **Threshold**, and then use the pop-up numeric keypad to set the threshold. You can also use the specified multifunction knob to set the value. The range of the threshold is related to the current vertical scale and offset.

CLK Edge

You can select "Rising", "Falling", or "Both" in **CLK Edge** when configuring the clock channel.

- **Rising:** samples the channel data on the rising edge of the clock.
- **Falling:** samples the channel data on the falling edge of the clock.
- **Both:** samples the channel data on the rising edge or the falling edge of the clock.

19.1.2 Bus Setting

Set the Bus

You can select analog channels or digital channels for Parallel decoding bus from the drop-down list of **BUS**. For the supported channels of each model, refer to *Content Conventions in this Manual*.

Table 19.1 Bus Setting of DHO Series 8-CH Model

Bus	Width	Bit X	Channel	Remarks
CH1	1	0	CH1	Width, Bit X, and CH are set automatically, and you cannot modify them.
CH2	1	0	CH2	Width, Bit X, and CH are set automatically, and you cannot modify them.
CH3	1	0	CH3	Width, Bit X, and CH are set automatically, and you cannot modify them.
CH4	1	0	CH4	Width, Bit X, and CH are set automatically, and you cannot modify them.
CH5	1	0	CH5	Width, Bit X, and CH are set automatically, and you cannot modify them.
CH6	1	0	CH6	Width, Bit X, and CH are set automatically, and you cannot modify them.
CH7	1	0	CH7	Width, Bit X, and CH are set automatically, and you cannot modify them.

Bus	Width	Bit X	Channel	Remarks
CH8	1	0	CH8	Width, Bit X, and CH are set automatically, and you cannot modify them.
User	1 to 8, 1 for default	0 (Default)	CH1-CH8	When the bus is set to "User", you can set the bus width.

Table 19.2 Bus Setting of MHO Series 4-CH Model


Bus	Width	Bit X	Channel	Remarks
CH1	1	0	CH1	Width, Bit X, and CH are set automatically, and you cannot modify them.
CH2	1	0	CH2	Width, Bit X, and CH are set automatically, and you cannot modify them.
CH3	1	0	CH3	Width, Bit X, and CH are set automatically, and you cannot modify them.
CH4	1	0	CH4	Width, Bit X, and CH are set automatically, and you cannot modify them.
D7-D0	8	0 (Default)	D0 (Default)	Bit0 to Bit7 are set to D7 to D0 respectively. Width is set automatically, and you cannot modify them.
D15-D8	8	0 (Default)	D8 (Default)	Bit0 to Bit7 are set to D15 to D8 respectively. Width is set automatically, and you cannot modify them.
D15-D0	16	0 (Default)	D0 (Default)	Bit0 to Bit15 are set to D15 to D0 respectively. Width is set automatically, and you cannot modify them.
D0-D7	8	0 (Default)	D7 (Default)	Bit0 to Bit7 are set to D0 to D7 respectively. Width is set

Bus	Width	Bit X	Channel	Remarks
				automatically, and you cannot modify them.
D8-D15	8	0 (Default)	D15 (Default)	Bit0 to Bit7 are set to D8 to D15 respectively. Width is set automatically, and you cannot modify them.
D0-D15	16	0 (Default)	D15 (Default)	Bit0 to Bit15 are set to D0 to D15 respectively. Width is set automatically, and you cannot modify them.
User	1 to 4, 1 for default	0 (Default)	CH1-CH4, D0-D15	When the bus is set to "User", you can set the bus width.

Set the Threshold Level

When the analog channel is set as the bus source, to judge logic "1" and logic "0" of the buses, you need to set a threshold for each analog channel. When the channel signal amplitude is greater than the preset threshold, it is judged as logic "1"; otherwise logic "0".

Click or tap the input field of **Threshold**, and then use the pop-up numeric keypad to set the threshold. You can also use the specified multifunction knob to set the value. The range of the threshold is related to the current vertical scale and offset.



Endian

In **Endian**, select "Invert" or "Normal" as the endian of the bus.

Polarity

In **Polarity**, select "Positive" or "Negative" as the data polarity.

19.1.3 Display-related Setting

In the **Decode** menu, set the following display-related parameters.

Set the Display Format

Click or tap the drop-down button of **Format** to select the display format of the bus data and that of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".

Set the Label Display

Click or tap the ON/OFF tab for **Label** to enable or disable the label display of the decoding bus. When enabled, the bus label will be displayed at the upper-left side of the bus (when the bus display is enabled). The label shows the current bus type.

19.1.4 Event Table

The event table displays the decoded data and the corresponding decoding information in time order in the form of a table. It can be used to observe relatively longer decoded data. The decoding information includes the decoded data, the corresponding line number, time, etc.

When the event table is enabled, the event table window of the specified decoding is displayed on the screen. The decoding information is shown in the event table.



Figure 19.3 Parallel Decoding Event Table

TIP

- When you adjust the horizontal time base, the waveform displayed on the screen will also change, and the total number of lines containing the decoding information in the event table will also be changed.
- The displayed decoded data information in the bus is related to the value of the horizontal time base. Reducing the horizontal time base can help you view the detailed information.

Set the Event Table Format

Click or tap the drop-down button of **Format** to select the display format of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".

Export

When the operating status of the instrument is STOP, you can export the time and corresponding decoding data from the current event table.

Click or tap **Export** to enter the file export interface. You can export the data list to the internal memory or the external USB storage device (when detected) in "*.csv" format. The detailed export operation is similar to the save operation, you can refer to relevant descriptions in *To Store and Load*.

19.2 RS232 Decoding

RS232 serial bus consists of the transmitting data line (TX) and the receiving data line (RX).





Figure 19.4 Schematic Diagram of RS232 Serial Bus

In RS232, baud rate is used to represent the transmission rate (namely bits per second) of the data. You need to set the start bit, data bits, check bit (optional), and stop bits for each frame of data.



- **Start Bit:** indicates when to output data.
- **Data Bit:** indicates the number of data bits actually contained in each frame of data.
- **Check Bit:** used to check whether the data are properly transmitted.
- **Stop Bit:** indicates when to stop outputting data.

In the **Decode** menu, click or tap the drop-down button of **Bus Type** to select **RS232**, then configure the parameters for RS232 decoding.




Figure 19.5 RS232 Decoding Menu

Bus Status

Click or tap the ON/OFF tab for **Bus Status** to enable or disable the bus decoding.

Quickly Apply Trigger Settings to Decoding

Copy trig indicates applying the trigger settings to the specified decoding setting.

Click or tap **Copy Trig** to apply the trigger settings to the specified decoding setting.

19.2.1 Source Setting

Set the Tx source and the threshold

Click or tap the drop-down button of **Tx** to select the desired source. The options include analog channels, digital channels, or OFF.

When the source is set to the analog channel, click or tap the input field of **Threshold**, and then use the pop-up numeric keypad to set the threshold of Tx source. You can also use the specified multifunction knob to set the value. The range of the threshold is related to the current vertical scale and offset.

When you modify the threshold of the Tx source channel, a dotted line displaying the current threshold level is displayed on the screen. It disappears in about 2 s after you stop modifying the threshold.

NOTE

For the supported channels of each model, refer to *Content Conventions in this Manual*.



Set the Rx source and the threshold

Use the same method to select the **Rx** source and set the threshold. The default state of **Rx** is OFF.



TIP

The sources of **Tx** and **Rx** cannot be set to OFF at the same time.

Polarity

Click or tap "**Positive**" or "**Negative**" in **Polarity**.

- **Positive:** High level is logic "1" and low level is logic "0".
- **Negative:** High level is logic "0" and low level is logic "1".

Set the baud rate

Click or tap the drop-down button of **Baud** to select the baud rate. The available baud rates include 50 bps, 75 bps, 110 bps, 134 bps, 150 bps, and etc.

The oscilloscope allows you to self-define the baud rate. Click or tap the drop-down button of **Baud** to select "User" and then set the baud rate with the pop-up numeric keypad.

19.2.2 To Set Data Package

Data

Click or tap the drop-down button of **Data** to select the data bits. The available data bits are 5 bits, 6 bits, 7 bits, 8 bits, and 9 bits.

Parity

It is used to check whether the data transmission is correct. Click or tap the drop-down button of **Parity** to select the desired parity mode.

- **None:** indicates that no check bit appears during the transmission.
- **Even:** indicates that the total number of "1" in the data bit and check bit is an even number. For example, when 0x55 (01010101) is sent, "0" should be added to the check bit.
- **Odd:** indicates that the total number of "1" in the data bit and check bit is an odd number. For example, when 0x55 (01010101) is sent, "1" should be added to the check bit.


Stop Bit

Click or tap the drop-down button of **Stop Bit** to set the stop bits after each frame of data. It can be set to 1 bit, 1.5 bits, or 2 bits.

Endian

Click or tap the drop-down button of **Endian** to select the desired endian.

- **LSB:** indicates Least Significant Bit transmission sequence, i.e. the lowest bit of the data is transmitted first.
- **MSB:** indicates Most Significant Bit transmission sequence, i.e. the highest bit of the data is transmitted first.



19.2.3 Display-related Setting

In the **Decode** menu, set the following display-related parameters.

Set the Display Format

Click or tap the drop-down button of **Format** to select the display format of the bus data and that of the event table. The available formats include "**Hex**", "**Dec**", "**Bin**", and "**ASCII**".

Set the Label Display

Click or tap the ON/OFF tab for **Label** to enable or disable the label display of the decoding bus. When enabled, the bus label will be displayed at the upper-left side of the bus (when the bus display is enabled). The label shows the current bus type.

19.2.4 Event Table

When the event table is enabled, the event table window of the specified decoding is displayed on the screen. The decoding information is shown in the event table.




Figure 19.6 RS232 Decoding Event Table



TIP

- When you adjust the horizontal time base, the waveform displayed on the screen will also change, and the total number of lines containing the decoding information in the event table will also be changed.
- The displayed decoded data information in the bus is related to the value of the horizontal time base. Reducing the horizontal time base can help you view the detailed information.

Set the Event Table Format

Click or tap the drop-down button of **Format** to select the display format of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".

Export

When the operating status of the instrument is STOP, you can export the time and corresponding decoding data from the current event table.

Click or tap **Export** to enter the file export interface. You can export the data list to the internal memory or the external USB storage device (when detected) in "*.csv" format. The detailed export operation is similar to the save operation, you can refer to relevant descriptions in *To Store and Load*.

19.3 I2C Decoding

I2C serial bus consists of the clock line (SCL) and the data line (SDA).

SCL: samples SDA on the rising or falling edge of the clock.

SDA: indicates the data channel.




Figure 19.7 I2C Serial Bus

In the **Decode** menu, click or tap the drop-down button of **Bus Type** to select **I2C**, then configure the parameters for I2C decoding.




Figure 19.8 I2C Decoding Menu

Bus Status

Click or tap the ON/OFF tab for **Bus Status** to enable or disable the bus decoding.

Quickly Apply Trigger Settings to Decoding

Copy trig indicates applying the trigger settings to the specified decoding setting.

Click or tap **Copy Trig** to apply the trigger settings to the specified decoding setting.

19.3.1 Source Setting

Set the Clock Channel and Data Channel

- You can select analog channels or digital channels as the source for **CLK**. When the source is set to the analog channel, set the **SCL Thre** value with the numeric keypad or multifunction knob.

When you modify the threshold of the clock channel, a dotted line displaying the current threshold level is displayed on the screen. It disappears in about 2 s after you stop modifying the threshold.

- You can select analog channels or digital channels as the source for **SDA**. When the source is set to the analog channel, set the **SDA Thre** with the numeric keypad or the multifunction knob.

For the available channels, refer to *Content Conventions in this Manual*.


Exchange Sources

Click or tap the "SCL/SDA" or "SDA/SCL" tab for **Exchange** to exchange the sources of the current clock channel and data channel.

Set the Address Width

Click or tap the drop-down button of **Width** to select the address width. The available options include 7 Bits, 8 Bits, or 10 Bits. When "7 Bits" is selected, R/W bit is not included in the address. When "8 Bits" or "10 Bits" is selected, R/W bit is included in the address.

- 7:** In 7-bit addressing, after the START condition, a slave address is sent. The address starts to transfer from the first byte, as shown in the figure below. The first seven bits of the first byte make up the slave address, and the eighth bit is the LSB (least significant bit) which determines the direction of the message, also called a data direction bit (R/W). A "zero" indicates a transmission (WRITE), a "one" indicates a request for data (READ).



- 8:** same as the 7-bit addressing. A R/W bit is included in the 8-bit addressing for the slave address.
- 10:** 10-bit addressing is compatible with 7-bit addressing. As shown in the figure below, in 10-bit addressing, the first byte is the special reserved address 10-bit Address Indicator to indicate the current 10-bit address that is transferring.



19.3.2 Display-related Setting

In the **Decode** menu, set the following display-related parameters.

Set the Display Format

Click or tap the drop-down button of **Format** to select the display format of the bus data and that of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".

Set the Label Display

Click or tap the ON/OFF tab for **Label** to enable or disable the label display of the decoding bus. When enabled, the bus label will be displayed at the upper-left side of the bus (when the bus display is enabled). The label shows the current bus type.

19.3.3 Event Table

When the event table is enabled, the event table window of the specified decoding is displayed on the screen. The decoding information is shown in the event table.



Figure 19.9 I2C Decoding Event Table



TIP

- When you adjust the horizontal time base, the waveform displayed on the screen will also change, and the total number of lines containing the decoding information in the event table will also be changed.
- The displayed decoded data information in the bus is related to the value of the horizontal time base. Reducing the horizontal time base can help you view the detailed information.

Set the Event Table Format

Click or tap the drop-down button of **Format** to select the display format of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".



Export

When the operating status of the instrument is STOP, you can export the time and corresponding decoding data from the current event table.

Click or tap **Export** to enter the file export interface. You can export the data list to the internal memory or the external USB storage device (when detected) in "*.csv" format. The detailed export operation is similar to the save operation, you can refer to relevant descriptions in *To Store and Load*.

Address Information of I2C Decoding

For I2C bus, each frame of data starts with the address information (read address and write address). In the address information, "Read" indicates the read address

() and "Write" indicates the write address ()

Error Expressions in I2C Decoding

In I2C decoding, the decoded data may include address with ACK or without ACK

(NACK). When NACK appears following the write address, an error message  indicated in red is displayed.

19.4 SPI Decoding

SPI bus is based on the master—slave configuration and usually consists of chip select line (CS), clock line (CLK), and data line (SDA). Wherein, the data lines include the master input/slave output (MISO) data line and master output/slave input (MOSI) data line. The oscilloscope samples the channel data on the rising edge or falling edge of the clock signal and judges each data point (logic "1" or logic "0") according to the preset threshold level.




Figure 19.10 SPI Serial Bus

In the **Decode** menu, click or tap the drop-down button of **Bus Type** to select **SPI**, then configure the parameters for SPI decoding.




Figure 19.11 SPI Decoding Menu

Bus Status

Click or tap the ON/OFF tab for **Bus Status** to enable or disable the bus decoding.

Quickly Apply Trigger Settings to Decoding

Copy trig indicates applying the trigger settings to the specified decoding setting.

Click or tap **Copy Trig** to apply the trigger settings to the specified decoding setting.

19.4.1 Source Setting

Set the Clock Signal

- Click or tap the drop-down button of **CLK** to select the analog channels or digital channels as the desired source.
- When the source is set to the analog channel, click or tap the input field of the **Threshold** to set the value with the pop-up numeric keypad. You can also use the corresponding multifunction knob to set the value.
- Click or tap "Rising" or "Falling" under **Slope** to set the instrument to sample MISO and MOSI on the CLK.

MISO and MOSI Setting

- You can select the analog channels, digital channels or OFF as the desired source of **MISO**.

When the MISO source is set to the analog channel, you can set the **Threshold** for the MISO source channel with the numeric keypad or the multifunction knob.

- You can select the analog channels, digital channels or OFF as the desired source of **MOSI**.

When the MOSI source is set to the analog channel, you can set the **Threshold** for the MOSI source channel with the numeric keypad or the multifunction knob.



NOTE

The MISO and MOSI sources cannot be set to "OFF" at the same time.

For the supported channels of each model, refer to *Content Conventions in this Manual*.

19.4.2 To Set the Mode and Data

Mode

Select "**Timeout**" or "**CS**" in **Mode**.

- **Timeout**

You can perform frame synchronization according to the timeout. The timeout value must be greater than half of the clock cycle. Click or tap the input field of **Timeout**, and then use the pop-up numeric keypad to set the timeout value. You can also use the specified multifunction knob to set the value. The adjustable range of the timeout value is from 8 ns to 10 s. By default, it is 1 μ s.

- **CS**

Indicates the chip select line (CS). You can perform frame synchronization according to CS. When "CS" is selected,

- Click or tap the drop-down button of **CS** to select the desired source. You can select analog channels or digital channels.



NOTE


For the supported channels of each model, refer to *Content Conventions in this Manual*.

- Click or tap the input field of the **Threshold** to set the threshold with the pop-up numeric keypad. You can also use the specified multifunction knob to set the threshold.
- In **CS Polarity**, click or tap to select "**Positive**" or "**Negative**".

Endian

Click or tap the drop-down button of **Endian** to select the desired endian.

- **LSB:** indicates Least Significant Bit transmission sequence, i.e. the lowest bit of the data is transmitted first.
- **MSB:** indicates Most Significant Bit transmission sequence, i.e. the highest bit of the data is transmitted first.



Polarity

In **Polarity**, select "**Positive**" or "**Negative**".

Width Setting

Click or tap the input field of **Width**, and then use the pop-up numeric keypad to set the bits of each frame of data. You can also use the specified multifunction knob to set the value. The setting range is from 4 to 32. By default, it is 8.

19.4.3 Display-related Setting

In the **Decode** menu, set the following display-related parameters.

Set the Display Format

Click or tap the drop-down button of **Format** to select the display format of the bus data and that of the event table. The available formats include "**Hex**", "**Dec**", "**Bin**", and "**ASCII**".

Set the Label Display

Click or tap the ON/OFF tab for **Label** to enable or disable the label display of the decoding bus. When enabled, the bus label will be displayed at the upper-left side of the bus (when the bus display is enabled). The label shows the current bus type.

19.4.4 Event Table

When the event table is enabled, the event table window of the specified decoding is displayed on the screen. The decoding information is shown in the event table.



Figure 19.12 SPI Decoding Event Table



TIP

- When you adjust the horizontal time base, the waveform displayed on the screen will also change, and the total number of lines containing the decoding information in the event table will also be changed.
- The displayed decoded data information in the bus is related to the value of the horizontal time base. Reducing the horizontal time base can help you view the detailed information.

Set the Event Table Format

Click or tap the drop-down button of **Format** to select the display format of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".

Export

When the operating status of the instrument is STOP, you can export the time and corresponding decoding data from the current event table.

Click or tap **Export** to enter the file export interface. You can export the data list to the internal memory or the external USB storage device (when detected) in "*.csv" format. The detailed export operation is similar to the save operation, you can refer to relevant descriptions in *To Store and Load*.

19.5 CAN Decoding

The oscilloscope samples the CAN (standard) or CAN-FD (option) signal at the specified sample position, and judges each data point to be logic "1" or logic "0" according to the preset threshold level. You need to specify the CAN/CAN-FD signal type and sample position.

In the **Decode** menu, click or tap the drop-down button of **Bus Type** to select **CAN**, then configure the parameters for CAN decoding. The **CAN-FD Baud** and **FD Sample Position** items are available only when the CAN-FD option is installed and enabled. The CAN-FD Baud item specifies the baud rate of the CAN-FD bus.




Figure 19.13 CAN Decoding Menu

Bus Status

Click or tap the ON/OFF tab for **Bus Status** to enable or disable the bus decoding.

Quickly Apply Trigger Settings to Decoding

Copy trig indicates applying the trigger settings to the specified decoding setting.

Click or tap **Copy Trig** to apply the trigger settings to the specified decoding setting.

19.5.1 Signal Configuration

Set the Source and the Threshold

- Click or tap the drop-down button of **Source** to select the desired source from the drop-down list. The sources include analog channels, digital channels, and Math1-Math4. For the channel sources supported by different models, refer to *Content Conventions in this Manual*.
- When an analog channel or Math1-Math4 is selected as the source, you can set **Threshold** for the specified channel with the pop-up numeric keypad. You can also use the specified multifunction knob to set the threshold.

When you modify the threshold of the signal source, a dotted line displaying the current threshold level is displayed on the screen. It disappears in about 2 s after you stop modifying the threshold.

Select the Signal Type

Click or tap the drop-down button of **Signal** to select a signal type that matches the CAN bus signal. The available signal types include CAN_H, CAN_L, Rx, Tx, and Diff.

- **CAN_H**: indicates the actual CAN_H bus signal.
- **CAN_L**: indicates the actual CAN_L bus signal.
- **Rx**: indicates the Receive signal from the CAN bus transceiver.
- **Tx**: indicates the Transmit signal from the CAN bus transceiver.
- **Diff**: The CAN differential bus signals connected to the source channel by using a differential probe. Connect the probe's positive lead to the CAN_H bus signal and connect the negative lead to the CAN_L bus signal.

Specify the Standard Signal Rate

Click or tap the drop-down button of **Baud** to select the preset baud rate. The available baud rates include 10.0 kbps, 19.2 kbps, 20.0 kbps, 33.3 kbps, and etc. You can also click or tap **User** to set a user-defined baud rate.

Sample Position

Sample position is a point within a bit's time. The oscilloscope samples the bit level at this point. The sample position is represented by the proportion of "the time from the start of the bit to the sample point" to the "bit time", as shown in the figure below.




Figure 19.14 Sample Position (CAN Decoding)

Set the CAN-FD Baud

CAN-FD baud rate is a dedicated setting for the CAN-FD decoding. It is available only when the CAN-FD option has been installed. Click or tap the drop-down button of **CAN-FD Baud** to select the variable baud rate from the drop-down list. The available baud rates include 1 Mbps, 2 Mbps, 3 Mbps, 4 Mbps, and etc. You can also click or tap **User** to set a user-defined baud rate.

FD Sample Position

FD sample position a dedicated setting for the CAN-FD decoding. It is available only when the CAN-FD option has been installed. Click or tap the input field of **FD Sample Position** to set the sample position of the CAN-FD decoding with the pop-up

numeric keypad. You also use the specified knob to set it. The settable range is from 10% to 90%.

19.5.2 Display-related Setting

In the **Decode** menu, set the following display-related parameters.

Set the Display Format

Click or tap the drop-down button of **Format** to select the display format of the bus data and that of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".

Set the Label Display

Click or tap the ON/OFF tab for **Label** to enable or disable the label display of the decoding bus. When enabled, the bus label will be displayed at the upper-left side of the bus (when the bus display is enabled). The label shows the current bus type.

19.5.3 Event Table

When the event table is enabled, the event table window of the specified decoding is displayed on the screen. The decoding information is shown in the event table.




Figure 19.15 CAN Decoding Event Table



TIP

- When you adjust the horizontal time base, the waveform displayed on the screen will also change, and the total number of lines containing the decoding information in the event table will also be changed.
- The displayed decoded data information in the bus is related to the value of the horizontal time base. Reducing the horizontal time base can help you view the detailed information.

Search ID

When the event table is enabled and the operating status of the oscilloscope is STOP (stopping acquisition), you can search for the event with the specified ID from the current event table. When you enable "Search On" and input the specified search ID, the event table will only display the event with specified ID.

Set the Event Table Format

Click or tap the drop-down button of **Format** to select the display format of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".

Export

When the operating status of the instrument is STOP, you can export the time and corresponding decoding data from the current event table.

Click or tap **Export** to enter the file export interface. You can export the data list to the internal memory or the external USB storage device (when detected) in "*.csv" format. The detailed export operation is similar to the save operation, you can refer to relevant descriptions in *To Store and Load*.

Interpret the CAN Decoding Frame Structure

- **Frame ID:** expressed in Hex, displayed as "ID:".
- **DLC (Data Length Code):** expressed in Hex, displayed as "DLC:".
- **Data:** Its display format is the same as that of the bus data (Hex, Dec, Bin, or ASCII), displayed as "Data:".
- **CRC (Cyclic Redundancy Check):** expressed in Hex, displayed as "CRC:".
- **ACK (Acknowledgement):** displayed as "ACK: "; when errors (ACK is detected to be 1) occur, it is displayed as a red patch.
- **R (Remote Frame):** displayed as "R:".
- **Stuff (Bit Filling Error):** displayed as "Stuff".

19.6 LIN Decoding (Option)

The oscilloscope samples the LIN signal, and judges each data point to be logic "1" or logic "0" according to the preset threshold level. The LIN decoding is required to specify the LIN signal protocol version.

In the **Decode** menu, click or tap the drop-down button of **Bus Type** to select **LIN**, then configure the parameters for LIN decoding.




Figure 19.16 LIN Decoding Menu

Bus Status

Click or tap the ON/OFF tab for **Bus Status** to enable or disable the bus decoding.

Quickly Apply Trigger Settings to Decoding

Copy trig indicates applying the trigger settings to the specified decoding setting.

Click or tap **Copy Trig** to apply the trigger settings to the specified decoding setting.

19.6.1 Signal Configuration

Set the Source and the Threshold

- The analog channel and the digital channel can all be set as the signal source. For the channel sources supported by different models, refer to *Content Conventions in this Manual*.
- When an analog channel is selected as the source, you can set the threshold for the specified channel with the pop-up numeric keypad. You can also use the specified multifunction knob to set the threshold.

When you modify the threshold of the signal source, a dotted line displaying the current threshold level is displayed on the screen. It disappears in about 2 s after you stop modifying the threshold.

Set the Signal

- You can select the preset baud rate. The available baud rates include 2.4 kbps, 4.8 kbps, 9.6 kbps, 19.2 kbps, etc. You can also set a user-defined baud rate.
- You can select whether the data contain the parity bit.

- You can select the protocol version that matches the LIN bus. The versions include "1.X", "2.X", and "Both".

19.6.2 Display-related Setting

In the **Decode** menu, set the following display-related parameters.

Set the Display Format

Click or tap the drop-down button of **Format** to select the display format of the bus data and that of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".

Set the Label Display

Click or tap the ON/OFF tab for **Label** to enable or disable the label display of the decoding bus. When enabled, the bus label will be displayed at the upper-left side of the bus (when the bus display is enabled). The label shows the current bus type.

19.6.3 Event Table

When the event table is enabled, the event table window of the specified decoding is displayed on the screen. The decoding information is shown in the event table.




Figure 19.17 LIN Decoding Event Table



TIP

- When you adjust the horizontal time base, the waveform displayed on the screen will also change, and the total number of lines containing the decoding information in the event table will also be changed.
- The displayed decoded data information in the bus is related to the value of the horizontal time base. Reducing the horizontal time base can help you view the detailed information.

Set the Event Table Format

Click or tap the drop-down button of **Format** to select the display format of the event table. The available formats include "**Hex**", "**Dec**", "**Bin**", and "**ASCII**".

Export

When the operating status of the instrument is STOP, you can export the time and corresponding decoding data from the current event table.

Click or tap **Export** to enter the file export interface. You can export the data list to the internal memory or the external USB storage device (when detected) in "*.csv" format. The detailed export operation is similar to the save operation, you can refer to relevant descriptions in *To Store and Load*.

Interpret the LIN Decoding Frame Structure

- **Break (Sync Break):** expressed in Hex, displayed as "Break:".
- **SYNC (Sync):** expressed in Hex, displayed as "SYNC:".
- **ID (Frame ID):** expressed in Hex, displayed as "ID:".
- **Data:** Its display format is the same as that of the bus data (Hex, Dec, Bin, or ASCII), displayed as "Data:".
- **Checksum:** expressed in Hex, displayed as "Checksum:". When errors occur, it is displayed as a red patch.
- **Wakeup:** displayed as "Wakeup".

19.7 I2S Decoding (Option)

The oscilloscope samples the I2S signal, and judges each data point to be logic "1" or logic "0" according to the preset threshold level. I2S decoding is required to specify the serial clock, channel signal, and the data's source channel. You need to set Alignment, WS Low, and other parameters.

In the **Decode** menu, click or tap the drop-down button of **Bus Type** to select **I2S**, then configure the parameters for I2S decoding.




Figure 19.18 I2S Decoding Menu

Bus Status

Click or tap the ON/OFF tab for **Bus Status** to enable or disable the bus decoding.

Quickly Apply Trigger Settings to Decoding

Copy trig indicates applying the trigger settings to the specified decoding setting.

Click or tap **Copy Trig** to apply the trigger settings to the specified decoding setting.

19.7.1 Source Setting

Set the SCLK Source and Threshold

- Click or tap the drop-down button of **SCLK** to select the analog channel or the digital channel as the desired serial clock source.
- When the source is set to an analog channel, click or tap the input field of **SCLK Thre** to set the SCLK threshold with the pop-up numeric keypad. You can also use the specified multifunction knob to set the threshold. When you modify the threshold of the clock channel, a dotted line displaying the current threshold level is displayed on the screen. It disappears in about 2 s after you stop modifying the threshold.
- In **SCLK Edge** menu, click or tap to select "Rising" or "Falling" as the desired clock edge.

Set the WS Source and Threshold

- Click or tap the drop-down button of **WS** to select the analog channel or digital channel as the WS source.

- Click or tap the input field of **WS Thre** to set the WS threshold with the pop-up numeric keypad. You can also use the specified multifunction knob to set the WS threshold. When you modify the WS threshold, a dotted line displaying the current threshold level is displayed on the screen. It disappears in about 2 s after you stop modifying the threshold.

Set the SDA Source and Threshold

- Click or tap the drop-down button of **SDA** to select the analog channel or digital channel as the SDA source.
- Click or tap the input field of **Data Thre** to set the data threshold with the pop-up numeric keypad. You can also use the specified multifunction knob to set the data threshold. When you modify the data threshold, a dotted line displaying the current threshold level is displayed on the screen. It disappears in about 2 s after you stop modifying the threshold.



NOTE

For the supported channels of each model, refer to *Content Conventions in this Manual*.

19.7.2 Bus Setting

Set the Word Size

You can use the pop-up numeric keypad to set **Word Size**. Its range is from 4 to 32. You can also use the specified knob indicated in the input field to set the value.

Set the Receiver Word Size

You can use the pop-up numeric keypad to set **Receive**. Its range is from 4 to 32. Also, you can use the specified knob indicated in the input field to set the value.

Set the Endian

In **Endian** menu, click or tap to select "**LSB**" or "**MSB**". By default, it is "MSB".

Set the Alignment Mode

Click or tap the drop-down button of **Alignment** to select the alignment way for data signal. The available choices include "**I2S**", "**LJ**", and "**RJ**".

Set the Audio Polarity

Click or tap the drop-down button of **WS Low** to select "**Left**" or "**Right**".

Set the Data Polarity

In **Data Polarity** menu, click or tap to select "**Positive**" or "**Negative**".

19.7.3 Display-related Setting

In the **Decode** menu, set the following display-related parameters.

Set the Display Format

Click or tap the drop-down button of **Format** to select the display format of the bus data and that of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".

Set the Label Display

Click or tap the ON/OFF tab for **Label** to enable or disable the label display of the decoding bus. When enabled, the bus label will be displayed at the upper-left side of the bus (when the bus display is enabled). The label shows the current bus type.

19.7.4 Event Table

When the event table is enabled, the event table window of the specified decoding is displayed on the screen. The decoding information is shown in the event table.



Figure 19.19 I2S Decoding Event Table



TIP

- When you adjust the horizontal time base, the waveform displayed on the screen will also change, and the total number of lines containing the decoding information in the event table will also be changed.
- The displayed decoded data information in the bus is related to the value of the horizontal time base. Reducing the horizontal time base can help you view the detailed information.

Set the Event Table Format

Click or tap the drop-down button of **Format** to select the display format of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".

Export

When the operating status of the instrument is STOP, you can export the time and corresponding decoding data from the current event table.

Click or tap **Export** to enter the file export interface. You can export the data list to the internal memory or the external USB storage device (when detected) in "*.csv" format. The detailed export operation is similar to the save operation, you can refer to relevant descriptions in *To Store and Load*.

19.8 FlexRay Decoding (Option)

FlexRay is a type of differential serial bus configured with three consecutive segments (i.e. packet header, payload, and packet trailer). The oscilloscope samples the FlexRay signal at the specified sample position and judges each data point as logic "1" or logic "0" according to the preset threshold level. The FlexRay decoding is required to specify the signal type and baud rate.

In the **Decode** menu, click or tap the drop-down button of **Bus Type** to select **FlexRay**, then configure the parameters for FlexRay decoding.




Figure 19.20 FlexRay Decoding Menu

Bus Status

Click or tap the ON/OFF tab for **Bus Status** to enable or disable the bus decoding.

Quickly Apply Trigger Settings to Decoding

Copy trig indicates applying the trigger settings to the specified decoding setting.

Click or tap **Copy Trig** to apply the trigger settings to the specified decoding setting.

19.8.1 Signal Configuration

Set the Source and the Threshold

- The analog channel and the digital channel can all be set as the signal source. For the channel sources supported by different models, refer to *Content Conventions in this Manual*.
- When an analog channel is selected as the source, you can set the threshold for the specified channel with the pop-up numeric keypad. You can also use the specified multifunction knob to set the threshold.

When you modify the threshold of the signal source, a dotted line displaying the current threshold level is displayed on the screen. It disappears in about 2 s after you stop modifying the threshold.

Select the Signal

Click or tap "A" or "B" in **Channel** to select a channel that matches the actual FlexRay bus signal.

Specify the Signal Rate

Click or tap the drop-down button of **Baud** to select a FlexRay baud rate that matches the FlexRay bus signal. The available baud rates include "2.5 Mbps", "5 Mbps", and "10 Mbps".

Set the Signal Type

Click or tap the drop-down button of **Signal** to select a signal type that matches the actual FlexRay bus signal. The available signal types include "BP", "BM", and "RX/TX".

Sample Position

Sample position is a point within a bit's time. The oscilloscope samples the bit level at this point. The sample position is represented by the proportion of "the time from the start of the bit to the sample point" to the "bit time", as shown in the figure below.




Figure 19.21 Sample Position (FlexRay Decoding)

Click or tap the input field of **Sample Position** to set it by using the pop-up numeric keypad. You can also use the specified multifunction knob to set the value. The settable range is from 10% to 90%.

19.8.2 Display-related Setting

In the **Decode** menu, set the following display-related parameters.

Set the Display Format

Click or tap the drop-down button of **Format** to select the display format of the bus data and that of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".

Set the Label Display

Click or tap the ON/OFF tab for **Label** to enable or disable the label display of the decoding bus. When enabled, the bus label will be displayed at the upper-left side of the bus (when the bus display is enabled). The label shows the current bus type.

19.8.3 Event Table

When the event table is enabled, the event table window of the specified decoding is displayed on the screen. The decoding information is shown in the event table.




Figure 19.22 FlexRay Decoding Event Table

TIP

- When you adjust the horizontal time base, the waveform displayed on the screen will also change, and the total number of lines containing the decoding information in the event table will also be changed.

- The displayed decoded data information in the bus is related to the value of the horizontal time base. Reducing the horizontal time base can help you view the detailed information.

Set the Event Table Format

Click or tap the drop-down button of **Format** to select the display format of the event table. The available formats include "**Hex**", "**Dec**", "**Bin**", and "**ASCII**".

Export

When the operating status of the instrument is STOP, you can export the time and corresponding decoding data from the current event table.

Click or tap **Export** to enter the file export interface. You can export the data list to the internal memory or the external USB storage device (when detected) in "*.csv" format. The detailed export operation is similar to the save operation, you can refer to relevant descriptions in *To Store and Load*.

Interpret the FlexRay Decoding Frame Structure

- **TSS**: Transmit Start Sequence, displayed as "TSS:".
- **Sync Frame**: displayed as "SYNC:".
- **ID (Frame ID)**: expressed in Hex, displayed as "ID:".
- **PL (Payload Length)**: expressed in Hex, displayed as "PL:".
- **HCRC (Header Cyclic Redundancy Check)**: expressed in Hex, displayed as "HCRC:". When errors occur, it is displayed as a red patch.
- **CYC (Cycle Number)**: expressed in Hex, displayed as "CYC:".
- **Data**: Its display format is the same as that of the bus data (Hex, Dec, Bin, or ASCII), displayed as "Data:".
- **TCRC (Tail Cyclic Redundancy Check)**: expressed in Hex, displayed as "TCRC:". When errors occur, it is displayed as a red patch.

19.9 1553B Decoding (Option)

The oscilloscope samples the 1553B signal, and judges each data point to be logic "1" or logic "0" according to the preset threshold level. 1553B decoding is required to specify the data channel source and the threshold.

In the **Decode** menu, click or tap the drop-down button of **Bus Type** to select **1553B**, then configure the parameters for 1553B decoding.




Figure 19.23 1553B Decoding Menu

Bus Status

Click or tap the ON/OFF tab for **Bus Status** to enable/disable the bus decoding.

Quickly Apply Trigger Settings to Decoding

Copy trig indicates applying the trigger settings to the specified decoding setting.

Click or tap **Copy Trig** to apply the trigger settings to the specified decoding setting.

19.9.1 To Set the Data Channel Source and the Threshold

Select the Data Channel

You can select the analog channel or the digital channel as the source for **Data**. For the supported channels of each model, refer to *Content Conventions in this Manual*.

Set the Threshold

When an analog channel is selected as the source, you can set the threshold for the specified channel with the pop-up numeric keypad. You can also use the specified multifunction knob to set the threshold.

When you modify the threshold of the channel, a dotted line displaying the current threshold level is displayed on the screen. It disappears in about 2 s after you stop modifying the threshold.

19.9.2 Event Table

When the event table is enabled, the event table window of the specified decoding is displayed on the screen. The decoding information is shown in the event table.




Figure 19.24 1553B Decoding Event Table



TIP

- When you adjust the horizontal time base, the waveform displayed on the screen will also change, and the total number of lines containing the decoding information in the event table will also be changed.
- The displayed decoded data information in the bus is related to the value of the horizontal time base. Reducing the horizontal time base can help you view the detailed information.

Set the Event Table Format

Click or tap the drop-down button of **Format** to select the display format of the event table. The available formats include "Hex", "Dec", "Bin", and "ASCII".

Export

When the operating status of the instrument is STOP, you can export the time and corresponding decoding data from the current event table.

Click or tap **Export** to enter the file export interface. You can export the data list to the internal memory or the external USB storage device (when detected) in "*.csv" format. The detailed export operation is similar to the save operation, you can refer to relevant descriptions in *To Store and Load*.

Interpret the 1553B Decoding Frame Structure

- C/S:** command/status word, displayed as "C/S".
- RTA:** remote terminal address of the command/status word, displayed as "RTA:".
- C/S data:** the rest data value of the command/status word. Its display format is the same as that of the bus data (Hex, Dec, Bin, or ASCII), displayed as "C/S:".

- **Parity bit:** displayed as a yellow-green patch; when errors occur, it is displayed as a red patch.
- **Data word data:** data of the data word. Its display format is the same as that of the bus data (Hex, Dec, Bin, or ASCII), displayed as "Data:".

20 Multi-pane Windowing

This series oscilloscope supports multi-pane windowing. You can add multiple windows and result display windows for display and view.

Click or tap  > **Windows** to enter the "Add Window" menu. You can also click or tap the **Windows** icon on the toolbar menu.




Figure 20.1 Add Window Menu

Add Diagram Windows

1. First, select the desired waveform window in the **Diagram** menu, then you can preview the corresponding waveform and parameter settings at the top of the menu.
2. You can set parameters such as Source according to your needs. For details, refer to descriptions of relevant chapters.
3. Click or tap **Add** and then the selected diagram is displayed on the screen.

Add Result List Window

Click or tap **Measure**, **All Measure**, or **Decode** under the **Result List** menu. Then the results of the selected item are displayed in the preview section of the current interface. Click or tap **Add**, the measurement results window of the selected item will be displayed on the screen.

21 Waveform Recording and Playing

Records the waveforms and plays back the recorded waveforms to make an analysis of the waveforms.

To enter the waveform recording menu, perform one of the following operations.

- Click or tap the function navigation icon  at the lower-left corner of the screen to open the function navigation menu. Click or tap to select **Record** to enter the waveform recording interface.
- Click or tap the **Record** icon on the quick operation toolbar to enter the waveform recording interface.
- Press  on the front panel, then the Analyse interface is displayed. Click or tap **Record** to enter the waveform recording interface.




Figure 21.1 Waveform Recording Interface


21.1 Common Settings

Recording Operation

Click or tap the ON/OFF tab for the **Enable** menu in the Record & Play interface to enable or disable the waveform recording and playing function. Before recording the waveform, you can refer to descriptions in *Record Options* to set the waveform recording parameters.

- Click or tap the **Record** icon  to start recording the waveforms. Then the record icon turns from  to .

- The figure at the right side of the recording progress bar shows the number of currently recorded frames and the total number of frames that can be recorded (Number of Currently Recorded Frames/Total Number of Frames that can be Recorded). During the recording, the current recording information updates in a real-time manner on the screen, and the number of currently recorded frames changes constantly.
- After the recording is completed,  turns out to be  and recording stops automatically.
- During recording, you can also click or tap  to suspend recording manually.



Play Operation

Click or tap the play icon  in the **Play** menu to start to play the recorded waveforms. The play icon turns from  to the pause action icon . For details about playing, refer to descriptions in *Play Options*. During waveform playing, the value of **Current** changes dynamically. During playing, you can also click or tap the icon  again to suspend playing manually. ΔT indicates the time interval between the current frame played and the first frame.

Storage

Click or tap **Storage**, then it goes to the storage interface. For the detailed operation, refer to descriptions in *To Save the Wave* to save the recorded waveforoms based on the settings.

21.2 Record Options

During the waveform recording, the oscilloscope records the waveforms of the currently enabled channel at a specified interval until you manually stops the recording operation or the number of recorded frames has reached the set value.

Before recording the waveforms, set the following parameters.

1. Interval

Indicates the time interval between the frames during the recording process.

Click or tap the input field of **Interval** to set the interval between frames with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field to set the value. The available range is from 10 ns to 1 s.

2. Frames

Indicates the number of frames that can be recorded actually. After starting the recording operation, the oscilloscope will stop the recording operation automatically when the number of recorded frames reaches the set value.

Click or tap **Frames** to set the number of frames that can be recorded with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field to set the value. The available range is from 1 to the maximum number of frames that can be recorded currently.

3. Max Frames

Indicates the maximum number of frames that can be recorded. Click or tap **Max** which is at the right of the input field of **Frames**, and the maximum number of recorded waveform frames is automatically input into the input field of **Frames**.

As the capacity of the waveform memory is fixed, the more the number of points each frame of waveform has, the less the number of waveform frames that can be recorded. Therefore, the maximum number of recorded frames is related to the currently selected "memory depth" (refer to *Memory Depth*). The number of points per frame of waveform refers to the current memory depth. $\text{Memory Depth} \geq \text{Sample Rate} \times \text{Horizontal Time Base} \times \text{Number of Grids in the Horizontal Direction on the Screen}$. Therefore, the Max Frames value of waveform recording is also related to the "Sample Rate" and "Horizontal Time Base".

4. Beeper

Sets whether to enable the beeper after the recording process is completed.



: the beeper sounds after recording is completed.



: the beeper does not sound after recording is completed.

21.3 Play Options

Play back the waveforms currently recorded. In the **Play** section, click or tap the ON/OFF tab for the **Minimize** menu to select whether to minimize the Play operation window. If you select **ON**, the play operation window is minimized, making the interface simple, distinctive, and easy to use, as shown in the figure below.




Figure 21.2 Minimized Window of Play Operation Interface

Before playing the waveforms, set the following parameters.

1. Play Mode

Plays the waveforms in single mode (1) or cycle mode (2). Click or tap the first icon at the bottom of the Play option menu to switch the play mode.

- 1: plays from the start frame to the end frame, and then stops automatically.
- 2: plays from the start frame to the end frame, then such playback operation is repeated until you stop it manually.

2. Playback Sequence

Plays back the waveforms clockwise (3) or counterclockwise (4). Click or tap the last icon at the bottom of the Play option menu to switch the playback sequence.

- 3: plays from the start frame to the end frame.
- 4: plays from the end frame to the start frame.

3. Interval

Indicates the time interval between the frames during the playing process.

Click or tap the input field of **Interval** to set the interval between frames with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field to set the value. The available range is from 1 ms to 1 s.

4. Start Frame

Click or tap the input field of "Start Frame" shown in *Figure 21.2* to set the start frame to be played back with the pop-up numeric keypad. You can also rotate the

specified multifunction knob indicated in the input field to set the value. The default is 1, and the maximum value is the maximum number of waveform frames that have been recorded.

5. End Frame

Click or tap the input field of "End Frame" shown in *Figure 21.2* to set the end frame to be played back with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field to set the value. The default value is the number of waveform frames that have been recorded.

6. Current Frame

When stopping playing back, click or tap the input field of **Current** shown in *Figure 21.2* to set the currently displayed frame with the pop-up numeric keypad. You can also rotate the specified multifunction knob indicated in the input field to set the value. The max. value for the current frame is the max. number of frames that have been recorded.

22 Search and Navigation Function

The search function can help you quickly locate the concerned events and make a mark. Then, you can use the specific navigation arrow keys to quickly locate the specified event. The search type can be set to Edge or Pulse.

The navigation function guides users to quickly locate and view the specified waveforms. You can navigate by time and event.

22.1 Search Function

The search function allows you to search the specified Edge or Pulse event, then marks it with an upside-down triangle icon (▼).

To enter the Search menu, perform any of the following operations:

- Click or tap the function navigation icon  at the lower-left corner of the screen to enter the function navigation. Click or tap **Search** to enter the search menu.
- Click or tap **Search** in the Navigation interface to enter the search menu.




Figure 22.1 Search Menu

Enable or Disable the Search Function

Click or tap the ON/OFF tab for **Search** to enable or disable the search function.

**TIP**

When the search function is enabled, *Zoom Mode (Delayed Sweep)* is automatically enabled.

Select the Search Type

Selects "Edge" or "Pulse" as the search type.

- **Edge search:** After selecting "Edge" as the search type, set the edge type and threshold. For detailed setting methods, refer to *Edge Trigger*.
- **Pulse search:** After selecting "Edge" as the search type, set the pulse polarity, search condition, and threshold. For detailed setting methods, refer to *Pulse Trigger*.

Set the Source

Selects an analog channel as the source of the search function. For the channel sources supported by different models, refer to *Content Conventions in this Manual*.

Copy Trigger

- **To Trigger**
Click or tap **To Trigger** to copy the selected search type settings to the same trigger type. For example, if the current search type is "Edge", clicking or tapping **To Trigger** can copy the edge search settings to the "Edge Trigger" settings.
- **From Trigger**
Click or tap **From Trigger** to copy the trigger settings to the specified search type settings. For example, if the current trigger type is "Edge Trigger", click or tap **From Trigger** to copy the Edge trigger settings to the "Edge" search settings.

**NOTE**

If you select "From Trigger", you need to set the search type first, and then copy the trigger type settings from the trigger menu.

Enable or Disable the Marker Table

When the marker table is enabled, the marker table is displayed, as shown in the figure below. The marker table lists the marker events of the waveforms displayed in the current waveform view. When you zoom or pan to adjust the waveforms, the events in the marker table will change. You can perform the following operations on the marker table.

- When the instrument is in STOP status, click or tap any row in the marker table to select the specified event. The upside-down triangle that marks the selected event turns red (▼).

- Click or tap the icon  at the upper-right corner of the marker table to open the Search menu.
- Clicking on the marker table title bar indicated in gray and long holding the mouse to drag the marker table to adjust its position on the screen.
- Click or tap the icon  at the upper-right corner of the table to close the marker table.

Search   			
Index	Time	EventCount	Info
1	-50us	1	Rising edge
2	-49.59us	1	Rising edge
3	-48.79us	1	Rising edge
4	-47.99us	1	Rising edge
5	-47.19us	1	Rising edge
6	-46.39us	1	Rising edge
7	-45.59us	1	Rising edge
8	-44.79us	1	Rising edge
9	-43.99us	1	Rising edge
10	-43.19us	1	Rising edge

Figure 22.2 Marker Table

Navigation

Click or tap **Navigation** to go to the navigation interface. You can also refer to *Navigation Function* to navigate by search event.

Save the Search Event

You can save the event marker data to the internal memory or external USB storage device in "*.csv" format.

Click or tap **Save Events** to enter the event saving interface. Please refer to descriptions in *To Save a File* to save the event marker data to the internal or external memory.

NOTE

This series oscilloscope only supports the flash memory USB storage device of FAT32 format.



22.2 Navigation Function

The navigation function includes the time navigation and search event navigation. To enter the **Navigation** interface, perform any of the following operations:

- Press  on the front panel to enter the "Navigation" menu.
- Click or tap the **Navigate** icon on the toolbar at the upper-right part of the screen to enter the Navigation menu.
- In the Search interface, click or tap the **Navigation** button to enter the Navigation setting menu.




Figure 22.3 Navigation Menu

Clicking or tapping the icon  can minimize the Navigation window, making the interface simple and clear, as shown in the figure below.




Figure 22.4 Minimized Navigation Window (Time Navigation)



NOTE

The navigation function is only available when the operating status of the oscilloscope is STOP.

Time Navigation

After stopping data acquisition, use the navigation control buttons in the Navigation interface to play forward and backward the captured waveforms. You can also use the navigation combination keys    on the horizontal control area on the front panel to control the waveforms.

- After selecting time navigation, click or tap  to start to play the waveforms.

- During the play, click or tap  to play backward, then stops automatically until it plays back to the start; click or tap  to play forward, then stops automatically until it reaches the end.
- When it stopped playing, click/tap  or  to move backward or forward the waveforms.
- Click or tap  to go to the start segment of the waveforms to be played. Click or tap  to go to the last segment of the waveforms to be played.

Click or tap the drop-down button of **Speed** to select the play speed of the waveforms.

Search Event Navigation

When you enable the navigation function and complete the event search, you can use the navigation combination keys to quickly navigate the specific event in the event mark table.




Figure 22.5 Search Event Navigation Interface

After selecting the "Search Event" navigation, click or tap **Search** to set the search conditions.

The search event type can be set to "Edge" or "Pulse", which shall be consistent with the search type specified in **Search** menu.

Click or tap  to navigate to the previous event (the serial number in the mark table decreases); click or tap  to navigate to the next event (the serial number in the

mark table increases); click or tap  to go to the first event; click or tap  to go to the last event.

23 Display Control

In the **Display** setting menu, you can set the type, persistence time, waveform intensity, grid type, grid brightness, and etc. Click or tap the function navigation icon



at the lower-left corner of the screen, and then select **Display** to enter the

"Display" menu. You can also click or tap the icon at the upper-right of the Waveform View to enter the "Display" menu.




Figure 23.1 Display Setting Menu

23.1 Display Type

This series oscilloscope provides the "Vector" display mode in which the sample points are connected by lines and displayed. In most cases, this mode can provide the most vivid waveform for you to view the steep edge of the waveform (such as square waveform).

23.2 Persistence Time

In the **Display** setting menu, click or tap the drop-down button of **Persistence Time** to select the persistence time from the drop-down list. The available values are Min, variable persistence (100 ms, 200 ms, 500 ms, 1 s, 2 s, 5 s, 10 s), and Infinite.

The following section illustrates the waveform effects of the frequency sweep signal of the Sine waveform when you make a different choice in persistence time.

- **Min**

Enables you to view waveform changing in high refresh rate.

- **Variable Persistence**

Enables to view glitches that change relatively slowly or glitches with lower occurrence probability after a certain amount of persistence time that you set. The persistence time can be set to 100 ms, 200 ms, 500 ms, 1 s, 2 s, 5 s, or 10 s.

- **Infinite**

In this mode, the oscilloscope will never clear the previous acquisitions of the waveforms while acquiring the new waveforms. The previous acquisitions of the waveforms will be displayed in relatively low-brightness color and the newly acquired waveforms will be displayed in normal brightness and color. You can use infinite persistence to measure noise and jitter and to capture events that occur infrequently.

23.3 Waveform Intensity

In **Display** menu, drag the slide bar of **Wave Intensity** to set the brightness of waveforms. The default is 50%, and the range available is from 1% to 100%.

23.4 To Set the Screen Grid

In the **Display** setting menu, click or tap "FULL", "HALF", or "NONE" for the **Grid** menu.



- **FULL:** turns the background grid and main coordinates on.
- **HALF:** turns the main coordinates off, with the background grid on.
- **NONE:** turns the background grid and main coordinates off.

23.5 Display Setting

Grid Brightness

In the **Display** setting menu, drag the slide bar of **Grid Brightness** to set the grid brightness. The default is 50%, and the range available is from 0% to 100%.

Window Transparency

In the **Display** setting menu, drag the slide bar of **Window Transparency** to set the window transparency. The default is 50%, and the range available is from 0% to 100%.

Cursor Brightness

In the **Display** setting menu, drag the slide bar of **Cursor Brightness** to set the cursor brightness. The default is 80%, and the range available is from 0% to 100%.

23.6 Show Scale

In the **Display** setting menu, click or tap the ON/OFF tab for **Show Scale** to enable or disable the scale display on the screen. By default, it is ON.

23.7 Color Grade

In the **Display** setting menu, click or tap the ON/OFF tab for **Color Grade** to enable or disable the color grade. By default, it is OFF.

When enabled, different colors are displayed on the screen to indicate the times of data acquisition or acquisition probability.

23.8 Waveform Freeze

In the **Display** setting menu, click or tap the ON/OFF tab for **Waveform Freeze** to enable or disable the waveform freeze function. By default, it is ON.

When enabled, the oscilloscope displays the waveform that has undergone multiple samplings and superpositions after sampling is stopped when you click or tap the

STOP/RUN icon on the quick operation toolbar or press  on the front panel. If disabled, the last triggered waveform is displayed.

24 To Store and Load

You can save the current setups, waveforms, screen image, and parameters of the oscilloscope to the internal memory or external USB storage device (such as USB storage device) in various formats and recall the stored setups or waveforms when necessary. You can also load the upgrade software to the system and perform the upgrade operation for the instrument.

You can also copy, delete, or rename the specified type of file from the internal memory or external USB storage device via the disk management menu.

This oscilloscope provides two USB HOST interfaces on the front panel, which can all be connected to the USB storage device for external storage. The USB storage devices connected are marked as "Removable USB Disk (D)" and "Removable USB Disk (E)".



TIP

This oscilloscope only supports the flash memory USB storage device of FAT32 format.

24.1 To Enter the Storage Menu

You can enter the storage setting menu in the following ways.

- Click or tap the function navigation icon  at the lower-left corner of the screen, and then select **Storage** to enter the storage setting menu.
- Click or tap the **Storage** button on the toolbar to enter the storage setting menu.

In the **Storage** setting menu, there are three sub-menus (Save, Load, and Upgrade) for you to choose. Select the specified sub-menu and configure the corresponding parameters.

24.2 To Save a File

In the Storage interface, click or tap the **Save** tab to enter the file saving menu.




Figure 24.1 Storage Menu

This oscilloscope allows you to save the image, waveforms, and setup files in various format. After completing the parameter settings, save the file according to the following steps.

1. Click or tap the input field of **File Name**, then input the filename with the pop-up virtual keypad.
2. Click or tap the input field of **File Path**, then the disk management interface is displayed. In the disk management interface, select the destination storage path, then click or tap **OK** to set the storage path for the saved file. For the disk management operation, refer to descriptions in *Disk Management*.

When no USB storage device is inserted, by default, the storage path is "Local Disk". When a USB storage device is detected, "D:" automatically appears in the file path.

3. Click or tap the ON/OFF tab for **Overlay** to enable or disable the file overwriting. When enabled, the existing file in the specified file path will be overwritten by the newly saved file that has the same filename as the existing one.
4. Click or tap **Save** to save the file based on the current settings. Then the storage menu is closed.



NOTE

The filename can contain letters, numbers, and other non-Chinese characters. The length of the filename shall not exceed 16 characters. Neither the file name nor file path shall contain any special characters such as "#" and ",".

24.2.1 To Save the Image

In the Storage interface, click or tap the **Save** tab to enter the Save interface. Click or tap the drop-down button of **Choose** to select **Save Image**. The screen image will be saved to the internal or external memory based on the settings, as shown in *Figure 24.1*.

Image Format

Click or tap the drop-down button of **Format** to select **".png"**, **".bmp"**, or **".jpg"**. Then the screen image will be saved to the internal or external memory in **".png"**, **".bmp"**, or **".jpg"** format.

Invert

Click or tap the ON/OFF tab for **Invert** to enable or disable the image invert function.

Color

Press **Color** to select the desired storage color. It can be set to **"Gray"** or **"Color"**.

Header

Click or tap the ON/OFF tab for **Header** to enable or disable the display of the header. If you select **"ON"**, the instrument model and the image creation date will be displayed in the header of the image when you save the image file.



TIP

Refer to *Quick Operation*. When the quick operation type is set to **"Save Image"**, or set to **"Save Group"** with **"Save Image"** being selected, pressing the front-panel quick operation key  can quickly save the image.

24.2.2 To Save the Wave

In the **Storage** menu, click or tap the **Save** tab to enter the save operation menu. In this menu, click or tap the drop-down button of **Choose** to select **"Save Wave"** to enter the **"Save Wave"** setting menu. The main setting information (e.g. **"On/Off"** state of the channel, vertical scale, and horizontal time base) and waveform data of all enabled channel will be saved to the internal or external memory.




Figure 24.2 Waveform Saving Setting Menu

Sets the Source of Waveform Data

The available sources of the waveform data are as follows:

- **Screen:** waveforms displayed on the screen.
- **Memory:** waveforms from the memory.
- **Record:** waveforms that have been recorded. For details about the recorded waveforms, refer to *Waveform Recording and Playing*.

Set the Format

The available formats of the waveform data are as follows:

- When the data source is "Screen", the available formats are "*.bin" and "*.csv".
- When the data source is "Memory", the available formats are "*.bin", "*.csv", and "*.wfm".
- When the data source is "Record", the available format is "*.csv".

TIP

Refer to *Quick Operation*. When the quick operation type is set to "Save Wave", or set to "Save Group" with "Save Wave" being selected, pressing the front-panel quick operation key  can quickly save the waveform file.

24.2.3 To Save the Setup

In the **Storage** menu, click or tap the **Save** tab to enter the save operation menu. In this menu, click or tap the drop-down button of **Choose** to select "**Save Setup**" to enter the "Save Setup" setting menu. The settings of the oscilloscope can be saved to the internal or external memory in "*.stp" format. The saved setup files can be loaded from the specified path when you perform the loading operation.




Figure 24.3 Setup Saving Setting Menu

Refer to *Quick Operation*. When the quick operation type is set to "Save Setup", or set to "Save Group" with "Save Setup" being selected, pressing the front-panel quick operation key  can quickly save the setup file.

24.2.4 Binary Data Format (.bin)

Binary data format stores waveform data in binary format and provides data headers that describe these data. As data are displayed in binary format, its file size is much more smaller than that in ASCII format. If several channels are enabled, then all the displayed channels will be saved (save the first channel then save the second, and then it goes on like this until all the displayed channels are saved).

Table 24.1 BIN File Format

File Header	Waveform Header	Waveform Data Header	Channel Data	Waveform Header	Waveform Data Header	Channel Data
-------------	-----------------	----------------------	--------------	-----------------	----------------------	--------------

16 Bytes	140 Bytes	16 Bytes	n Bytes	140 Bytes	16 Bytes	n Bytes
----------	-----------	----------	---------	-----------	----------	---------

In BIN file format, it contains the following channel data:

- CH1 Data
- CH2 Data
- CH3 Data
- CH4 Data
- Math Waveform Data

Binary Header Format

1. File Header

There is only one file header in a binary file. The file header contains the following information.

Table 24.2 File Header

Cookie	Two-byte characters, RG, indicating that the file is the RIGOL binary data file format.
Version	Two-byte, indicating the file version.
File Size	An 8-byte long integer, indicating the number of bytes in the file. It includes the header.
Number of Waveforms	A 4-byte integer, indicating the number of waveforms that are stored in the file.

2. Waveform Header

It is possible to store several waveforms in the file. Each stored waveform has a waveform header. When several channels are stored, each channel can be considered as a separate waveform. The waveform header contains the information about the type of waveform data that are stored following the waveform data header.

Table 24.3 Waveform Header

Header Size	A 4-byte integer, indicating the number of bytes in the header.
Waveform Type	A 4-byte integer, indicating the type of the waveform stored in the file. It is fixed to 1. - 0 = Unknown

	- 1 = Normal - 2 = Peak Detection - 3 = Average - 4 = Not Used - 5 = Not Used - 6 = Logic
Number of Waveform Buffers	A 4-byte integer, indicating the number of waveform buffers required to read the data. It is fixed to 1.
Number of Points	A 4-byte integer, indicating the number of waveform points in the data.
Count	A 4-byte integer. It is fixed to 0.
X Display Range	A 4-byte float, indicating the X-axis duration of the waveform that is displayed. For time-domain waveforms, it indicates the duration of the display. If the value is zero, then no data has been acquired.
X Display Origin	An 8-byte double-precision floating-point, indicating the X-axis value at the left edge of the screen. For time-domain waveforms, it indicates the time at the start of the display. The value is treated as a double precision 64-bit float point number. If the value is zero, then no data has been acquired.
X Increment	An 8-byte double-precision floating-point, indicating the duration between data points on the X-axis. For time-domain waveforms, it indicates the time between points. If the value is zero, then no data has been acquired.
X Origin	An 8-byte double-precision floating-point, indicating the X-axis value of the first data point in the data recording. For time-domain waveforms, it indicates the time of the first point. The value is treated as a double precision 64-bit float point number. If the value is zero, then no data has been acquired.
X Units	A 4-byte integer, indicating the unit of measurement for X values in the acquired data. It is fixed to 2. - 0 = Unknown - 1 = Volts (V) - 2 = Seconds (s) - 3 = Constant - 4 = Amps (A) - 5 = Decibel (dB) - 6 = Hertz (Hz)

Y Units	A 4-byte integer, indicating the unit of measurement for Y values in the acquired data. The possible values are listed above under X Units.
Date	A 16-byte character array, indicating the date when the file is saved.
Time	A 16-byte character array, indicating the time when the file is saved.
Model	A 24-byte character array in the format of MODEL#:SERIAL#, indicating the oscilloscope's model and serial number.
Channel Name	A 16-byte character array that contains the label assigned to the waveform.

3. Waveform Data Header

A waveform may have multiple data sets. Each waveform data set has a waveform data header. The waveform data header consists of information about the waveform data set. The header is stored before the data set.

Table 24.4 Waveform Data Header

Header Size	A 4-byte integer, indicating the number of bytes in the waveform data header.
Buffer Type	A 2-byte integer, indicating the type of the waveform data stored in the file. - 0 = Unknown - 1 = Normal 32-bit float data - 2 = Maximum float data - 3 = Minimum float data - 4 = Not Used - 5 = Digital unsigned 8-bit character data (for digital channels)
Bytes Per Point	A 2-byte short integer, indicating the number of bytes per data point.
Buffer Size	An 8-byte long integer, indicating the number of bytes of the current channel waveform data.

24.3 To Upload the File via the FTP Server

Use the USB storage device to copy the file from the PC to the local disk of the oscilloscope. You can also upload it via the FTP server to the local disk of the oscilloscope. The operation procedures are as follows:

1. Connect the oscilloscope to the network via the LAN interface. Then obtain the IP address. For example, 192.68.0.1.
2. Open the file explorer of the PC or the browser, then input "ftp://192.68.0.1/" (quotation marks not included) into the address bar to access the file manager of the oscilloscope.
3. Copy the file from the PC to the file manager of the oscilloscope. After uploading the file, you can view the file in the disk management interface of the oscilloscope.



NOTE

When you choose to upload the file via the FTP server, note that the name of the file that you upload shall not contain any Chinese characters.

24.4 To Load the Setup File

In the Storage interface, click or tap the **Load** tab to switch to the load menu. Under this menu, you can load the setup file to the instrument from the internal or external memory.




Figure 24.4 Setup File Loading Interface

To load the setup file, perform the following procedures.

1. Click or tap the drop-down button of **Choose** to select "Load Setup". By default, only "Load Setup" is available for you to choose currently.
2. Click or tap the drop-down button of **Choose** to select "*.stp". The default file type is "*.stp", and no other options are available.
3. Click or tap the input field of **File Path**. Then *Disk Management* is displayed. You can select the desired setup file from the specified file path.
4. Click or tap **Load** to load the setup file to the oscilloscope. Then the setup parameters of the oscilloscope will be loaded and updated to keep consistent with that in the setup file.

24.5 Upgrade

This instrument supports local upgrade and online upgrade.

Local Upgrade

1. In the storage setting menu, click or tap **Upgrade** to enter the local upgrade setting menu.




Figure 24.5 Upgrade Menu

2. Click or tap the input field of **File Path**, then the disk management interface is displayed. Select the upgrade file. For detailed operations, refer to descriptions in *Disk Management*.
3. Click or tap **Upgrade** to complete the local upgrade.

Online Upgrade

1. First ensure that the rear-panel LAN interface is connected to the network (if you do not have the access to the Internet, please ask the administrator to grant you permission to access the network).
2. Click or tap the function navigation icon  at the lower-left corner of the screen to enter the function navigation.
3. Then click or tap the **Upgrade** icon to perform the upgrade operation.

24.6 Disk Management

To enter the storage setting menu, perform the following operations:

- Click or tap the function navigation icon  at the lower-left corner corner of the screen, and then select **Storage** to enter the storage setting interface.
- Click or tap the **Storage** icon on the quick operation toolbar to enter the storage setting interface.

In the storage setting interface, click or tap **Disk** to enter the disk management interface.




Figure 24.6 Disk Management Interface

In the disk management menu, you can perform the following operations:

Select a Disk

Before using the external storage device, make sure that a USB storage device (FAT32 format, flash memory) is connected properly.

By default, Local Disk (Disk C) is displayed. If an external storage device is inserted, the available disks include "Local Disk (C)", "Removable USB Disk (D/E...)". If you select an external storage device, for example, Removable USB Disk (D), you can view the storage contents in it.

Create a Folder

Click or tap **New Folder**, then a folder name input keyboard is displayed.

For the name input method, refer to descriptions in *Parameter Setting Method*. Click or tap any place on the Storage interface to exit the keyboard interface.

Clear the Internal Memory

In the Disk interface, click or tap **Safe Clear**, then a prompt message "Clear all data from the internal memory?" is displayed. Click or tap **Yes** to confirm the clear operation. Click or tap **No** to cancel safe clear operation.

Select the File

Before operating on the file or folder, first select the desired file or folder.

Click or tap the check box at the right side of the folder, if checked, it is selected, with

an icon  being displayed. Click/tap the check box again or click/tap  to deselect it. The check box restores its original state.

You are allowed to select multiple files or folders in one time to perform the relevant operation. You can also click or tap the icon  at the upper-right corner of the interface to select all the files and folders under the current disk. Click or tap  to cancel the select-all operation.

Cut, Copy, and Paste a File or a Folder

- **Cut a File or a Folder to a Destination Path**

Select a specified file or a folder. Click or tap **Cut**, then select a destination path. Click or tap **Paste** to paste the desired file or folder to the destination path, and complete the operation.

- **Copy a File or a Folder to a Destination Path**

Select a specified file or a folder. Click or tap **Copy**, then select a destination path. Click or tap **Paste** to paste the desired file or folder to the destination path, and complete the operation.

Delete a File or a Folder

In the current folder, select the file or folder to be deleted. Click or tap **Delete**, then a prompt message "Are you sure to delete the file?" is displayed. Click or tap **OK** to delete the file. Click or tap **Cancel** to cancel the deletion operation.

Rename a File or a Folder

Select a specified file or a folder, then click or tap **Rename** to input a new filename or folder name with the pop-up numeric keypad. Then, the rename operation is completed.

25 System Utility Function Setting

In the **Utility** menu, you can set the I/O parameters and the system-related function parameters. You can enter the "Utility" menu in the following ways.

- Click or tap the Notification Area at the lower-right corner of the screen. Then the **Utility** menu is displayed.
- Click or tap the function navigation icon  at the lower-left corner of the screen, and then select **Utility** to enter the **Utility** menu.

25.1 I/O Setting

In the **Utility** menu, click or tap **I/O** to enter the I/O setting menu to configure the following parameters.

Network Status

Different prompts will be displayed according to the current network connection status.

- Network Config Succeeded!
- Acquiring IP...
- IP Conflict!
- DISCONNECTED!
- DHCP Config Failed
- Read Status Fail!
- CONNECTED
- Invalid IP
- IP lost
- Please wait...

MAC Address

The MAC address of each oscilloscope is unique. When assigning the IP address for the oscilloscope, the system uses the MAC address to identify the instrument.

VISA Address

Displays the VISA address currently used by the the instrument.

IP Configuration Type

The configuration type of the IP address can be DHCP, Auto IP, or Static IP. In different IP configuration types, the configurations for IP address and other network parameters are different.

- **DHCP**

If "DHCP" is selected, the DHCP server in the current network will assign the network parameters (e.g. IP address, Subnet, Gateway, and DNS) for the instrument.

- **Auto IP**

When "Auto IP" is selected, the instrument will acquire the IP address ranging from "169.254.0.1" to "169.254.255.254" and the subnet mask (255.255.0.0) automatically based on the current network configuration. The "Auto IP" works only when "DHCP" is not selected or connection is failed.

- **Static IP**

If "Static IP" is selected, the instrument is configured with static IP. In this case, you need to disable DHCP and Auto IP manually. At this time, you need to set the IP address, Subnet, Gateway, and DNS manually. At this time, you can self-define the network parameters (e.g. IP address) of the instrument.

- **Set the IP address**

The format of the IP address is nnn.nnn.nnn.nnn. The range of the first segment (nnn) of the address is from 0 to 255 (except 127); wherein, the valid range is from 0 to 223. The range for the other three segments is from 0 to 255. You are recommended to ask your network administrator for an IP address available.

This setting will be saved to the non-volatile memory. If "Load Last" is set to "Last", then DHCP and Auto IP are disabled at the next power-on, and the instrument will load the IP address that you set last time automatically.

- **Set the subnet mask**

The format of the subnet mask is nnn.nnn.nnn.nnn. Wherein, the range of first segment (nnn) of the address is from 0 to 255. You are recommended to ask your network administrator for a subnet mask available.

This setting will be saved in the non-volatile memory. If "Load Last" is set to "Last", then DHCP and Auto IP are disabled at the next power-on, and the instrument will load the subnet mask that you set last time automatically.

- **Set the default gateway**

You can set this parameter in Static IP mode. The format of the gateway is nnn.nnn.nnn.nnn. The range of the first segment (nnn) is from 0 to 223 (except 127), and the range for the other three segments is from 0 to 255.

You are recommended to ask your network administrator for a gate address available.

This setting will be saved in the non-volatile memory. If "Load Last" is set to "Last", then DHCP and Auto IP are disabled at the next power-on, and the instrument will load the subnet mask that you set last time automatically.

- Set the DNS address

You can set this parameter in Static IP mode. The format of the DNS address is "nnn.nnn.nnn.nnn". The range for the first segment (nnn) of the address is from 0 to 223 (except 127); and the range for the other three segments is from 0 to 255. You are recommended to ask your network administrator for an address available.

Generally, you do not need to set the DNS, therefore this parameter setting can be ignored.



TIP

- When the three IP configuration types are all turned on, the priority of the parameter configuration from high to low is "DHCP", "Auto IP", and "Static IP".
- The three IP configuration types cannot be all turned off at the same time.

mDNS

Click or tap the ON/OFF tab for **mDNS** to enable or disable the multicast Domain Name System (mDNS). This system is used to provide the function of DNS server for service discovery in a small network without a DNS server.

Host Name

The length of the host name is a string of 26 characters at most.

GPIOB

When controlling the instrument via the GPIOB, first use the USB-GPIB module to extend a GPIB interface, then use the GPIB cable to connect it to the PC. Configure the GPIB address. Its settable range is from 1 to 30. By default, it is 1.

Apply the Network Parameter Setting

Click or tap **Apply** to apply the current network parameter setting.

25.2 Basic Settings

In the **Utility** menu, click or tap **Setup** to enter the basic setting menu.

Language

This product supports menus in multiple languages. The help information, prompt messages, and interface can be displayed in multiple languages. Click or tap the

drop-down button of **Language** to select the specified system language from the drop-down list.

Screen Brightness

Drag the slide to set the screen brightness. Its range is from 1% to 100%.

Load Last

You can set the system configuration to be recalled when the oscilloscope is powered on again after power-off. Click or tap "Default" or "Last" for **Load Last**.

- Last: restores the system to its last setting at last power-off.
- Default: restores the system to its factory setting.

Power Status

- Switch Off: After the oscilloscope is connected to power, you need to press the Power key on the front panel to power on the instrument.
- Switch On: After the oscilloscope is connected to power, it will be powered on automatically.

Beeper

Click or tap the ON/OFF tab for **Beeper** to enable or disable the beeper. When the beeper is enabled, you can hear the sound of the beeper when you perform the following operations:

- Press a key or a menu key on the front panel
- Operate on the touch screen
- When a prompt message is displayed

AUX Out

Click or tap to select the desired signal type output from the rear-panel **[AUX OUT]** connector. The available signal types are "TrigOut" and "PassFail".

- **TrigOut:** After this type is selected, at each trigger (hardware trigger), the oscilloscope outputs a signal from the **[AUX OUT]** connector on the rear panel that can reflect the current capture rate of the oscilloscope. If this signal is connected to a waveform display device to measure the frequency, it can be found that the measurement result is the same as the current capture rate.

When the AUX Out menu is set to "TrigOut", then in the pass/fail test menu (click or tap  > **Pass/Fail** to enter the pass/fail test menu), the **Aux Output** menu item is automatically disabled.

- **PassFail:** After this type is selected, the instrument can output a positive or negative pulse via the **[AUX OUT]** connector when a successful or failed event is detected.

When the AUX Out menu is set to "PassFail", then in the pass/fail test menu

(click or tap  > **Pass/Fail** to enter the pass/fail test menu), the **Aux Output** menu item is automatically enabled. For the parameter settings such as pulse width, polarity, and output event of the pulse signal output from the connector, you can set it in the "Option" menu of the "PassFail" interface. For details, refer to *To Set the Output Form of the Test Results*.

Operation Lock

When enabled, both the touch screen operation and the front-panel keys except the Power key are disabled. You cannot operate with the touch screen and front-panel keys and knobs.

To unlock the operation, press the front-panel channel keys CH1 () , CH3 () , CH2 () , and CH4 () in sequence to unlock the operation.

Vertical Expansion

Click or tap to select the way to expand or compress the waveform. It can be set to "Center" or "GND".

- Center: when the vertical scale is changed, the waveform will be expanded or compressed around the screen center.
- GND: when the vertical scale is changed, the waveform will be expanded or compressed around the signal ground level position.

Display Time

Click or tap the ON/OFF tab for **Display Time** to enable or disable the display of the system time. When enabled, the system time (date and time) is displayed in the Notification Area at the lower-right corner of the screen. The date is displayed in "yyyy/mm/dd" format, and the time is displayed in "hh:mm:ss" format. You can enable or disable the display of system time when saving the waveform. When enabled, the saved file will contain the system time information.

- **Date:** Click or tap the "Date" area, then the date setting interface is displayed. Drag the year, month, and day section up and down respectively to set the date. Click or tap **OK** to confirm the date modification. Click or tap the close window icon  to cancel the date modification and exit the menu. You can also click or tap any place other than the date setting interface to exit the date modification menu.

- **Time:** Click or tap the "Time" area, then the time setting interface is displayed. Drag the hour and minute section up and down respectively to set the time. Click or tap **OK** to confirm the time modification. Click or tap the close window icon  to cancel the time modification and exit the menu. You can also click or tap any place other than the time setting interface to exit the time modification.

25.3 About this Oscilloscope

In **Utility** menu, click or tap **About**, and then you can view the model, version, and other information about this instrument in **About** menu.

- **Model**
Indicates the product model.
- **Serial Number**
Indicates the serial number, the unique identification for the product.
- **Firmware**
Indicates the firmware version number of the product.
- **Hardware**
Indicates the hardware version number of the product.
- **Build**
Indicates the creation time of the software version.
- **Android.Build**
Indicates the creation time of the Android operating system.
- **Android.Version**
Indicates the version number of the Android operating system. For example, 7.1.0.
- **Launcher**
Indicates the desktop UI version number of the Android operating system.
- **WebControl**
Indicates the version number of browser remote control module.

25.4 Other Settings

EXT 10M IN

Indicates the rear-panel **[10MHz REF IN]** reference clock input interface. When ON, the interface is enabled; when OFF, the interface is disabled.

Open Source Acknowledgment

Click or tap **Open Source Acknowledgment** to open the Open Source Acknowledgment of this series oscilloscope.

25.5 Auto Config

In the "Utility" menu, click or tap **Auto Config** to enter the Auto Config menu. You can configure the **Auto** function.

- Click or tap the ON/OFF tab for **Peak to Peak** to enable or disable the peak-peak priority setting. This function is intended for the shifted signal. If there is a large deviation, you can view the signal waveform in priority when you enable the function.
- Click or tap the ON/OFF tab for **Live CH** to enable or disable test the enabled channel.

If you select "OFF", the system will test all analog channels in sequence when performing AUTO operation. If no signal is found on the channel, then the channel is disabled. If a signal is found on the channel, the channel will be adjusted to an optimal scale to show the signal. If you select "ON", the system will only test the enabled channels when performing AUTO operation.

- Click or tap the ON/OFF tab for **Overlay** to enable or disable the waveform overlay display function. If enabled, waveforms of the different channels will be overlaid on the screen when you perform auto setting. If disabled, waveforms of different channels will be displayed on the screen from top to bottom in sequence.
- Click or tap the ON/OFF tab for **Keep Coupling** to enable or disable the channel coupling keeping. If enabled, the settings for the channel coupling remain unchanged when you perform the auto setting operation. If disabled, the channel is DC-coupled by default.

25.6 SelfCal

The self-calibration program can quickly make the oscilloscope to work in an optimal state to get the precise measurement results. You can perform self-calibration at any time, especially when the temperature variation is $\pm 5^{\circ}\text{C}$ from the ambient temperature. Make sure that the oscilloscope has been warmed up or operating for more than 30 minutes before the self-calibration.

In "Utility" menu, click or tap **SelfCal**, the following self-calibration interface is shown below.




Figure 25.1 Self-calibration Menu

- Click or tap **Start**, and then the oscilloscope will start to execute the self-calibration program.
- After starting the self-calibration program, click or tap **Exit** to cancel self-calibration operation at any time.
- Click or tap **Close** to close the self-calibration information window.

25.7 Option List

In the **Utility** menu, click or tap **Options** to view all the options. For the procedures of installing the option, refer to descriptions in *To View the Option Information and the Option Installation*.

25.8 Quick Operation

In the **Utility** menu, click or tap **Quick** to enter the quick setting operation menu.

To Save Image

- Click or tap **Save Image**, and the current **Operation** menu shows "Save Image".
- In the **Format** menu item, the available image type can be **".png"**, **".bmp"**, or **".jpg"**.
- Click or tap the ON/OFF tab for **Invert** to enable or disable the invert function.
- Click or tap **"Color"** or **"Gray"** for **Color** to select the desired storage color.

After configuring the settings, press  on the front panel to capture the current screen image and save it based on your settings of the image to be saved. The storage path is where you set the **File Path** under the **Storage** menu. For the settings of the storage path, refer to descriptions in *To Save a File*.

To Save Wave

- Click or tap **Save Wave**, and the current **Operation** menu shows "Save Wave".
- Click or tap to select "**Memory**", "**Screen**", or "**Record**" (only available when Record function is enabled and recorded waveforms are available) under **Data Source** as the source of waveforms to be saved.
- The available choices under **Format** include "*.bin" and "*.csv".

After configuring the settings, press  on the front panel to capture the current waveform and save it based on your settings of the waveforms to be saved. The storage path is where you set the **File Path** under the **Storage** menu. For the settings of the storage path, refer to descriptions in *To Save a File*.

Save Setup

Click or tap **Save Setup**, and the current **Operation** menu shows "Save Setup".

After configuring the settings, press  on the front panel to save the current settings of the oscilloscope as a file suffixed with "*.stp". The storage path is where you set the **File Path** under the **Storage** menu. For the settings of the storage path, refer to descriptions in *To Save a File*.

Perform All Measurement

- Click or tap **All Measure**, and the current **Operation** menu shows "All Measure".
- The available channels under **All Measure** are CH1-CH8.

After configuring the settings, press  on the front panel to perform the measurement for the specified channel.

Reset Statistics

- Click or tap **Stat Reset**, and the current **Operation** menu shows "Stat Reset".
- Under **Stat Reset**, click or tap "Measure" or "Pass/Fail" to reset the statistics of the specified function.

After configuring the settings, press  on the front panel to reset the result list of the specified function. Then the instrument restarts to make statistics.

Record Waveforms

Click or tap **Record**, and the current **Operation** menu shows "Record".

After configuring the settings, press  on the front panel to record the waveforms.

Save Group

- Click or tap **Save Group**, and the current **Operation** menu shows "Save Group".
- Under **Save Group**, select one or multiple items from the three options: "**Save Image**", "**Save Wave**", and "**Save Setup**".

After configuring the settings, press  on the front panel to save the specified type based on your choice. The storage path is where you set the **File Path** under the **Storage** menu. For the settings of the storage path, refer to descriptions in *To Save a File*.

25.9 Self-check

In the **Utility** menu, click or tap **Self Check** to enter the sub-menus of "Self Check". You can test the following self-check items for the device.

Key Test

Click or tap **Key Test** to enter the key test interface (virtual front panel key), as shown in the figure below.




Figure 25.2 Key Test Interface

At this time, you can press the keys on the front panel to check whether the virtual keys are highlighted. If yes, it indicates that the keys work normally; if no, it indicates that there's something wrong with the keys. If the virtual key is not illuminated, the key may fail to work. Click or tap **Exit** at the lower-left corner of the key test interface

to exit the key test interface. You can also press  on the front panel for three consecutive times to exit the key test interface.

Touch Test

Click or tap **Touch Test** to enter the touch screen test interface, as shown in the figure below.




Figure 25.3 Touch Screen Test Interface

Slide with your finger on the screen. If there is a line displaying in the empty area where you slide on the screen and the box that you tap turns out to be filled with green background, it indicates that the touch function of this area is normal. Click or tap **Exit** at the lower-left corner of the touch screen test interface to exit the touch

screen test interface. You can also press  on the front panel for three consecutive times to exit the touch screen test interface.

Screen Test

Click or tap **Screen Test** to enter the screen test interface and check whether the defective pixel exists.

There are 15 colors of test screens. Click on the screen to go to the next screen test interface. Click or tap **Exit** at the upper-left corner of the touch screen test interface to

exit the touch screen test interface. You can also press  on the front panel for three consecutive times to exit the touch screen test interface.

Board Test

Click or tap **Board Test**, then the board test interface is displayed. Check whether the status of each module is in good condition.

26 Remote Control

The following ways of remote control are supported:

- **User-defined Programming**

Users can program and control the instrument by using the SCPI (Standard Commands for Programmable Instruments) commands. For details about the SCPI commands and programming, refer to *Programming Guide* of this product series.

- **PC Software**

Users can use the PC software to send commands to control the instrument remotely. RIGOL Ultra Sigma is recommended. You can download the software from RIGOL official website (<http://www.rigol.com>).

Operation Procedures:

- Set up communication between the instrument and PC.
- Run Ultra Sigma and search for the instrument resource.
- Open the remote command control panel to send commands.

- **Web Control**

This instrument supports Web Control. Connect the instrument to the network, then input the IP address of the instrument into the address bar of the browser of your computer. The web control interface is displayed. Click Web Control to enter the web control page. Then you can view the display of the real-time interface of the instrument. Through the Web Control method, you can migrate the device control to the control terminals (e.g. PC, Mobile, iPad, and other smart terminals) to realize remote control of the instrument.

This instrument can be connected to the PC via the USB, LAN, or GPIB interface to set up communication and realize remote control through the PC. The remote control can be realized by using SCPI (Standard Commands for Programmable Instruments) commands.

This chapter will illustrate how to use the RIGOL Ultra Sigma software to remotely control the instrument via various interfaces. Note: When communicating with the PC via GPIB, the instrument does not support large data transmission operation such as screen shot and waveform reading.



CAUTION

Before connecting the communication cable, please turn off the instrument to avoid causing damage to the communication interfaces.

26.1 Remote Control via USB

1. Connect the device

Use the USB cable to connect the rear-panel USB DEVICE interface of the instrument to the USB HOST interface of the PC.

2. Search for the device resource

Start up Ultra Sigma and the software will automatically search for the resource currently connected to the PC via the USB interface. You can also click **USB-TMC** to search for the resource.

3. View the device resource

The resources found will appear under the "RIGOL Online Resource" directory, and the model number and USB interface information of the instrument will also be displayed.

4. Control the instrument remotely

Right-click the device resource name and select "SCPI Panel Control" to open the remotely command control panel. Then you can send commands and read data through the panel. For details about the SCPI commands and programming, refer to the Programming Guide of this instrument.

26.2 Remote Control via LAN

1. Connect the device

Use the network cable to connect the instrument to your local area network (LAN).

2. Configure network parameters

Configure the network parameters of the instrument in **Utility>IO** menu.

3. Search for Search device resource

Start up Ultra Sigma and click **LAN** to open the panel as shown in the figure below. Click **Search** and the software searches for the instrument resources currently connected to the LAN and the resources found are displayed at the right section of the window as shown in the figure below. Click **OK** to add it.



Besides, you can input the IP address of the instrument manually into the text field under "Manual Input LAN Instrument IP", then click **TEST**. If the instrument passes the test, click **Add** to add the instrument to the LAN instrument resource list in the right section; if the instrument fails the test, please check whether the IP address that you input is correct, or use the auto search method to add the instrument resource.

4. View the device resource

The resources found will appear under the "RIGOL Online Resource" directory.

5. Control the instrument remotely

Right-click the device resource name and select "SCPI Panel Control" to open the remotely command control panel. Then you can send commands and read data through the panel.

6. Load LXI webpage

As this instrument conforms to LXI CORE 2011 DEVICE standards, you can load LXI web page through Ultra Sigma (right-click the instrument resource name and select "LXI-Web"). Various important information about the instrument (including the model, manufacturer, serial number, description, MAC address, and IP address) will be displayed on the web page. You can also directly input the IP address of the instrument in the address bar of the PC browser to load the LXI web page.

26.3 Remote Control via GPIB

1. Connect the device

Use the USB-GPIB interface converter to extend the GPIB interface for the instrument, and then use the GPIB cable to connect the instrument to the PC to realize remote control.

2. Install the driver of GPIB card

Correctly install the driver of the GPIB card which has been connected to the PC.

3. Set the GPIB address

Click or tap the Notification Area at the lower-right corner of the screen, then the **Utility** menu is displayed. Click or tap **IO**, and then click or tap the input field of **GPIB** to input the GPIB address with the pop-up numeric keypad.

4. Search for the device resource

Start Ultra Sigma, and then click **GPIB**. A window is displayed as shown in *Figure 26.1*. Click **Search** and the software searches for the instrument resource currently connected to the PC via the GPIB interface. The resource found is displayed at the right side of the window, as shown in *Figure 26.2*. Click **OK** to add it.




Figure 26.1 Search for the Available Device



Figure 26.2 Confirm the Available Device

5. View the device resource

Click **OK** to go back to the main interface of Ultra Sigma. The searched instrument resource will be displayed under the directory of "RIGOL Online Resource".

6. Control the instrument remotely

Right-click the device resource name. In the displayed menu, select "SCPI Panel Control" to open the programming command control panel. Then you can input commands to send commands and read data.

27 Troubleshooting

1. When I power on the instrument, the instrument stays black and does not display anything.

- a. Check whether the power supply has been connected correctly.
- b. Check whether the power key is really pressed.
- c. Check whether the fuse is blown. If you need to replace the fuse, use only the specified fuse that conforms to the product.
- d. Restart the instrument after finishing the above inspections.
- e. If the problem still persists, please contact RIGOL.

2. No waveform of the signal is displayed on the screen.

- a. Check whether the probe is properly connected to the item under test.
- b. Check whether there are signals generated from the item to be tested (you can connect the probe compensation output signal to the faulty channel to locate the problem, and then determine whether the channel or the item to be tested has a problem).
- c. Resample the signal.
- d. If the problem still persists, please contact RIGOL.

3. The USB storage device cannot be recognized.

- a. Check whether the USB storage device can work normally when connected to other instruments or PC.
- b. Make sure that the USB storage device is FAT32 format and flash type. The instrument doesn't support hardware USB storage device.
- c. After restarting the instrument, insert the USB storage device again to check whether it can work normally.
- d. If the USB storage device still cannot work normally, please contact RIGOL.

4. The touch-enabled operation does not work.

- a. Check whether you have locked the touch screen. If yes, unlock the touch screen.
- b. Check whether the screen or your finger is stained with oil or sweat. If yes, please clean the screen or dry your hands.
- c. Check whether there is a strong magnetic field around the instrument. If the instrument is close to the strong magnetic field (e.g. a magnet), please move the instrument away from the magnet field.

d. If the problem still persists, please contact RIGOL.

28 Appendix

28.1 Appendix A: Options and Accessories

Order Information	Order No.
Model	
500 MHz, 4 GSa/s, 12-bit, 4-CH	DHO5054
1 GHz, 4 GSa/s, 12-bit, 4-CH	DHO5104
500 MHz, 4 GSa/s, 12-bit, 4+16CH	MHO5054
1 GHz, 4 GSa/s, 12-bit, 4+16CH	MHO5104
500 MHz, 4 GSa/s, 12-bit, 6+16CH	MHO5056
1 GHz, 4 GSa/s, 12-bit, 6+16CH	MHO5106
500 MHz, 4 GSa/s, 12-bit, 8-CH	DHO5058
1 GHz, 4 GSa/s, 12-bit, 8-CH	DHO5108
Standard Accessories	
Power Cord Conforming to the Standard of the Destination Country	— —
USB Cable	— —
DHO5054/DHO5104/MHO5054/MHO5104: Passive HighZ Probe (500 MHz) x4	RP3500A
MHO5056/MHO5106: Passive HighZ Probe (500 MHz) x6	
DHO5058/DHO5108: Passive HighZ Probe (500 MHz) x8	
Recommended Accessory	
4 sets of 4-Channel Logic Analyzer Probe for MHO Series	PLA3204
Bandwidth Upgrade Option	
500 MHz-1 GHz Upgrade Option	DHO5004-BWU05T10 (4-channel model)

Order Information	Order No.
	DHO5008-BWU05T10 (8-channel model) MHO5004-BWU05T10 (4-channel model) MHO5006-BWU05T10 (6-channel model)
Protocol Decoding Option	
CAN-FD/LIN Bus Trigger and Analysis Option	DHO5000-AUTOA MHO5000-AUTOA
MIL-STD-1553 Bus Trigger and Analysis Option	DHO5000-AEROA MHO5000-AEROA
FlexRay Serial Bus Trigger and Analysis Option	DHO5000-FLEXA MHO5000-FLEXA
I2S Bus Trigger and Analysis Option	DHO5000-AUDIOA MHO5000-AUDIOA
Optional Accessories	
Built-in Dual-Channel 50 MHz Function Waveform Generator Option	MHO5000-AWG
Power Analysis Option	DHO5000-PWRA MHO5000-PWRA
Function and Application Bundle Option, including AUTOA/AEROA/FLEXA/AUDIOA/PWRA.	DHO5000-BND MHO5006-BND
Function and Application Bundle Option, including AUTOA/AEROA/FLEXA/AUDIOA/PWRA/AWG.	MHO5004-BND

Note:

For all the mainframes, accessories, and options, please contact the local office of RIGOL.

28.2 Appendix B: Warranty

RIGOL TECHNOLOGIES CO., LTD. (hereinafter referred to as RIGOL) warrants that the product mainframe and product accessories will be free from defects in materials and workmanship within the warranty period. If a product proves defective within the

warranty period, RIGOL guarantees free replacement or repair for the defective product.

To get repair service, please contact your nearest RIGOL sales or service office.

There is no other warranty, expressed or implied, except such as is expressly set forth herein or other applicable warranty card. There is no implied warranty of merchantability or fitness for a particular purpose. Under no circumstances shall RIGOL be liable for any consequential, indirect, ensuing, or special damages for any breach of warranty in any case.

28.3 Appendix C: Factory Settings

Press  on the front panel, then a message "Restore default settings?" is displayed. Click or tap **OK** to restore the instrument to its factory default settings, as shown in the table below. You can also click or tap **Default** on the quick operation toolbar to restore the instrument to its default settings.

Table 28.2 Factory Settings

Parameter	Factory Settings
Horizontal	
Horizontal Scale	2 μ s
Horizontal Position	0 s
Delayed Sweep	OFF
Roll	Auto
Fine	OFF
Horizontal Expansion	Center
Acquire	
Acquisition Mode	Normal
Memory Depth	10 kpts
Vertical	
CH1	ON
CH2	OFF
CH3	OFF
CH4	OFF
CH5	OFF
CH6	OFF
CH7	OFF
CH8	OFF
Default selected channel	CH1

Parameter	Factory Settings
Display	ON
Impedance	1 MΩ
Fine	OFF
Vertical Scale	50 mV
VOffset	0 V
Channel Unit	[V]
Channel Coupling	DC
Bias	0 V
BW Limit	OFF
Ch-Ch Skew	0 s
Display Label	OFF
Invert	OFF
Attenuation	1X
Trigger	
Trigger Type	Edge Trigger
Trigger Mode	Auto
Source Selection	CH1
Trigger Level	0V
Edge Type	Rising
Trigger Coupling	DC
Trigger Holdoff	8 ns
Noise Rejection	OFF
Display	
Display Type	Vector
Persistence Time	Min
Intensity	50%
Grid	FULL
Grid Brightness	50%
Window Transparency	50%
Cursor Brightness	80%
Show Scale	ON
Color Grade	OFF
Waveform Freeze	ON
Dual-channel Function/Arbitrary Waveform Generator (AFG)^[1]	
Channel Output	OFF
GI Waveform Type	Sine
Freq	1 GHz

Parameter	Factory Settings
Amplitude	5 V
Offset	0 V
Start Phase	0°
Modulation State	OFF
Modulating Waveform	Sine
Modulation Depth	100%
Modulation Frequency	100 MHz
Logic Analyzer (LA)^[2]	
Select	N/A
D15-D12	OFF
D11-D8	OFF
D7-D4	OFF
D3-D0	OFF
Wave Size	Medium
Arrange	D15-D0
Bode Plot^[3]	
Bode Plot	OFF
Input Source	CH1
Output Source	CH2
AFG Channel	AFG1
Output Impedance	HighZ
Sweep Type	Log
Display Type	Waveform
Start Freq	10 Hz
Stop Freq	1 MHz
Points/Decade	10
Output Amplitude	200 mV
Var. Amplitude	OFF
Measure	
Threshold	OFF
Histogram	OFF
Indicator	OFF
Statistics	OFF
Count	1,000
Display Type	%
Source	CH1

Parameter	Factory Settings
Upper	90%
Vmid	50%
Lower	10%
Amplitude Measurement Method	Auto
Region	Main
Cursor	
Mode	OFF
Manual	
Source	CH1
Select	X
AX BX	OFF
AX	-6 μ s
BX	6 μ s
Track	
Source A	CH1
Source B	CH1
AX BX	OFF
Track	X
AX	-6 μ s
BX	6 μ s
XY	
Select	X
AX BX	OFF
AX	-150 mV
BX	150 mV
Frequency Counter	
Source	CH1
Statistics	OFF
Measure	Frequency
Resolution	4
DVM	
Source	CH1
Mode	AC RMS
Beeper	OFF
When	In Limits
Upper	1 V
Lower	0 V
Save Image	

Parameter	Factory Settings
Format	*.png
Invert	OFF
Color	Color
Header	ON
Overlay	OFF
Save Wave	
Data Source	Screen
Format	*.bin
Save Setup	
File Type	*.stp
Load Setup	
File Type	*.stp
System Setting	
Beeper	OFF
AUX Out	TrigOut
Input Lock	OFF
Vertical Expansion	GND
Show Time	Display
Other Settings Related to the System Utility	
EXT 10M IN	OFF
Auto Config	
Peak to Peak	ON
Live CH	OFF
Overlay	ON
Coupling	OFF
Quick Settings	
Operation	Save Image
Format	*.png
Invert	OFF
Color	Color
Pass/Fail Test	
Enable	OFF
Source	CH1
Y Mask	480 mdiv
X Mask	240 mdiv

Parameter	Factory Settings
Format of the Mask File to be Loaded	*.pf
Format of the Mask File to be Saved	*.pf
File Name	RigolDS
Aux Output	OFF
Pulse	1 μ s
Output Event	Fail
Polarity	Positive
Error Action	Stop
Power Analysis	
Enable	OFF
Count	500
Power Quality	
Voltage Channel	CH1
Current Channel	CH2
Frequency Reference	Voltage
Setting Type	Percent(%)
Upper	90%
Mid	50%
Lower	10%
Ripple	
Source	CH1
Waveform Recording	
Enable	OFF
Record	
Interval	10 ns
Frames	1,000
Beeper	
Play	
Minimize	OFF
Play Mode	
Play Sequence	
Interval	100 ms
Math Operation	
Invert	OFF
Vertical Expansion	GND
Display Label	OFF
Grid	FULL
A+B	

Parameter	Factory Settings
Operation	OFF
SourceA	CH1
SourceB	CH1
Scale	500 mV
Offset	0 V
A-B	
Operation	OFF
SourceA	CH1
SourceB	CH1
Scale	500 mV
Offset	0 V
A×B	
Operation	OFF
SourceA	CH1
SourceB	CH1
Scale	500 mU
Offset	0 U
A÷B	
Operation	OFF
SourceA	CH1
SourceB	CH1
Scale	500 mU
Offset	0 U
FFT	
Operation	OFF
Source	CH1
X	Span-Center
Unit	dBm/dBV
Center Freq	5 MHz
Span	10 MHz
Vertical Scale	20 dB
Offset	0 dBV
Window Function	Hanning
Color Grade	OFF
Peak Search	OFF
Peak Number	5
Threshold	5.5 dBV
Excursion	1.8 dB
Table Order	Amp Order
A&&B	
Operation	OFF

Parameter	Factory Settings
SourceA	CH1
SourceB	CH1
Wave Size	Medium
Offset	0 div
Sensitivity	300 mdiv
CH1.Thre.	0 V
CH2.Thre.	0 V
CH3.Thre.	0 V
CH4.Thre.	0 V
CH5.Thre.	0 V
CH6.Thre.	0 V
CH7.Thre.	0 V
CH8.Thre.	0 V
A B	
Operation	OFF
SourceA	CH1
SourceB	CH1
Wave Size	Medium
Offset	0 div
Sensitivity	300 mdiv
CH1.Thre.	0 V
CH2.Thre.	0 V
CH3.Thre.	0 V
CH4.Thre.	0 V
CH5.Thre.	0 V
CH6.Thre.	0 V
CH7.Thre.	0 V
CH8.Thre.	0 V
A^B	
Operation	OFF
SourceA	CH1
SourceB	CH1
Wave Size	Medium
Offset	0 div
Sensitivity	300 mdiv
CH1.Thre.	0 V
CH2.Thre.	0 V
CH3.Thre.	0 V
CH4.Thre.	0 V
CH5.Thre.	0 V
CH6.Thre.	0 V

Parameter	Factory Settings
CH7.Thre.	0 V
CH8.Thre.	0 V
!A	
Operation	OFF
SourceA	CH1
Wave Size	Medium
Offset	0 div
Sensitivity	300 mdiv
CH1.Thre.	0 V
CH2.Thre.	0 V
CH3.Thre.	0 V
CH4.Thre.	0 V
CH5.Thre.	0 V
CH6.Thre.	0 V
CH7.Thre.	0 V
CH8.Thre.	0 V
Intg	
Operation	OFF
Source	CH1
Scale	500 mV*s
Offset	0 V*s
Bias	0 V
Diff	
Operation	OFF
Source	CH1
Scale	500 mV/s
Offset	0 V/s
Smooth	5
Sqrt	
Operation	OFF
Source	CH1
Scale	500 mU
Offset	0 U
Lg	
Operation	OFF
Source	CH1
Scale	500 mU
Offset	0 U
Ln	
Operation	OFF
Source	CH1

Parameter	Factory Settings
Scale	500 mU
Offset	0 U
Exp	
Operation	OFF
Source	CH1
Scale	500 mU
Offset	0 U
Abs	
Operation	OFF
Source	CH1
Scale	500 mV
Offset	0 V
Low Pass	
Operation	OFF
Source	CH1
Scale	500 mV
Offset	0 V
ωc	4 kHz
High Pass	
Operation	OFF
Source	CH1
Scale	500 mV
Offset	0 V
ωc	4 kHz
Band Pass	
Operation	OFF
Source	CH1
Scale	500 mV
Offset	0 V
$\omega c1$	4 kHz
$\omega c2$	8 kHz
Band Stop	
Operation	OFF
Source	CH1
Scale	500 mV
Offset	0 V
$\omega c1$	4 kHz
$\omega c2$	8 kHz
AX+B	
Operation	OFF
Source	CH1

Parameter	Factory Settings
Scale	500 mV
Offset	0 V
A	1
B	0
Ref	
Current	Ref1
Source	CH1
Vertical Scale	50 mV
VOffset	0 V
Label	REF1
Label Display	OFF
Color	Orange
Decode	
Bus Type	Parallel
Bus Status	OFF
Format	Hex
Label	ON
Event Table	OFF
Parallel	
CLK	OFF
Bus	CH1
Threshold	0V
Endian	Invert
Polarity	Positive
RS232	
Tx	CH1
Rx	OFF
Threshold	0 V
Polarity	Negative
Baud	9.6 kbps
Data Bits	8 bits
Endian	LSB
Parity	None
Stop Bit	1 bit
I2C	
SCL	CH1
SCL Thre	0V
SDA	CH2
SDA Thre	0V
Exchange	SCL/SDA

Parameter	Factory Settings
SPI	
CLK	CH1
Threshold	0 V
Slope	Rising
MISO	CH2
Threshold	0 V
MOSI	OFF
Mode	Timeout
Timeout Value	1 μ s
Polarity	Positive
Width	8
Endian	MSB
LIN	
Source	CH1
Threshold	0 V
Baud Rate	19.2 kbps
Parity	Without
Version	Both
CAN	
Source	CH1
Threshold	0 V
Signal Type	CAN_L
Baud	1 Mbps
Sample Position	50%
CAN-FD Baud	1 Mbps
FD Sample Position	50%
FlexRay	
Source	CH1
Threshold	0V
Channel Selection	A
Baud	10 Mbps
Signal Type	BP
Sample Position	50%
I2S	
SCLK	CH1
SCLK Threshold	0 V
SCLK Edge	Rising
WS	CH2
WS Threshold	0 V
SDA	CH3
SDA Threshold	0 V

Parameter	Factory Settings
Word Size	4
Receive	4
Alignment	I2S
WS Low	Left
Endian	MSB
Data Polarity	Positive
1553B	
Data	CH1
Threshold	0 V



NOTE


- [1]: The AFG function is the optional configuration for MHO5054 and MHO5104 models.
- [2]: Digital channels are only supported by MHO5054, MHO5104, MHO5056, and MHO5106.
- [3]: The Bode plot function is the standard configuration only for MHO5054 and MHO5104 models.

Boost Smart World and Technology Innovation

Industrial Intelligent
Manufacturing



Semiconductors



Education &
Research



Communication

System Integration



New Energy



- 5G Cellular-5G/WIFI
- UWB/RFID/ ZIGBEE
- Digital Bus/Ethernet
- Optical Communication

- Digital/Analog/RF Chip
- Memory and MCU Chip
- Third-Generation Semiconductor
- Solar Photovoltaic Cells

- New Energy Automobile
- PV/Inverter
- Power Test
- Automotive Electronics

*Provide Testing and Measuring Products
and Solutions for Industry Customers*

HEADQUARTER

RIGOL TECHNOLOGIES CO., LTD.
No.8 Keling Road, New District,
Suzhou, Jiangsu, P.R.China
Tel: +86-400620002
Email: info-cn@rigol.com

JAPAN

RIGOL JAPAN CO., LTD.
5F, 3-45-6, Minamitsuka, Toshima-Ku,
Tokyo, 170-0005, Japan
Tel: +81-3-6262-8932
Fax: +81-3-6262-8933
Email: info.jp@rigol.com

EUROPE

RIGOL TECHNOLOGIES EU GmbH
Friedrichshafener Str. 5
82205 Gilching
Germany
Tel: +49(0)8105-27292-21
Email: info-europe@rigol.com

KOREA

RIGOL KOREA CO., LTD.
5F, 222, Gonghang-daero,
Gangseo-gu, Seoul, Republic of Korea
Tel: +82-2-6953-4466
Fax: +82-2-6953-4422
Email: info.kr@rigol.com

NORTH AMERICA

RIGOL TECHNOLOGIES, USA INC.
10220 SW Nimbus Ave.
Suite K-7
Portland, OR 97223
Tel: +1-877-4-RIGOL-1
Email: sales@rigol.com

For Assistance in Other Countries

Email: info.int@rigol.com

RIGOL® is the trademark of **RIGOL TECHNOLOGIES CO., LTD.** Product information in this document is subject to update without notice. For the latest information about **RIGOL's** products, applications and services, please contact local **RIGOL** channel partners or access **RIGOL** official website: www.rigol.com